

GEHL®

Form No.
909772
Revision G
Dec. 2011

253, 303, 353 & 373

Compact Excavators



Operator's Manual

GEHL COMPANY

WARRANTY

GEHL COMPANY, hereinafter referred to as Gehl, warrants new Gehl equipment to the Original Retail Purchaser to be free from defects in material and workmanship for a period of twelve (12) months from the Warranty Start Date.

GEHL WARRANTY SERVICE INCLUDES:

Genuine Gehl parts and labor costs required to repair or replace equipment at the selling dealer's business location.

GEHL MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND, EXPRESS OR IMPLIED (INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR PARTICULAR PURPOSE), EXCEPT AS EXPRESSLY STATED IN THIS WARRANTY STATEMENT.

ANY OF THESE LIMITATIONS EXCLUDED BY LOCAL LAW SHALL BE DEEMED DELETED FROM THIS WARRANTY; ALL OTHER TERMS WILL CONTINUE TO APPLY.

SOME STATES DO NOT PERMIT THE EXCLUSION OR LIMITATION OF THESE WARRANTIES AND YOU MAY HAVE GREATER RIGHTS UNDER YOUR STATE LAW.

GEHL WARRANTY DOES NOT INCLUDE:

1. Transportation to selling dealer's business location or, at the option of the Original Retail Purchaser, the cost of a service call.
2. Used equipment.
3. Components covered by their own non-Gehl warranties, such as tires, batteries, trade accessories and engines.
4. Normal maintenance service and expendable, high-wear items.
5. Repairs or adjustments caused by: improper use; failure to follow recommended maintenance procedures; use of unauthorized attachments; accident or other casualty.
6. Liability for incidental or consequential damages of any type, including, but not limited to lost profits or expenses of acquiring replacement equipment.

No agent, employee or representative of Gehl has any authority to bind Gehl to any warranty except as specifically set forth herein.

TABLE OF CONTENTS

Chapter 1 - General Information	1-1
Introduction	1-1
Ownership Change	1-2
Excavator Component Identification	1-3
Specifications	1-4
Fluid Capacities/Lubricants	1-4
Model 253 Specifications	1-5
Engine	1-5
Hydraulic System	1-5
Undercarriage and Swing System	1-5
Dozer Blade	1-5
Bucket (Standard)	1-6
Noise Levels	1-6
General Specifications	1-6
Model 303 Specifications	1-7
Engine	1-7
Hydraulic System	1-7
Undercarriage and Swing System	1-7
Dozer Blade	1-7
Bucket (Standard)	1-8
Noise Levels	1-8
General Specifications	1-8
Fuse Panel	1-8
Model 353 Specifications	1-9
Engine	1-9
Hydraulic System	1-9
Undercarriage and Swing System	1-9
Dozer Blade	1-10
Bucket (Standard)	1-10
Noise Levels	1-10
General Specifications	1-10
Model 373 Specifications	1-11
Engine	1-11
Hydraulic System	1-11
Undercarriage and Swing System	1-11
Dozer Blade	1-12
Bucket (Standard)	1-12
Noise Levels	1-12
General Specifications	1-12
Load Diagrams	1-13
Checklists	1-17
Chapter 2 - Safety	2-1

General Safety Information	2-1
Unauthorized Modifications	2-2
Attachment Precautions	2-2
Mandatory Safety Shutdown Procedure	2-2
Operational Safety	2-2
Exposure to Crystalline Silica	2-5
Parking the Machine	2-5
Travel Controls May Produce Reversed Travel Operations	2-5
Additional Travel Precautions	2-5
Snow, Ice and Cold Temperature Operation Precautions	2-5
Fire Hazards	2-6
Fire Extinguisher Recommendation	2-6
Additional Safety Equipment	2-6
Maintenance Safety	2-7
Safety Decals	2-8
Hydraulic Cylinder Seal Periodic Replacement	2-9
High Pressure Hydraulic Lines Store Energy	2-9
Operator's Cab and Swing Frame Deck Maintenance	2-9
Battery Electrolyte and Explosive Gas Hazard	2-9
Battery Disconnection Precaution	2-9
Jump-starting or Charging the Battery	2-9
Lifting the Machine with a Crane	2-9
Transporting	2-10
Safety Decals	2-10
New Decal Application	2-10
ISO-Style Safety Decal Locations (Later Machines)	2-11
ISO-Style Information Decal Locations (All Machines)	2-14
ANSI-Style Safety Decal Locations (Early Machines)	2-16
Chapter 3 - Operation	3-1
Operating Controls	3-1
Machine Orientation	3-1
Ignition Key Switch	3-6
Engine Speed Control	3-6
Travel Controls	3-6
SAE-Pattern Operating Controls	3-8
ISO-Pattern Operating Controls	3-8
Boom Swivel	3-9
Optional Joystick Buttons	3-9
Operator's Seat Adjustments	3-12
Seat Belt	3-13
Ventilation	3-14
Machine Operation	3-15
Engine Shut Down	3-18
Travel	3-18
Water Operation	3-20
Operating Instructions	3-21

Slope Operation	3-22
Cold Weather Operation	3-23
Swiveling the Boom	3-23
Grading	3-24
Mounting/Removing Buckets	3-24
Auxiliary Hydraulics Connections	3-26
Excavating	3-27
Proper Digging Techniques	3-28
Transporting	3-30
Towing	3-30
Lifting the Machine	3-30
Loading and Transporting	3-31
Chapter 4 - Maintenance	4-1
General Information	4-1
Care and Servicing	4-1
Maintenance Safety	4-2
Maintenance Schedule	4-3
Check, Clean and Inspect	4-3
Fluid and Filter Changes	4-4
Swing Gear Ring	4-5
Cab Heating System	4-5
Bucket, Boom and Dozer Blade	4-5
Lubrication	4-6
Recommended Lubricants	4-7
Engine Oil	4-7
Hydraulic Oil	4-7
Swing Ring	4-7
Final Drive Unit	4-7
All Lubrication Points - See Figure 4-1	4-7
Engine	4-8
Checking Engine Oil Level	4-8
Changing Engine Oil and Filter	4-9
Air Cleaner Service	4-10
Fuel System	4-11
Filling the Fuel Tank	4-11
Fuel Filter	4-12
Water Separator	4-13
Purging Air from the Fuel System	4-13
Coolant System	4-14
Checking Coolant Level	4-14
Checking and Adjusting V-belt Tension	4-15
Electrical System	4-15
Fuses	4-15
Battery	4-16
Hydraulic System	4-19
Checking Hydraulic Oil Level	4-19

Changing Hydraulic Oil	4-20
Hydraulic Hose Maintenance	4-21
Track System	4-22
Track Cleaning	4-22
Changing Final Drive Oil	4-22
Checking and Adjusting Track Tension	4-23
Windshield Washer Fluid	4-24
Cab/Canopy Removal/Replacement	4-25
Long-Term Storage	4-27
Before Storage	4-27
During Storage	4-27
After Storage	4-27
Chapter 5 - Troubleshooting	5-1
Engine	5-1
Indicator Lamps	5-3
Seals and Hoses	5-3
Traveling Gear	5-4
Bucket, Boom and Dozer Blade	5-4

CHAPTER 1 – GENERAL INFORMATION

INTRODUCTION

This Operator's Manual is intended to give the owner/operator assistance in preparing, adjusting, maintaining and servicing the machine. More importantly, this manual provides an operating plan for safe and proper use of the machine. Major points of safe operation are detailed in Chapter 2 – *Safety*.

Read and understand the contents of this manual completely and become familiar with the machine before attempting to operate it. Contact your Gehl dealer to obtain extra manuals or manuals in other languages.

Throughout this manual, information is introduced by the word **NOTE** or **IMPORTANT**. Be sure to read the message carefully and comply with the message. Following this information will improve operating and maintenance efficiency, help to avoid breakdown and damage and extend the service life of the machine.

Do not use the machine for any application or purpose other than described in this manual. Consult your dealer before using special attachments or equipment not approved for use with the machine. Any person making unauthorized modifications is responsible for the consequences.

The use of the machine is subject to certain hazards that cannot be eliminated by mechanical means – only by exercising intelligence, care and common sense. Such hazards include, but are not limited to: hillside operation, overloading, load stability, poor maintenance and use of the machine for purposes for which it was not intended or designed.

It is essential to have competent and careful operators, not physically or mentally impaired, who are thoroughly trained in safe operation and proper load handling.

It is recommended that operators be capable of obtaining a valid motor vehicle operator's license.

Manitou Americas, Inc. reserves the right to make changes and improvements in the design and construction of any part without incurring the obligation to install such changes on any unit previously delivered.

Some illustrations in this manual may show doors, guards and shields open or removed for illustrative purposes only. BE SURE all doors, guards and shields are in their proper operating positions BEFORE starting the engine to operate the machine.

The Gehl dealer network stands ready to provide any assistance you may require, including genuine service parts. All service parts should be obtained from your dealer. Give complete information about the part and include the model and serial number of your machine. Record the serial number in the space provided on this page, as a handy reference.

Purchased from: _____

Date of Purchase: _____

Model No.: _____

Serial No.: _____

Serial Number Location

The machine serial number plate (1, "Machine and Cab Serial Number Plate Locations" on page 1-2.) is located on the front frame, below the operator's cab. The cab/canopy serial number (2) is located on the inside of the cab frame.




Figure 1-1 Machine and Cab Serial Number Plate Locations

Engine Serial Number Location

The engine serial number label is located on the cylinder head cover





Figure 1-2 Machine and Cab Serial Number Plate Locations

Ownership Change

If this machine was purchased “used,” or if the owner’s address has changed, please provide your Gehl dealer or Gehl Company Service Department with the owner’s name and current address, along with the machine model and serial numbers. This will allow the registered owner information to be updated, so that the owner can be notified directly in case of an important product issue, such as a safety update program.

Excavator Component Identification




Figure 1-3 Component Names (353 canopy model shown)

SPECIFICATIONS

Fluid Capacities/Lubricants

Note: Capacities indicated are approximate.

Component/Application	Lubricant	Specification	Season/Temperature	Capacity ^a
Diesel Engine	Engine Oil ^b	SAE 10W-40 (according to DIN 51502); API: CD, CF, CF-4, CI-4	-4°F (-20°C) +104°F (+40°C)	Model 253: see “Engine” on page 1-5. Model 303: see “Engine” on page 1-7. Model 353: see “Engine” on page 1-9. Model 373: see “Engine” on page 1-11.
		SAE E3, E4, E5		
Travelling Drive Gearbox Oil	Gearbox Oil ^c	Q8 T 55, SAE80W-90	Year-round	About 0.6 qts. (0.6 L) each
		FINA PONTONIC GLS SAE80W-90		
Hydraulic Oil Tank	Hydraulic Oil ^d	HVLP46 (according to DIN 51524 section 3)	Year-round	Model 253: 7. gal. (27 L) Models 353/373: 13 gal. (50 L)
		HV 46 (according to ISO 6743/4)		
	Biodegradable Oil ^e	PANOLIN HLP Synth 46		
		FINA BIOHYDRAN SE 46		
Grease	Roller and Friction Bearings	FINA Energ grease L21M	Year-round	As Required
	Open Gear (live ring gears)	BP Energ grease MP-MG2		
Grease Fittings	Multipurpose Grease ^f	FINA Energ grease L21M	Year-round	As Required
Battery Terminals	Acid-proof Grease ^g	FINA Marson L2	Year-round	As Required
Diesel Fuel Tank	Diesel Fuel ^h	2-D ASTM D975 – 94	Depending on outside temperatures Summer or winter diesel fuel.	Model 253: see “Engine” on page 1-5. Model 303: see “Engine” on page 1-7. Model 353: see “Engine” on page 1-9. Model 373: see “Engine” on page 1-11.
		1-D ASTM D975 – 94		
Engine and Hydraulic Oil Cooler	Coolant	Water + antifreeze ASTM D4985	Year-round	
Windshield Washer	Cleaning Agent	Water + Antifreeze	Year-round	1.3 qts. (1.2 L)

a. Capacities shown are approximate; use only oil level check to determine correct oil level.

b. BP Vanellus MG 15W40, BP Vanellus C-Extra 10W30, Chevron Delo 400 15W40 or equivalent; Refer to engine operator’s manual for more detailed information about recommended oil grade type use depending upon ambient temperature.

c. Hypoid gearbox oil based on basic mineral oil (API GL-4, GL-5).

d. Mobile DTE15M, Amoco Rykon 46, BP Energol HLP-HD 46 or equivalent.

e. Based on saturated synthetic esters with an iodine value of < 10 g/mg, according to DIN, section 3, HVLP, HEES. IMPORTANT! Do not mix biodegradable oil types/grades; do not mix biodegradeable and mineral oils. Ensure hydraulic attachments are free of mineral oil residue before use.

f. FINA Energ grease 21M, Chevron RPM Heavy-Duty Grease No. 2, Mobilgrease Moly 52, or BP Energ grease Moly EP2.

g. Standard acid-proof grease.

h. Sulphur content below 0.05% cetane number over 45.

Model 253 Specifications

Engine

	SN Before AD00001	SN AD00001 — AD00728
Model	Kubota D1403	Yanmar 3 TNE 88-SNS
Type	Water-cooled 3-cylinder diesel engine	
Capacity	85 cu. in. (1393 cc)	100 cu. in. (1642 cc)
Horsepower in DIN	24 hp (18 kW)	26 hp (19.1 kW)
Revolutions per minute	2200 rpm	
Battery	12V/71Ah	
Diesel Tank	11 gal. (41 L)	
Motor Oil ^a	7.4 qts. (7 L)	7.1 qts. (6.7 L)
Coolant Capacity	2.9 qts. (2.7 L)	6.7 qts. (6.3 L)

a. Capacities shown are approximate; use only oil level check to determine correct oil level.

Hydraulic System

Pump	Double axial-piston pump and gear pump
Pump Capacity	7 gpm (26.4 L/min) + 7 gpm (26.4 L/min) + 4.7 gpm (17.6 L/min)
Operating Pressure (working and driving)	3,481 psi (240 bar) and 3,481 psi (240 bar)
Operating Pressure (swing unit)	2,901 psi (200 bar)
Hydraulic Fluid Cooler	Standard
Hydraulic Reservoir (system capacity)	7 gal. (27 L)

Undercarriage and Swing System

Travel Speed	
Low Speed	1.4 mph (2.2 km/h)
High Speed	2.7 mph (4.3 km/h)
Ground Clearance	10.75" (270 mm)
Swing Speed	9 rpm
Gradability	30° (58%)
Rubber Track Width	10" (250 mm)
Number of Track Rollers	3 per side
Average Ground Pressure	5 psi (0.33 kg/cm ²)

Dozer Blade

Width	54" (1370 mm)
Height	13.25" (340 mm)
Maximum Lift Above Ground	15.25" (390 mm)
Maximum Depth Below Ground	16.25" (415 mm)

Bucket (Standard)

Width	20" (500 mm)
Capacity	2.75 cu. ft. (75 L)

Noise Levels

Sound Power	94 dB(A)
Sound Pressure	74 dB(A)

General Specifications

Operating Weight w/Cab (SAE)	5,732 lbs. (2600 kg)
Height	93" (2370 mm)
Width	54" (1370 mm)
Length	120" (3050 mm)
Max. Digging Depth	102.5" (2605 mm)
Max. Digging Height	162.5" (4125 mm)
Max. Dumping Height	115.25" (2925 mm)
Max. Digging Radius	177.75" (4515 mm)
Bucket Tooth Breakout Force	4,343 lbf (19.3 kN)
Min. Tail Swing Radius	48.75" (1240 mm)
Min. Arm Clearance	53.75" (1360 mm)
Boom Swivel Angle – Left	80°
Boom Swivel Angle – Right	50°

Model 303 Specifications

Engine

	SN Before AD00001	SN AD00001 – AD01819	SN AD018201 – AE02400
Model	Kubota D1703	Yanmar 3TNE88-SNS	Yanmar 3TNV88-NNS, EPA Tier II
Type	Water-cooled 3-cylinder diesel engine		
Capacity	101 cu. in. (1647 cc)	100 cu. in. (1642 cc)	98 cu. in. (1600 cc)
Horsepower in DIN	33 hp (24 kW)	29.5 hp (22 kW)	29.5 hp (22 kW)
Revolutions per minute	2450 rpm		2500 rpm
Battery	12V/71Ah		
Diesel Tank	11 gal. (41 L)		
Motor Oil	7.5 qts. (7 L)	7 qts. (6.7 L)	
Coolant Capacity	3 qts. (2.7 L)	6.7 qts. (6.3 L)	

Hydraulic System

Pump	Double axial-piston pump and gear pump
Pump Capacity	10.3 gpm (39.2 L/min) + 10.3 gpm (39.2 L/min) + 6.3 gpm (25.7 L/min)
Operating Pressure (working and driving)	3,480 psi (240 bar) and 3,480 psi (240 bar)
Operating Pressure (swing unit)	2,900 psi (200 bar)
Hydraulic Fluid Cooler	Standard
Hydraulic Reservoir (system capacity)	13.25 gal. (50 L)

Undercarriage and Swing System

Travel Speed	
Low Speed	1.6 mph (2.5 km/h)
High Speed	3.2 mph (5.0 km/h)
Ground Clearance	11 in. (275 mm)
Swing Speed	10 rpm
Gradability	30° (58%)
Rubber Track Width	12 in. (300 mm)
Number of Track Rollers	4 per side
Average Ground Pressure	5 psi (0.33 kg/cm ²)

Dozer Blade

Width	63.75 in. (1620 mm)
Height	14.5 in. (370 mm)
Maximum Lift Above Ground	16.25 in. (410 mm)
Maximum Depth Below Ground	19 in. (480 mm)

Bucket (Standard)

Width	20 in. (500 mm)
Capacity	3.25 cu. ft. (88 L)

Noise Levels


Sound Power	94 dB(A)
Sound Pressure	74 dB(A)

General Specifications

Operating Weight w/Cab (SAE)	6,878 lbs. (3120 kg)
Height	94.5 in. (2400 mm)
Width	58.3 in. (1480 mm)
Length	124.0 in. (3150 mm)
Max. Digging Depth (Standard Dipper)	109.1 in. (2770 mm)
Max. Digging Height (Standard Dipper)	176.0 in. (4470 mm)
Max. Dumping Height (Standard Dipper)	124.0 in. (3150 mm)
Max. Digging Radius (Standard Dipper)	189.0 in. (4800 mm)
Bucket Tooth Breakout Force	5,957 lbf (26.5 kN)
Boom Swivel Angle – Left	80°
Boom Swivel Angle – Right	45°

Fuse Panel

The following table shows fuse locations and the protected circuits and functions.

	Fuse	Current	Protected Circuit
	1	10 Amp	Switch / Instrument lighting, engine relays
	2	15 Amp	Lights, boom / roof lights
	3	10 Amp	12 V / 15 cab
	4	15 Amp	Cab heat, horn
	5	10 Amp	Rotating beacon, radio, cigarette lighter
	6	15 Amp	Socket
	7	10 Amp	Spare
	8	10 Amp	Valve
	9	10 Amp	Windshield wiper, cab
	10	10 Amp	Alternator
	11	10 / 15 Amp	Spare

Model 353 Specifications

Engine

	SN Before AD00001	SN AD00001 – AD01552	SN AD01553 – AE02832	SN AG00593 and Up
Model	Kubota D1703	Yanmar 4TNV88-ENSR	Yanmar 4TNV88-WNS, EPA Tier II	Yanmar 4TNV 88-BWNS, EPA Tier III
Type	Water-cooled 3-cylinder diesel engine	Water-cooled 4-cylinder diesel engine		
Capacity	100 cu. in. (1647 cc)	134 cu. in. (2190 cc)		
Horsepower in DIN	33 hp (24 kW)	32 hp (23.7 kW)		
Revolutions per minute	2450 rpm	2000 rpm	2500 rpm	2025 rpm
Battery/Electical	12V/71Ah			
Diesel Tank	11 gal. (41 L)	13.7 gal. (52 L)		
Motor Oil	7.5 qts. (7 L)	7.8 qts. (7.4 L)		
Coolant Capacity	3 qts. (2.7 L)	6.7 qts. (6.3 L)		

Hydraulic System

Pump	Double variable-displacement pump and gear pump
Pump Capacity	11.8 gpm (44.5 L/min) + 11.8 gpm US (44.5 L/min) + 6.6 gpm (25.0 L/min)
Operating Pressure (working and driving)	3,480 psi (240 bar) and 3,480 psi (240 bar)
Operating Pressure (swing unit)	2,900 psi (200 bar)
Hydraulic Fluid Cooler	Standard
Hydraulic Reservoir (system capacity)	13.25 gal. (50 L)

Undercarriage and Swing System

Travel Speed	
Low Speed	1.6 mph (2.5 km/h)
High Speed	3.2 mph (5.0 km/h)
Ground Clearance	11 in. (275 mm)
Swing Speed	10 rpm
Gradability	30° (58%)
Rubber Track Width	12 in. (300 mm)
Number of Track Rollers	4 per side
Average Ground Pressure	5 psi (0.33 kg/cm ²)

Dozer Blade

Width	63.75 in. (1620 mm)
Height	14.5 in. (370 mm)
Maximum Lift Above Ground	16.25 in. (410 mm)
Maximum Depth Below Ground	19 in. (480 mm)

Bucket (Standard)

Width	20 in. (500 mm)
Capacity	3.25 cu. ft. (88 L)

Noise Levels

Sound Power	94 dB(A)
Sound Pressure	74 dB(A)

General Specifications

Operating Weight w/Cab (SAE)	7,700 lbs. (3500 kg)
Height	95 in. (2405 mm)
Width	63.75 in. (1620 mm)
Transport Length	204 in. (5170 mm)
Max. Digging Depth (Standard Dipper)	127.25 in. (3230 mm)
Max. Digging Height (Standard Dipper)	193.5 in. (4910 mm)
Max. Dumping Height (Standard Dipper)	142.5 in. (3620 mm)
Max. Digging Radius (Standard Dipper)	207.5 in. (5270 mm)
Bucket Tooth Breakout Force	6,812 lbf (30.3 kN)
Min. Tail Swing Radius	55.25 in. (1400 mm)
Min. Arm Clearance	57.75 in. (1470 mm)
Boom Swivel Angle – Left	80°
Boom Swivel Angle – Right	50°

Model 373 Specifications

Engine

	SN Before AD00001	SN AD00001 – AD01553	SN AD01554 – AE02600	SN AG00580 and Up
Model	Kubota D1703	Yanmar 4TNV88- ENSR	Yanmar 4TNV88- WNS, EPA Tier II	Yanmar 4TNV 88- BWNS, EPA Tier III
Type	Water-cooled 3-cyl- inder diesel engine	Water-cooled 4-cylinder diesel engine		
Capacity	100 cu. in. (1647 cc)	134 cu. in. (2190 cc)		
Horsepower in DIN	33 hp (24 kW)	32 hp (23.7 kW)		
Revolutions per minute	2450 rpm	2000 rpm	2500 rpm	2025 rpm
Battery	12V/71Ah		12V/88Ah	
Diesel Tank	11 gal. (41 L)	13.7 gal. (52 L)		
Motor Oil	7.5 qts. (7 L)	7.8 qts. (7.4 L)		
Coolant Capacity	3 qts. (2.7 L)	6.7 qts. (6.3 L)		

Hydraulic System

Pump	Double variable-displacement pump and gear pump
Pump Capacity	11.8 gpm (44.5 L/min) + 11.8 gpm (44.5 L/min) + 6.6 gpm (25.0 L/min)
Operating Pressure (working and driving)	3,480 psi (240 bar) and 3,480 psi (240 bar)
Operating Pressure (swing unit)	2,900 psi (200 bar)
Hydraulic Fluid Cooler	Standard
Hydraulic Reservoir (system capacity)	13.25 gal. (50 L)

Undercarriage and Swing System

Travel Speed	
Low Speed	1.6 mph (2.5 km/h)
High Speed	3.2 mph (5.0 km/h)
Ground Clearance	11 in. (280 mm)
Swing Speed	10 rpm
Gradability	30° (58%)
Rubber Track Width	12 in. (300 mm)
Number of Track Rollers	4 per side
Average Ground Pressure	5 psi (0.33 kg/cm ²)

Dozer Blade

Width	63.75 in. (1620 mm)
Height	14.5 in. (370 mm)
Maximum Lift Above Ground	16.25 in. (410 mm)
Maximum Depth Below Ground	19 in. (480 mm)

Bucket (Standard)

Width	20 in. (500 mm)
Capacity	3.25 cu. ft. (88 L)

Noise Levels







Sound Power	94 dB(A)
Sound Pressure	74 dB(A)

General Specifications


Operating Weight w/Cab (SAE)	8,232 lbs. (3734 kg)
Height	99.20 in. (2520 mm)
Width	63.75 in. (1620 mm)
Length	132.25 in. (3360 mm)
Max. Digging Depth (Standard Dipper)	122.83 in. (3120 mm)
Max. Digging Height (Standard Dipper)	197.64 in. (5020 mm)
Max. Dumping Height (Standard Dipper)	147.05 in. (3735 mm)
Max. Digging Radius (Standard Dipper)	207.5 in. (5270 mm)
Bucket Tooth Breakout Force	6,834 lbf (30.4 kN)
Min. Tail Swing Radius	55.25 in. (1400 mm)
Min. Arm Clearance	57.75 in. (1470 mm)
Boom Swivel Angle – Left	80°
Boom Swivel Angle – Right	50°
Cab Tilt	15° upwards or downwards

Load Diagrams

Model 253 Load Diagram



A			11'6" (3.5 m)		9'10" (3.0 m)		8'2" (2.5 m)		6'7" (2.0 m)	
B										
	Pounds (Kilograms)		Pounds (Kilograms)		Pounds (Kilograms)		Pounds (Kilograms)		Pounds (Kilograms)	
9'10" (3.0 m)	915* (415*)	827 (375)			882* (400*)	849 (385)				
6'7" (2.0 m)	904* (410*)	595 (270)	904* (410*)	650 (295)	926* (420*)	838 (380)	1058* (480*)	1135 (515)		
3'3" (1.0 m)	937* (425*)	507 (230)	1014* (460*)	617 (280)	1190* (540*)	783 (355)	1477* (670*)	981 (445)	2205* (1000*)	1400 (635)
0 (0 m)	992* (450*)	518 (235)	1113* (505*)	595 (270)	1400* (635*)	739 (335)	1907* (865*)	959 (435)	2668* (1210*)	1290 (585)
-3'3" (-1.0 m)	1047* (475*)	628 (285)			1279* (580*)	728 (330)	1742* (790*)	937 (425)	2271* (1030*)	1301 (590)
-6'7" (-2.0 m)	981* (445*)	981* (445*)							959* (435*)	959 (435)

All table values are for a machine in a horizontal position on firm ground without a bucket.



Maximum permissible load on dipper arm

A	Overhang from the center of the turntable
B	Height of load fixing point
*	Lifting capacity hydraulically limited

	Dozer blade support in drive direction
	Dozer blade support 90° to drive direction







If equipped with a bucket or other implements, lift capacity or tilt load is reduced by bucket or implement weight.

Calculation basis: according to ISO 10567.


The excavator's lift capacity is restricted by the settings of the pressure relief valves and the hydraulic system's stabilizing features.

Neither 75% of the static tilt load nor 87% of the hydraulic lift capacity is exceeded.



Model 303 Load Diagram

A			11'6" (3.5 m)		9'10" (3.0 m)		8'2" (2.5 m)		6'7" (2.0 m)	
B										
	Pounds (Kilograms)		Pounds (Kilograms)		Pounds (Kilograms)		Pounds (Kilograms)		Pounds (Kilograms)	
9'10" (3.0 m)	1676* (760*)	860 (390)			1598* (725*)	937 (425)	1543* (700*)	1279 (580)		
6'7" (2.0 m)	1676* (760*)	650 (295)	1698* (770*)	794 (360)	1819* (825*)	948 (430)	2094* (950*)	1279 (580)		
3'3" (1.0 m)	1742* (790*)	573 (260)	1984* (900*)	772 (350)	2326* (1055*)	948 (430)	2932* (1330*)	1279 (580)	4387* (1990*)	1786 (810)
0 (0 m)	1819* (825*)	595 (270)	2205* (1000*)	717 (325)	2701* (1225*)	959 (435)	3560* (1615*)	1268 (575)	5071* (2300*)	1631 (740)
-3'3" (-1.0 m)	1896* (860*)	705 (320)			2524* (1145*)	1014 (460)	3318* (1505*)	1268 (575)	4354* (1975*)	1620 (735)
-6'7" (-2.0 m)	1819* (825*)	1301 (590)							2370* (1075*)	1709 (775)

All table values are for a machine in a horizontal position on firm ground without a bucket.



Maximum permissible load on dipper arm	
A	Overhang from the center of the turntable
B	Height of load fixing point
*	Lifting capacity hydraulically limited

	Dozer blade support in drive direction
	Dozer blade support 90° to drive direction







If equipped with a bucket or other implements, lift capacity or tilt load is reduced by bucket or implement weight.

Calculation basis: according to ISO 10567.


The excavator's lift capacity is restricted by the settings of the pressure relief valves and the hydraulic system's stabilizing features.

Neither 75% of the static tilt load nor 87% of the hydraulic lift capacity is exceeded.



Model 353 Load Diagram

A			14'9" (4.5 m)		11'6" (3.5 m)		8'2" (2.5 m)		4'11" (1.5 m)	
B										
	Pounds (Kilograms)		Pounds (Kilograms)		Pounds (Kilograms)		Pounds (Kilograms)		Pounds (Kilograms)	
9'10" (3.0 m)	1764* (800*)	882 (400)			1642* (745*)	1135 (515)				
6'7" (2.0 m)	1852* (840*)	717 (325)			1918* (870*)	1058 (480)	2447* (1110*)	1819 (825)		
3'3" (1.0 m)	1962* (890*)	639 (290)	1984* (900*)		2425* (1100*)	992 (450)	3957* (1795*)	1620 (735)		
0 (0 m)	2105* (955*)	661 (300)	2105* (955*)		2866* (1300*)	937 (425)	4696* (2130*)	1477 (670)		
-3'3" (-1.0 m)	2304* (1045*)	750 (340)			2888* (1310*)	926 (420)	4630* (2100*)	1466 (665)	9259* (4200*)	3770 (1710)
-6'7" (-2.0 m)	2535* (1150*)	1058 (480)					3748* (1700*)	1565 (710)	7275* (3300*)	3869 (1755)

All table values are for a machine in a horizontal position on firm ground without a bucket.



Maximum permissible load on dipper arm	
A	Overhang from the center of the turntable
B	Height of load fixing point
*	Lifting capacity hydraulically limited

	Dozer blade support in drive direction
	Dozer blade support 90° to drive direction







If equipped with a bucket or other implements, lift capacity or tilt load is reduced by bucket or implement weight.

Calculation basis: according to ISO 10567.


The excavator's lift capacity is restricted by the settings of the pressure relief valves and the hydraulic system's stabilizing features.

Neither 75% of the static tilt load nor 87% of the hydraulic lift capacity is exceeded.



Model 373 Load Diagram

A			14'9" (4.5 m)		11'6" (3.5 m)		8'2" (2.5 m)		4'11" (1.5 m)	
B										
	Pounds (Kilograms)		Pounds (Kilograms)		Pounds (Kilograms)		Pounds (Kilograms)		Pounds (Kilograms)	
9'10" (3.0 m)	1764* (800*)	1433 (650)			1653* (750*)	1213 (550)				
6'7" (2.0 m)	1863* (845*)	772 (350)			1984* (900*)	1168 (530)	2668* (1210*)	1962 (890)		
3'3" (1.0 m)	1984* (900*)	750 (340)	1984* (900*)	750 (340)	2480* (1125*)	1102 (500)	4079* (1850*)	1764 (800)		
0 (0 m)	2105* (955*)	750 (340)	2105* (955*)	750 (340)	2866* (1300*)	1014 (460)	4740* (2150*)	1653 (750)		
-3'3" (-1.0 m)	2315* (1050*)	871 (395)			2866* (1300*)	992 (450)	4586* (2080*)	1653 (750)	9259* (4200*)	4090 (1855)
-6'7" (-2.0 m)	2536* (1150*)	1268 (575)					3638* (1650*)	1742 (790)	6945* (3150*)	4211 (1910)

All table values are for a machine in a horizontal position on firm ground without a bucket.



Maximum permissible load on dipper arm	
A	Overhang from the center of the turntable
B	Height of load fixing point
*	Lifting capacity hydraulically limited

	Dozer blade support in drive direction
	Dozer blade support 90° to drive direction

If equipped with a bucket or other implements, lift capacity or tilt load is reduced by bucket or implement weight.

Calculation basis: according to ISO 10567.

The excavator's lift capacity is restricted by the settings of the pressure relief valves and the hydraulic system's stabilizing features.

Neither 75% of the static tilt load nor 87% of the hydraulic lift capacity is exceeded.

CHECKLISTS

Pre-Delivery Checklist

The following checklist is an important reminder of valuable information and inspections that **MUST** be made before delivering the machine to the customer. Check off each item after the prescribed action is taken.

✓ CHECK THAT:

- ☐ Machine has not been damaged in shipment. Check for such things as dents and loose or missing parts. Correct or replace components as required.
- ☐ Battery is securely mounted and not cracked. Be sure cable connections are tight.
- ☐ Cylinders, hoses and fittings are not damaged, leaking or loosely connected.
- ☐ Coolant/radiator hoses and fittings are not damaged, leaking or loosely connected. Coolant system is filled to the proper level and has proper antifreeze protection.
- ☐ Filters are not damaged, leaking or loosely secured.
- ☐ Machine is properly lubricated and no grease fittings are missing or damaged.
- ☐ Hydraulic system reservoir, engine crankcase and drive motors are filled to their proper levels.
- ☐ All adjustments are made to comply with settings provided in *Chapter 4 – Maintenance* of this manual.
- ☐ All guards, shields and decals are in place and secured.
- ☐ Model and serial numbers for the machine are recorded in the space provided on this page and on page 1-1

IMPORTANT

Start the engine and test run the unit while checking that all controls operate properly.

✓ CHECK THAT:

- ☐ Drive controls and boom/arm/bucket/dozer blade/swing/pivot controls operate properly and are not damaged or binding.
- ☐ Drive controls are properly adjusted for correct neutral position.
- ☐ The parking and travelling gear brake, along with the lock-out devices, are activated with the machine stationary (no pilot control pressure).
- ☐ All hydraulic functions are NOT operational with the left control console in the raised lock-out position.
- ☐ All instrument panel gauges, indicator lights, etc. function properly and all installed lights, such as work lights, function properly.

I acknowledge the pre-delivery procedures were performed on this unit as outlined on this page.

Dealership's Name

Dealer Representative's Name

Date Checklist Filled Out

Model & Serial Number

Delivery Checklist

The following checklist is an important reminder of valuable information that **MUST** be passed on to the customer at the time of delivery. Check off each item as you explain it to the customer.

✓ EXPLAIN:

- ☐ The *Safety* and *Operation* chapters of this manual, regarding the safe operation of the machine.
- ☐ The *Maintenance* and *Troubleshooting* chapters for information regarding the proper maintenance of the machine. Explain that regular lubrication and maintenance is required for continued safe operation and long machine life.
- ☐ Give this Operator's Manual and the AEM Compact Excavator Safety Manual to the customer and instruct the customer to read and completely understand the contents before operating the machine.
- ☐ Complete the Owner's Registration, including customer's signature and return it to Manitou Americas, Inc.
- ☐ Explain that a copy of the product warranty is included on the inside front cover of this Operator's Manual.

Customer's Signature

Date Delivered

RETAIN FOR CUSTOMER'S RECORDS

INTENTIONALLY BLANK

CHECKLISTS

Pre-Delivery Checklist

The following checklist is an important reminder of valuable information and inspections that **MUST** be made before delivering the machine to the customer. Check off each item after the prescribed action is taken.

✓ CHECK THAT:

- ☐ Machine has not been damaged in shipment. Check for such things as dents and loose or missing parts. Correct or replace components as required.
- ☐ Battery is securely mounted and not cracked. Be sure cable connections are tight.
- ☐ Cylinders, hoses and fittings are not damaged, leaking or loosely connected.
- ☐ Coolant/radiator hoses and fittings are not damaged, leaking or loosely connected. Coolant system is filled to the proper level and has proper antifreeze protection.
- ☐ Filters are not damaged, leaking or loosely secured.
- ☐ Machine is properly lubricated and no grease fittings are missing or damaged.
- ☐ Hydraulic system reservoir, engine crankcase and drive motors are filled to their proper levels.
- ☐ All adjustments are made to comply with settings provided in *Chapter 4 – Maintenance* of this manual.
- ☐ All guards, shields and decals are in place and secured.
- ☐ Model and serial numbers for the machine are recorded in the space provided on this page and on page 1-1

IMPORTANT

Start the engine and test run the unit while checking that all controls operate properly.

✓ CHECK THAT:

- ☐ Drive controls and boom/arm/bucket/dozer blade/swing/pivot controls operate properly and are not damaged or binding.
- ☐ Drive controls are properly adjusted for correct neutral position.
- ☐ The parking and travelling gear brake, along with the lock-out devices, are activated with the machine stationary (no pilot control pressure).
- ☐ All hydraulic functions are NOT operational with the left control console in the raised lock-out position.
- ☐ All instrument panel gauges, indicator lights, etc. function properly and all installed lights, such as work lights, function properly.

I acknowledge the pre-delivery procedures were performed on this unit as outlined on this page.

Dealership's Name

Dealer Representative's Name

Date Checklist Filled Out

Model & Serial Number

Delivery Checklist

The following checklist is an important reminder of valuable information that **MUST** be passed on to the customer at the time of delivery. Check off each item as you explain it to the customer.

✓ EXPLAIN:

- ☐ The *Safety* and *Operation* chapters of this manual, regarding the safe operation of the machine.
- ☐ The *Maintenance* and *Troubleshooting* chapters for information regarding the proper maintenance of the machine. Explain that regular lubrication and maintenance is required for continued safe operation and long machine life.
- ☐ Give this Operator's Manual and the AEM Compact Excavator Safety Manual to the customer and instruct the customer to read and completely understand the contents before operating the machine.
- ☐ Complete the Owner's Registration, including customer's signature and return it to Manitou Americas, Inc.
- ☐ Explain that a copy of the product warranty is included on the inside front cover of this Operator's Manual.

Customer's Signature

Date Delivered


RETAIN FOR CUSTOMER'S RECORDS

Remove dealer's file copy at perforation.

INTENTIONALLY BLANK

CHAPTER 2 – SAFETY

GENERAL SAFETY INFORMATION

Manitou Americas, Inc, in cooperation with the Society of Automotive Engineers (SAE), has adopted this safety alert symbol:  This warning symbol, used with a “signal word,” indicates situations or conditions that can cause injury or death if precautions are not followed. The signal words used with the safety alert symbol are:

“CAUTION,” “WARNING,” and “DANGER,” which indicate the level of risk and severity of hazards. All three levels indicate that safety is involved. Observe the precautions whenever you see the safety alert symbol, no matter which signal word is used.

The following signal words are used throughout this manual and on decals on the machine to warn of potential hazards:



DANGER

“DANGER” indicates an imminently hazardous situation, which, if not avoided, will result in death or serious injury.



WARNING

“WARNING” indicates a potentially hazardous situation, which, if not avoided, could result in death or serious injury.



CAUTION

“CAUTION” indicates a potentially hazardous situation, which, if not avoided, may result in minor or moderate injury. May also alert against unsafe practices.

IMPORTANT

“IMPORTANT” is used to draw attention to a procedure that must be followed to prevent machine damage.

Before operating the machine, first read and study the safety information in this manual. Be sure that anyone who operates or works on the machine is familiar with the safety precautions. This includes providing translations of the warnings and instructions for operators who are not fluent in reading English.

It is essential that operators be thoroughly trained in the safe operation of the machine and handling loads. Operators must not be physically or mentally impaired. Do not allow minors or unqualified personnel to operate the machine, or to be near the machine unless they are properly supervised. It is recommended that the operator be capable of obtaining a valid motor vehicle operator’s license.

Only trained and authorized personnel, with a full awareness of safe procedures, should be allowed to operate or perform maintenance or service on the excavator.

Read the operator’s manual provided with each attachment before using it.

Use of the machine is subject to certain hazards that cannot be eliminated by mechanical means, but only by exercising intelligence, care and common sense. Such hazards include: hillside operation, overloading, load instability, poor maintenance, and using the machine for a purpose for which it was not intended or designed.

Manitou Americas, Inc. always takes operator’s safety into consideration during the design process. Guards and shields are provided, which protect the operator and bystanders from moving parts and other hazards. Operators must be alert, however, because some areas cannot be guarded or shielded without preventing or interfering with proper operation.

Different applications may require optional safety equipment. Users must evaluate the worksite hazards and equip the machine and the operator as necessary. The information in this manual does not replace any applicable safety rules and laws. Before operating the machine, learn the rules and laws for the local area. Make sure the machine is equipped as required according to these rules/laws.

Remember that some risks to your health may not be immediately apparent. Exhaust gases and noise pollution may not be visible, but these hazards can cause permanent injuries.

Some photographs in this manual may show doors, guards and shields open or removed for the purposes of illustration only. Be sure all doors, guards, shields and panels are in the proper operating positions before starting the engine to operate the machine.

Do not modify the Falling Object Protective Structure (“FOPS”) unless instructed to do so in approved installation instructions. Modifications, such as welding, drilling or cutting, can weaken the structure and reduce the protection it provides. A damaged protective structure cannot be repaired – it must be replaced.

For safety reasons, use only genuine replacement service parts. For example, using incorrect fasteners could lead to a condition in which the safety of critical assemblies is dangerously compromised.

The machine is designed and intended to be used only with approved attachments. To avoid possible personal injury, equipment damage or performance problems, use only attachments that are approved for use on and within the rated operating capacity of the machine. Contact your dealer or the Manitou Americas, Inc. service department for information about attachment approval and compatibility with specific machine models. Manitou Americas, Inc. cannot be responsible if the machine is used with non-approved attachments.

Do not use the machine for any application or purpose other than described in this manual.

Unauthorized Modifications

Any machine modification made without authorization from Manitou Americas, Inc. could create a safety hazard, for which the machine owner would be responsible.

For safety reasons, use only genuine replacement service parts. For example, using incorrect fasteners could lead to a condition in which the safety of critical assemblies is dangerously compromised.

Attachment Precautions

Optional kits are available through your dealer. Contact your dealer or the Manitou Americas, Inc. service department for information on available one-way (single-acting) and two-way (double-acting) piping/valving/auxiliary control kits. Because Manitou Americas, Inc. cannot anticipate, identify and test all of the attachments that owners may want to install on their machines, please contact Manitou Americas, Inc. for information on approval of attachments, and their compatibility with optional kits.

MANDATORY SAFETY SHUTDOWN PROCEDURE

Before leaving the machine:

1. Bring the machine to a complete stop on a level surface. Avoid parking on an incline or a hillside, but if this is not possible, park across the slope; place chocks under the tracks to prevent the machine from moving.
2. Lower the working equipment to the ground and support it securely.
3. Run the engine at idle speed for a few minutes to allow systems to cool after operation at full speed.
4. Turn the key fully counter-clockwise to shut off the engine. Wait for all movement to stop.
5. Move the joysticks in all directions to verify the hydraulic system is de-pressurized.
6. Lock out controls by raising left control console.
7. Remove the ignition key and take it with you. Exit the machine using the hand-holds.

OPERATIONAL SAFETY

Before Operation

Contact the proper local authorities for utility line locations BEFORE starting to dig. In North America, contact the North American One-Call Referral System at 8-1-1 in the U.S., or 1-888-258-0808 in the U.S. and Canada.

Remove all trash and debris from the machine every day, especially in the engine compartment, to minimize the risk of fire.

The operator's area, steps and hand holds must be kept free of oil, dirt, ice and unsecured objects.

Never use ether starting aids. Glow plugs are used for cold weather starting. Glow plugs can cause ether or other starting fluid to detonate, causing injury or damage.

Walk around the machine and inspect it before using it. Look for damage, loose or missing parts, leaks, etc. Repair as required before using the machine.

Check the tracks for damage at regular intervals. Repair or replace as necessary.

Warn all nearby personnel before starting the machine.

Below-ground hazards also include water mains, tunnels and buried foundations. Know what is underneath the work site before starting to dig.

Before working near power lines (either above-ground or buried cable-type), always contact the power utility and establish a safety plan with them.

Be aware of height obstacles. Any object in the vicinity of the boom could represent a potential hazard, or cause the operator to react suddenly and cause an accident. Use a spotter or signal person when working near bridges, phone lines, work site scaffolds, or other obstructions.

Depending upon the voltage in the line and atmospheric conditions, strong current shocks can occur if the boom or bucket is closer than 10 ft. (3 m) to the power line. Very high voltage and rainy weather can further increase the safe operating distance.

If a lighting system is installed, check its operation before working in darkness.

Use warning tag/control lockout procedures during service. Alert others that service or maintenance is being performed by tagging the operator's controls — and other machine areas if required — with a warning notice. **NEVER** start the engine if there is any indication that maintenance or service work is in progress, or if a warning tag is attached to controls in the cab.

Replace damaged safety decals and a lost or damaged operator's manual. Always store this operator's manual in the storage compartment provided for it inside the cab.

Work crew members should observe and monitor all terrain and soil conditions at the work site, along with traffic, weather-related hazards and any above- or below-ground obstacles and hazards.

If the machine is equipped with a cab, keep the windshield, mirrors and windows clean. If equipped, adjust the rearview mirrors to provide the best view to the rear of the machine. Poor visibility can cause accidents.

Adjust the seat to allow complete and comfortable access to the controls. Never adjust the seat during machine operation.

Stop the engine and lock out the controls by raising left control console before mounting attachments. Check that attachments are securely fastened to the excavator before using them.

Before working on or with the machine, remove jewelry, tie back long hair, and do not wear loose fitting garments, such as, scarves, ties, unzipped jackets, etc., which could become caught in the moving parts of the machine and cause injury.

Do not use the machine when maintenance is scheduled to be performed. Postponing maintenance can result in a serious reduction of the service life of the machine, more serious and costly equipment failures, and contribute to unsafe operating conditions.

During Operation

ALWAYS fasten the seat belt securely and properly. Never operate the machine without the seat belt fastened around the operator.

Operate **ONLY** while seated in the operator's seat. Never reach in through a window to work a control. Do not try to operate the excavator unless you're in the operator's position, seated at the controls. Stay alert and focused on your work at all times.

Always keep hands and feet inside the operator's compartment while operating the machine.

Control the machine cautiously and gradually until fully familiar with all the controls and handling. Avoid high-voltage lines. Serious injury or death can result from contact or proximity to high-voltage electric lines. The bucket or boom does not have to make physical contact with power lines for current to be transmitted.

Use care on loose ground. Working heavy loads over loose, soft ground or uneven, broken terrain can cause dangerous side-load conditions and possible tip over and injury. Traveling with a suspended load or an unbalanced load can also be hazardous.

Stay away from ditches and other weak support surfaces. Be sure the surrounding ground has adequate strength to support the weight of the machine and the load.

If temperatures are changing, be cautious of dark and wet patches when working or traveling over frozen ground.

Stay away from ditches, overhangs and other weak support surfaces. Halt work and install support mats or blocking if work is required in an area of poor track support.

Overhangs are hazardous. Digging under an overhang is dangerous. Know the height and reach limits of the excavator and plan ahead while working. Avoid creating dangerous situations caused by moving around the work site while making excavations. Move to another digging area before large overhangs are formed. Working around deep pits or along high-walls or trenches may require support blocks, especially after heavy rain-falls or during spring thaws. Park the excavator away from overhangs.

Exposed hydraulic hoses could react with explosive force if struck by falling or overhead items. NEVER allow hoses to be hit, bent or interfered with during operation. Extra guards may be required. Replace any damaged hoses.

To avoid tipping, travel with the bucket or attachment as low as possible: 8–12 inches (200–300 mm) from the ground. In an emergency, lower the attachment immediately to the ground to aid stopping the machine.

Sloping terrain requires caution. Dig evenly around the work site whenever possible, trying to gradually level any existing slope. If it is not possible to level the area or avoid working on a slope, reduce the size and cycling rate of the load.

On sloping surfaces, use caution when positioning the excavator prior to starting a work cycle. Stay alert for instability situations. For example, always avoid working the bucket over the downhill crawler tracks when parked perpendicular to the slope. Slow all downhill swing movements and avoid full extensions of the bucket in a downhill direction. Lifting the bucket too high, too close to the machine, while the excavator is turned uphill can also be hazardous.

If the machine becomes unstable and starts to tip, keep the seat belt fastened, hold on firmly and brace yourself. Lean away from the point of impact and stay with the machine. If tipping occurs, DO NOT jump from the machine. The machine is equipped with rollover protection, which can only protect the operator while in the operator's seat. Trying to escape from a tipping machine can result in death or serious personal injury.

Stay alert for people moving through the work area. When loading a truck you should always know where the driver is.

Avoid loading over the cab of a truck, even if the driver is in a safe spot, because someone else could have gone inside.

Slow down the work cycle and use slower travel speeds in congested or populated areas. Use commonly understood signals so that other members of the work crew can warn the operator to slow or halt work in a potentially hazardous situation.

Use a signal person if you can't see the entire work area clearly.

Use a spotter and hand signals to keep away from power lines not clearly visible to the operator.

All personnel at the work site should be aware of assigned individual responsibilities. Communication and hand signals used should be understood by everyone.

Terrain and soil conditions at the job site, approaching traffic, weather-related hazards and any above-or below-ground obstacles or hazards should be observed and monitored by all work crew members.

Be aware that attachments affect the handling and balance of the machine. Adjust the operation of the machine as necessary when using attachments.

Before coupling or uncoupling the hydraulic lines for the attachment, stop the engine and release the pressure in the hydraulic system by moving the joysticks in all directions a couple of times.

DO NOT raise or lower a loaded bucket suddenly. Abrupt movements under load can cause serious instability.

Make sure that no one comes inside the swing radius of the machine. Anyone standing near the track frames, swing frame or the attachment is at risk of being caught between moving parts of the machine.

Do not use the machine to lift or transport people. Never carry riders. Do not allow others to ride on the machine or attachments, because they could fall or cause an accident.

Unless necessary for servicing the engine, the engine hood must not be opened while the engine is running.

Engine exhaust gases can cause unconsciousness and fatalities. Ensure adequate ventilation before starting the engine in an enclosed area.

Operators should also be aware of any open windows, doors or ductwork into which exhaust gases may be carried, exposing others to danger.

Do not overload the machine. See “Load Diagrams”, starting on page 1-13, for load limits.

If the machine becomes damaged or malfunctions, stop the machine immediately and lock and tag it. Repair the damage or malfunction before using the machine.

Never jump off the machine. Always leave the machine using the steps and hand-holds. Never get on or off a moving machine.

Exposure to Crystalline Silica

Exposure to crystalline silica (found in sand, soil and rocks) has been associated with silicosis, a debilitating and often fatal lung disease. A Hazard Review (Pub. No. 2002-129) by the U.S. National Institute for Occupational Safety and Health (NIOSH) indicates that a significant risk (at least 1 in 100) of chronic silicosis for workers exposed to inhaled crystalline silica over a working lifetime. NIOSH recommends an exposure limit of 0.05 mg/m³ as a time-weighted average for up to a 10-hr workday during a 40-hr workweek. NIOSH also recommends substituting less hazardous materials when feasible, using respiratory protection, and regular medical examinations for exposed workers.

Parking the Machine

When shutting down the machine for the day, plan ahead so that the excavator will be on a firm, level surface away from traffic and away from high-walls, cliff edges and any area of potential water accumulation or runoff. If parking on an incline is unavoidable, block the crawler tracks to prevent movement. Lower the bucket and dozer blade to the ground. There should be no possibility of unintended or accidental machine movement.

After the machine has been parked properly, shut down the machine according to the “Mandatory Safety Shut-down Procedure” on page 2-2.

Travel Controls May Produce Reversed Travel Operations

Before starting the machine, always check to see which end of the track frame is under the operator’s cab. In the normal travel configuration, travel motors are at the rear of the machine, under the engine, and with the dozer blade to the front.

If the operator rotates the swing frame 180°, travel motors will be underneath the operator’s cab, and operating travel will be reversed.

Use caution in reverse travel and swing frame rotation.

Use a signal person in high traffic areas and whenever the operator’s view is not clear, such as when traveling in reverse.

Additional Travel Precautions

Swing frame control levers should not be operated while traveling.

Do not change selected travel mode (FAST/SLOW) while traveling.

Fold in work equipment so that the outer end of the boom is as close to the machine as possible, and is as low as possible (8”–12” [200 mm–300 mm]) to the ground.

Never travel over obstacles or slopes that will cause the machine to tilt severely. Travel around any slope or obstacle that would cause a tilt greater than 10°.

Snow, Ice and Cold Temperature Operation Precautions

In cold weather, avoid sudden travel movements and stay away from even very slight slopes. The machine can slide sideways on icy slopes.

Snow accumulation can hide potential hazards. Use care while operating and while using the machine to clear snow.

FIRE HAZARDS

The machine has several components that operate at high temperature under normal operation conditions, primarily the engine and exhaust systems. Also, the electrical system, if not properly maintained or if damaged, can arc or produce sparks. These conditions make it extremely important to avoid circumstances where explosive dust or gases can be ignited by arcs, sparks or heat.

The machine must be cleaned on a regular basis to avoid the buildup of flammable debris such as leaves, straw, etc. Accumulated debris, particularly in the engine compartment, poses a fire hazard.

Add fuel, oil, antifreeze and hydraulic fluid to the machine only in a well ventilated area. The machine must be parked with controls, lights and switches turned off. The engine must be turned off before refueling or service checks are performed.

Static electricity can produce dangerous sparks at the fuel-filling nozzle. In very cold, dry weather or other conditions that could produce static discharge, keep the tip of the fuel nozzle in constant contact with the filler neck of the fuel tank, to provide a ground. Make sure that the static line is connected from the excavator to the service truck before fueling begins.

Keep fuel and other fluid reservoir caps tight and do not start the engine until caps have been secured.

Do not smoke while filling the fuel tank, while working on the fuel or hydraulic systems, or while working around the battery.

Take care to avoid spilling combustible fluids, such as oil or fuel, on a hot engine.

Fire Extinguisher Recommendation

It is recommended that a 5 lb. (2.27 kg) or larger, multi-purpose “A/B/C” fire extinguisher be mounted in the cab. Check the fire extinguisher periodically and be sure that work crew members are trained in its use.

After the machine has been parked properly, shut down the engine and cycle all controls to release any remaining hydraulic system pressure. Be sure all switches and operating controls are in the OFF position and the left-hand console is raised, locking out the hydraulic functions.

ADDITIONAL SAFETY EQUIPMENT

Severe operation may require use of additional safety equipment

Work in mines, tunnels, deep pits or on loose or wet surfaces could produce the hazard of falling rock, roll over or falling objects.

Any operator protective system installed on the machine must comply with applicable safety standards and carry appropriate labeling and rating information. For example, the cab of an excavator used in applications with falling object hazards must meet Society of Automotive Engineers Standard SAE J1356, “Performance Criteria for Falling Object Guards for Excavators.”

Never attempt to alter or modify the protective structure, by drilling holes, welding or re-locating fasteners. Any serious impact or damage to the system requires a complete integrity re-evaluation, and the replacement of the system may be necessary.

Install additional safety equipment if conditions require.

When working with a hydraulic breaker, a front guard over the windshield may be required.

Laminated glass or polycarbonate protection for the front, side or rear windows may also be recommended depending upon particular work conditions.

Contact your dealer for available safety guards and/or recommendations if there is any risk of being hit by objects that could strike the operator’s cab.

Eye Protection and Safety Clothing

Wear full eye protection, ear and head protection, safety shoes, gloves and any other protective clothing or equipment as needed while operating the machine.

Safety Equipment Maintenance

Machinery guards and body panel covers must be in place at all times. Keep clear of rotating parts, such as cooling fan and alternator belts, which could catch hair, jewelry or loose clothing.

All safety equipment must be maintained so it is always in good condition.

Safety-critical parts must be periodically replaced. Replace the following potentially fire-sensitive components as soon as they begin to show signs of deterioration:

- Fuel system flexible hoses, fuel tank overflow drain hose and the fuel filler cap.
- Hydraulic system hoses, especially the pump outlet lines.

Keep mounting brackets and hose and cable routing straps tight. Hose routing should have gradual bends.

Breathing Masks and Ear Protection

Remember that some risks to your health may not be immediately apparent. Exhaust gases and noise pollution may not be visible, but these hazards can cause permanent injuries.

MAINTENANCE SAFETY

Only trained and authorized personnel, with a full awareness of safe procedures, should be allowed to operate or perform maintenance or service on the machine.

Use solid support blocking. Never rely on jacks or other inadequate supports when maintenance work is being done. Block tracks front and back to prevent any movement.

Keep fuel and other fluid reservoir caps tight. Do not start the engine until caps have been secured.

Never attempt to bypass the keyswitch to start the engine. Use only the proper jump-starting procedure according to See “Using a Booster Battery (Jump-Starting)” on page 4-18.

Never use hands to search for hydraulic fluid leaks. Instead, use a piece of paper or cardboard. Escaping fluid under pressure can be invisible and can penetrate the skin and cause serious injury. If any fluid is injected into your skin, see a doctor at once. Injected fluid must be surgically removed by a doctor or gangrene may result.

Always wear safety glasses with side shields when striking metal against metal. In addition, it is recommended that a softer (chip-resistant) material be used to cushion the blow, otherwise, serious injury to the eyes or other parts of the body could result.

Use care when seating retainer pins — retainer pins can fly out or splinter when struck and could cause injury.

Do not smoke or have any spark- or flame-producing equipment or materials in the area while filling the fuel tank or working on the fuel or hydraulic systems.

Do not attempt to loosen or disconnect any hydraulic lines, hoses, fittings, covers or caps without first relieving hydraulic circuit pressure. Relieve hydraulic pressure by performing the “Mandatory Safety Shutdown Procedure” on page 2-2. Be careful not to touch any hydraulic components that have been in recent operation, because they can be hot and cause burns.

Refer to the parts manual for information about assembly of components. Always use the correct parts and the proper torques — incorrect fastener connections can dangerously weaken assemblies.

Do not run the engine if repairs are being performed alone. There should always be at least two people working together if the engine must be run during service. Both persons must maintain visual contact with each other. Keep a safe distance away from all rotating and moving parts.

Always use the proper tools while working on the machine. Inappropriate tools could break or slip, causing injury, or they may not adequately perform intended functions.

Unless necessary for servicing the machine, do not open the engine cover while the engine is running.

Keep mounting brackets and hose and cable routing straps tight. Hose routing should have gradual bends.

After cleaning the machine, examine all fuel, lubricant and hydraulic oil lines for leaks, chafe marks and damage. Tighten any loose connections and repair or replace parts as necessary.

Use warning tag/control lockout procedures during service.

Alert others that service or maintenance is being performed and tag operator’s cab controls — and other machine areas if required — with a warning notice.

Don’t run the engine if repairs or work is being performed alone.

Do not run the engine if repairs or work is performed alone. There should always be at least two people working together if the engine must be run during service.

Always use adequate equipment supports and blocking.

Lower bucket to the ground before leaving the operator's seat. Don't work under any equipment supported solely by a lift jack.

Track tension adjustments require caution.

NEVER fully remove the track tension grease fitting. To release pressure from the crawler frame track tension assembly, you should loosen the grease fitting slightly, no more than two turns.

Keep your face and body away from the fitting. Refer to "Checking and Adjusting Track Tension" on page 4-23.

Don't work on hot engines, cooling or hydraulic systems.

Wait for the engine to cool after normal operation. Park the excavator on a firm, level surface and lower all equipment before shutting down and switching off controls. When engine lube oil, gearbox lubricant or other fluids require changing, wait for fluid temperatures to decrease to a moderate level before removing drain plugs.

Temperatures below 120°F (49°C) will reduce the chances of scalding exposed skin while allowing the fluid to drain quickly and completely. However, do not let the fluid to fully cool, because drain time will be substantially increased.

Cool-down is required prior to radiator or hydraulic reservoir checks.

Stop the engine and allow it to cool before performing service on the engine radiator or hydraulic reservoir. Both assemblies have pressure vents at the filler cap for venting pressure. **LOOSEN CAPS SLOWLY.** Vent the pressure before removing the filler caps.

Release hydraulic system pressure by cycling controls and releasing hydraulic reservoir pressure before removing hydraulic reservoir access cover.

The hydraulic reservoir is pressurized. Vent the system pressure by rotating the filler cap. **LOOSEN CAP SLOWLY** prior to removal.

Make sure to release any hydraulic pressure stored in the lines by cycling the operator's controls in each direction after the engine has been shut down.

Pressurized hydraulic oil leaks can be hazardous.

Fluid leaks from hydraulic hoses and pressurized components can be difficult to see, but pressurized oil can have enough force to pierce the skin and cause serious injury.

Always use a piece of wood or cardboard to check for suspected hydraulic leaks. Never use your hands. Obtain immediate medical attention if pressurized oil pierces the skin. Failure to obtain prompt medical assistance could result in gangrene or other serious damage to tissue.

Use correct replacement fasteners tightened to proper torque.

Refer to the Parts Manual for information on torques and assembly of components.

<h2>IMPORTANT</h2>
<p>Always use the correct, original-equipment parts. Incorrect fastener connections can dangerously weaken assemblies.</p>

Dispose of all petroleum-based oils and fluids properly.

Dispose of all petroleum-based oils and fluids properly. Used motor oil may pose a health risk. Wipe oil from your hands promptly and wash off any residue. Used motor oil is an environmental contaminant and may only be disposed of at approved collection facilities. Never drain any petroleum-based product on the ground or dispose of used oil in municipal waste collection containers, or in metropolitan sewer systems or landfills. Check state and local regulations for other requirements.

When handling oil, grease and other chemical substances, follow the product-related safety requirements (Material Safety Data Sheet (MSDS) carefully to prevent burning or scalding yourself or other persons.

Safety Decals

Safety decals must be replaced if they become unreadable. Safety decal mounting locations are shown starting on page 2-18.

Hydraulic Cylinder Seal Periodic Replacement

Check cylinder drift rate at regular intervals. Maximum allowable rates are included at the end of the Hydraulic section in the Excavator Service Manual. Overhaul seal kits are available through Manitou Americas, Inc.

High Pressure Hydraulic Lines Store Energy

Exposed hydraulic hoses on the arm or boom could react with explosive force if struck by a falling rock, overhead obstacle or other job site hazard. Extra safety guards may be required. NEVER allow hoses to be hit, bent or interfered with during operation.

Operator's Cab and Swing Frame Deck Maintenance

Cleaning off accumulations of grease and dirt helps extend equipment service life. Cleaning also provides an opportunity to inspect equipment. Minor damage can be repaired or corrected before major problems result.

Battery Electrolyte and Explosive Gas Hazard

Flush eyes with water for 10-15 minutes if battery acid is splashed in the face. Anyone who swallows acid must have immediate medical aid. Call the Poison Control center listing in the telephone directory.

Sparks can set off explosive battery gas from incidental contact or static discharge. Turn off all switches and the engine when working on batteries. Keep battery terminals tight. Contact between a loose terminal and post can create an explosive spark.

Battery Disconnection Precaution

Remove cable to negative terminal first when disconnecting a battery. Connect positive terminal cable first when installing a battery.

Jump-starting or Charging the Battery

Turn off all electrical equipment before connecting leads to the battery, including electrical switches on the battery charger or jump-starting equipment.

When jump-starting from another machine or vehicle, do not allow the machines to touch. Wear safety glasses or goggles while battery connections are made.

Batteries contain acid and produce explosive gases. Keep sparks, flames and lit cigarettes away from batteries at all times.


Connect positive cable first when installing jumper cables. The final cable connection, at the metal frame of the machine being charged or jump-started, should be as far away from the batteries as possible.

Disconnect the negative cable first when removing the jumper cables. For specific jump-starting instructions refer to Page 4-18 in the Maintenance chapter of this manual.

LIFTING THE MACHINE WITH A CRANE

Only lift the machine according to the following guidelines:

- The crane and rigging equipment must have sufficient capacity. See "Lifting the Machine" on page 3-30.
- Lift the machine according to "Lifting the Machine" on page 3-30.
- Secure the machine against unintentional movement. Use taglines as needed.
- Do not lift the machine with persons on or in the machine.
- Any person guiding the crane operator must be within sight or sound of the crane operator.
- Lift the machine only with the standard bucket installed, the bucket empty and in the transport position.
- Persons must stay clear of and not under the machine when it is lifted.
- Fasten the rigging equipment so the machine is horizontal when it is lifted.
- Do not lift the machine by the eye hooks on the cab. Attach the rigging equipment only at the lift points identified by this symbol:



TRANSPORTING

Obey state and local over-the-road regulations. Check state and local restrictions regarding weight, width and length of a load. The hauling vehicle, trailer and load must all be in compliance with local regulations. Refer to the Transporting section of this manual.

SAFETY DECALS

The machine has decals shown on the following pages that provide safety information and precautions. These decals must be kept legible. If missing or illegible, they must be replaced promptly. Replacements can be obtained from your dealer.


Refer to the Parts Manual for decal part numbers and ordering information.

New Decal Application


Surfaces must be free of dirt, dust, grease and foreign material before applying the decal. Remove the smaller portion of the decal backing paper and apply the exposed adhesive to the clean surface, maintaining proper position and alignment. Peel the rest of the backing paper and apply hand pressure to smooth out the decal surface. Refer to the following pages for proper decal locations.

If replacing a part that has a decal on it, ensure that the replacement part has the same decal.

ISO-Style Safety Decal Locations (Later Machines)




1



WARNING! Danger Zone Decal
AVOID INJURY OR DEATH!

Located on both sides of the boom.
Keep bystanders away from the machine when it is in use.

3



WARNING! Stay Clear Decal
AVOID INJURY OR DEATH!


Located next to the track tension grease fitting on both sides of the machine.

WARNING! Grease is under high pressure. Keep your face and body away from the fitting.

Do not loosen the fitting more than two turns. Do not loosen parts other than the fitting.

Refer to the operator's manual for track adjustment procedure.

2



WARNING! Hydraulic Reservoir Under Pressure
AVOID INJURY OR DEATH!

Located on the hydraulic system accumulator bulb inside the engine compartment.

Relieve hydraulic pressure before servicing machine. Removed hydraulic reservoir cap slowly.

Refer to the maintenance section in the operator's manual before servicing the machine.

4



WARNING! Hot Surfaces Decal
AVOID SERIOUS INJURY!

Located inside the engine compartment.

Stop the engine and wait for all parts to cool before opening the engine compartment. Hot surfaces can cause severe burns.

Read the operator's manual before performing any maintenance on the machine.

5



WARNING! Rotating and Hot Components Decal

AVOID SERIOUS INJURY!

Located on the fan shroud inside the engine compartment.

Stop the engine and wait for all parts to cool before opening the engine compartment. Rotating parts can cause severe injury. Hot surfaces and liquids can cause severe burns.

Read the operator's manual before performing any maintenance on the machine.

8




WARNING! Read Operator's Manual

AVOID INJURY OR DEATH!

Located on the door pillar inside the cab.

Read the operator's manual before operating or performing any maintenance on the machine.

6



WARNING! Rotating Components! Danger of Entanglement! Decal

AVOID SERIOUS INJURY!

Located below the engine cover latch.

Stop the engine before opening the engine compartment. Rotating parts can cause severe injury.

9



WARNING! Decal

AVOID INJURY OR DEATH!

Located on the door pillar inside the cab.

No riders! Never use work tool as work platform.

Operate only from operator's seat.

ALWAYS wear seatbelt.

WARNING: Avoid Overturn

Side stability is reduced when: 1) turning; 2) operating on rough terrain or side slopes; and 3) carrying load raised.


Carry load low. Do not exceed Rated Operating Capacity.

Avoid steep slopes and high speed turns.

Travel up and down slopes with heavy end uphill.

Read the operator's manual before operating the machine.

7



WARNING! Crushing Hazard Decal

AVOID SERIOUS INJURY!

Located on the inside of the front window on cab-equipped machines.

Only open and close the front window using the handles.

Always lock the front window using both locks.

10



WARNING! Hot Components Decal


AVOID SERIOUS INJURY!

Located next to the hydraulic system filler cap.

Stop the engine and wait for all parts to stop and cool before. Hot surfaces and liquids can cause severe burns.

Read the operator's manual before performing any maintenance on the machine.

11



WARNING! Danger Zone Decal

AVOID INJURY OR DEATH!

Located on the back of the swing frame.

Keep bystanders away from the machine when it is in use.

14




WARNING! Danger Zone Decal

AVOID INJURY OR DEATH!

Located on both sides of the superstructure.

NEVER loosen capscrew(s) before counterweight is secure. Read the operator's manual before operating or performing any maintenance on the machine.

12



WARNING! Danger Zone Decal

AVOID INJURY OR DEATH!

Located on both sides of the boom swivel bracket.

Swiveling boom can cause crushing. Keep bystanders away from the machine when it is in use.

13


WARNING! Mandatory Safety Shutdown Decal

AVOID INJURY OR DEATH!


Located on the door pillar inside the cab.

Before leaving the machine, or performing any service on the machine, perform the "Mandatory Safety Shutdown Procedure" on page 2-2.

1. Lower the working equipment to the ground and support it securely.
2. Run the engine at idle speed for a few minutes to allow systems to cool after operation at full speed.
3. Turn the key fully counter-clockwise to shut off the engine.
4. Lock out controls by raising left control console.
5. Remove the ignition key and take it with you.



ISO-Style Information Decal Locations (All Machines)



1

Track Front Decal



Located near the front of the track frame on both sides of the machine

Indicates the front of the track frame.

5

Tie-Down Point Decal



Located on both ends of the dozer blade and near the rear end of the track frame on both sides of the machine.

Only use tie-down points to secure the machine during transport.

2


Lift Point Decal



Located on both sides of the boom on the dipper arm cylinder bracket, and on both ends of the dozer blade.

Apply lift hooks only in these locations.

6



Operator Controls Decal

Located on the ceiling inside the cab.

Provides quick-reference for the SAE operator's control option inside the cab.

Read the operator's manual before operating the machine. Refer to the operator's manual for details about the operator's controls.

3

Hydraulic Fluid Decal



Located next to the hydraulic system filler cap.

USE HYDRAULIC FLUID ONLY!

4


Diesel Fuel Decal



USE DIESEL FUEL ONLY!

Located next to the fuel filler neck.


7



Flow Control Selector Valve Decal

Located inside the control valve compartment.
Indicates restricted-flow and full-flow auxiliary hydraulics selector valve positions.


9



Engine Cover Latch Decal

Located on the right side of the kick plate under the operator's seat.
Pull the handle to open the engine cover latch.

8



Hydraulic Valve Cover Latch Decal


Located on the right side of the kick plate under the operator's seat.
Pull the handle to open the hydraulic valve cover latch.

ANSI-Style Safety Decal Locations (Early Machines)


Swing Radius Warning Decal (both sides of boom)




Read Operator's Manual Decal inside right of cab/canopy wall



Hydraulic Pressure Warning Decal (next to hydraulic tank filler)




Operation/Warning Decal (cab/canopy ceiling)



Operation/Warning Decal (cab/canopy ceiling)



Track Tensioner Warning Decal (track frame — both sides)




Pinch Point Warning Decal (above inside windshield [cab unit only])



Crush Hazard Warning Decals (both sides of the swivel frame)



Crush Hazard Warning Decals (both sides of the swivel frame)



WARNING

ROTATING FAN

Keep hands out or stop engine.



CHAPTER 3 – OPERATION

OPERATING CONTROLS

WARNING

- Read and understand this entire manual. Follow warnings and instructions for operation and maintenance. Failure to follow instructions can result in injury or death.
- Read and understand all safety decals before operating the machine. **DO NOT** operate the machine unless all factory-installed guards and shields are in place.
- Be sure you are familiar with all safety devices and controls before operating the machine.
- Know how to stop the machine before starting.
- Use only with approved accessories or referral attachments. The manufacturer cannot be responsible for safety if the unit is used with non-approved attachments.
- Check for correct function after adjustments or maintenance.

Machine Orientation

All references to “right” and “left” are determined from the operator's position facing forward.

Guards and Shields


Whenever possible, guards and shields are used to protect potentially hazardous areas on the machine. In many places, decals are also provided to warn of potential hazards and/or to display special operating procedures (see Chapter 2 – *Safety*).

The left operator's console should be raised to enter and exit the cab. In the raised position, the left console locks out all hydraulic functions of the machine. See Figure 3-1.




Figure 3-1 Operator's Compartment with Left Console in Lock-out Position

Figure 3-2 Equipment and Controls




Item	Description	For more info, see page
1	Joystick (left)	3-8
2	Joystick (right)	3-8
3	Control Lever Base (left)	
4	Control Lever Base (right)	
5	Armrest (left)	
6	Armrest (right)	
7	Seat Horizontal Adjustment Lever	3-12
8	Air Vent (cab only)	
9	Seat Backrest Adjustment Knob	
10	Seat Belt Latch	
11	Cup Holder	
12	Switch Panel (right)	3-4
13	Switch Panel (left)	3-4
14	Throttle Lever	
15	Dozer Blade Lever	3-10
16	Auxiliary Hydraulics Pedal	3-23
17	Preheating/Ignition Switch	3-4
18	Cigarette Lighter	
19	Instrument Cluster	3-4
20	Drive Pedal (left)	3-7
21	Drive Pedal (right)	3-7
22	Drive Lever (left)	3-7
23	Drive Lever (right)	3-7
24	SAE/ISO Changeover Valve (underneath floor mat)	3-11
25	Seat Suspension Adjustment Lever	3-12
26	Engine and Valve Cover Latch Release Levers	


Figure 3-3 Instrument Panel, Switches and Indicators



Left-hand side control elements



Right-hand side control elements



Item	Description
27	Fuel level gauge – Gauge shows the amount of fuel in the tank.
28	Engine air cleaner indicator (red) – Lamp comes on when the air cleaner requires servicing.
29	Glow plug indicator (yellow) – Lamp comes on when the ignition key is in the glow plug activation position. Indicator will go out when the glow plugs have heated sufficiently to start the engine.
30	Hydraulic oil filter indicator (red) – Lamp comes on when hydraulic oil return filter requires servicing or while the hydraulic oil is cold.
31	Hydraulic oil temperature indicator (red) – Lamp comes on when hydraulic oil temperature rises above specification.
32	Battery charge fault indicator (red) – Comes on when the ignition is turned on and goes off when the engine starts. If the indicator light comes on while the engine is running, the battery is not charging, indicating a faulty charging circuit in the alternator or problems with the V-belt. NOTE: a faulty V-belt affects cooling pump operation, which can lead to overheating and more serious engine problems. Shut off the engine IMMEDIATELY and determine the cause if this indicator comes on when the engine is running.
33	Engine oil pressure indicator (red) – Comes on when the ignition is turned on and goes off when the engine starts. During normal operation, this indicator should remain off. The indicator will light if the engine oil pressure drops too low. If this occurs, shut off the engine IMMEDIATELY and determine the cause of the pressure drop.
34	Coolant temperature indicator (red) – Lamp comes on when coolant temperature rises above specification.
35	Hourmeter – Indicates the total operating hours of the machine. Use the hourmeter to track maintenance in the maintenance log.
36	Auto2Speed switch (transport speed) – Pressing the switch will enable high travel speed.
37	Ventilation fan (two-speed) – A two-position switch to turn on the ventilation fan. Pressing switch to the first position is the low fan speed position, and the second position is the high fan speed position. If the heater control (cab model only) is in the heating position, this switch will function as the cab heater ON/OFF switch.
38	Boom light (option, cab only) – Press switch ON to turn on the boom work light.
39	Windshield wiper switch (cab models only) – Pressing the two-position switch to the first position turns on the windshield wiper. Pressing and holding the switch indicator in the second position activates the washer fluid pump.
40	Roof lights (option, cab only) – Press switch ON to turn on the cab roof work lights.
41	Rotating beacon (option, cab only) – Press switch ON to turn on the rotating beacon.
42	Auto-idle switch (option) – Enables auto-idle feature (Models 353/373 only)

Ignition Key Switch

Note: *The engine can only be started if the left control lever console is pivoted down into the operation position.*

With the key in the fully counter-clockwise “P” position, all power is shut off. The key can be inserted or removed when the switch is in this position.

With the key in the “0” position, power to the accessory circuit is turned on. The key can be inserted or removed when the switch is in this position.

With the key in the “I” position, power is turned on to all controls and electrical circuits. The battery charge indicator light and the oil pressure indicator light will come on.

With the key in the “II” position, the glow plug indicator will come on while the glow plugs warm intake air in cold weather.

With the key turned fully clockwise “III” and held in position, the engine will crank/start. The indicator lights should go out when the engine starts. Release the key after the engine starts (the key returns to the “I” position when it is released after starting the engine).

The key must always be returned to the “I” position between attempts to start the engine in order to activate the glow plug system.




Figure 3-4 Ignition Key Switch

Engine Speed Control

The engine speed is controlled by the throttle lever (2) located behind the left joystick. See Figure 3-5.

- Push lever forward to decrease engine speed.
- Pull lever rearward to increase engine speed.




Figure 3-5 Throttle Lever

Travel Controls

WARNING

- Levers and controls should return to neutral position when released.
- Be sure the levers and controls are in the neutral (middle) position before starting the engine.
- Operate controls gradually and smoothly. Excessive speed and quick handle movements without regard for conditions and circumstances are hazardous and could cause an accident.

WARNING

Be sure that the dozer blade is “in front.” When the operator’s cab is facing forward, the blade will be visible and travel controls will operate as expected. If the dozer blade is not visible, the operator’s cab is facing to the rear, and the travel controls will operate in reverse.

Forward Travel

Push both travel control levers or pedals forward. The farther these are moved, the faster the machine will travel. See Figure 3-6.

Reverse Travel

Pull both travel control levers or pedals back. The farther these are moved, the faster the machine will travel. See Figure 3-6.

Turning During Travel

Move one control lever or pedal farther than the other one. To turn left while moving forward, move the right control lever farther forward; to turn right while moving forward, move the left control lever farther forward. See Figure 3-6.




Figure 3-6 Travel Controls

Spin Turn

Move the levers in opposite directions to spin the machine on its axis. To spin turn left, move the right control lever forward while pulling the left control lever to the rear; to spin turn right, move the left control lever forward while pulling the right control lever to the rear. See Figure 3-6.




Figure 3-7 Operator's Seat and Joystick Controls

ISO/SAE Selector Valve

Underneath the floor mat is the SAE/ISO-pattern joystick controls. This machine has been set at the factory for SAE-pattern standard operation. If the machine does not function according to the decals and instructions in this manual, move the selector valve to the other position. See Figure 3-8.



Figure 3-8 SAE/ISO Control Selector Valve

SAE-Pattern Operating Controls

SAE-pattern boom and bucket functions are controlled by the right and left joystick control levers located on the seat consoles.

SAE Left Joystick – see Figure 3-9.

- 1 – Arm extend
- 2 – Arm retract
- 3 – Swing left
- 4 – Swing right




Figure 3-9 SAE Left Joystick

ISO-Pattern Operating Controls

ISO-pattern boom and bucket functions are controlled by the right and left joystick control levers located on the seat consoles.

ISO Left Joystick – see Figure 3-11.

- 1 – Boom lower
- 2 – Boom raise
- 3 – Swing left
- 4 – Swing right




Figure 3-11 ISO Left Joystick

SAE Right Joystick – see Figure 3-10.

- 5 – Boom lower
- 6 – Boom raise
- 7 – Curl bucket in
- 8 – Curl bucket out




Figure 3-10 SAE Right Joystick

ISO Right Joystick – see Figure 3-12.

- 5 – Arm extend
- 6 – Arm retract
- 7 – Curl bucket in
- 8 – Curl bucket out




Figure 3-12 ISO Right Joystick

Note: The joystick controls are pilot-operated. The farther the controls are moved from center, the faster the machine will function.

Note: The joystick controls are pilot-operated. The farther the controls are moved from center, the faster the machine will function.

Boom Swivel

To swivel the boom without moving the swing frame, press and hold the swivel activation/changeover valve button (1, Figure 3-13) on top of the left-hand joystick, and press the auxiliary hydraulics pedal (2). Pressing down the toe of the auxiliary hydraulics pedal swivels the boom to the left. Pressing down the heel of the pedal swivels the boom to the right.




Figure 3-13 Boom Swivel

Optional Joystick Buttons

Additional machine functions are controlled by buttons located on top of the joysticks. See Figure 3-14.

- Left Joystick
 - (3) Dozer Blade Activation Button
- Right Joystick
 - (4) Left Top Button – Dozer Blade Activation
 - (5) Right Top Button – Superstructure Tilt (Optional - Model 373 only)
 - (6) Bottom Button – Horn




Figure 3-14 Joystick Controls – Optional Buttons

Dozer Blade Control

WARNING

Dozer blade operation is **NOT** disabled when the left console is in the raised lock-out position and/or when the engine is not running.

ALWAYS perform the Mandatory Safety Shutdown Procedure on page 2-2 and lower the dozer blade to the ground before leaving the operator's seat.




Figure 3-15 Dozer Blade Control Lever (Newer Excavators)

Newer Excavators Dozer Blade Control

Newer excavators have a dozer blade control lever (1) Figure 3-15, directly to the right of the right of the auxiliary hydraulics pedal (2). To use the dozer blade control lever:

- Push the dozer blade lever forward to lower the dozer blade.
- Pull the dozer blade lever back to raise the dozer blade.

Older Excavators Dozer Blade Control

On older excavators, the dozer blade is controlled with a combination of the dozer blade activation button and the right joystick. See Figure 3-16.

Press the dozer blade activation button and:

- Push the right joystick forward to lower the dozer blade.
- Pull the right joystick back to raise the dozer blade.




Figure 3-16 Dozer Blade Controls (Older Excavators)

WARNING

- **Be sure there is proper clearance for the front end attachments when bulldozing.**
- **Be sure that the front end attachments do not contact any overhead power lines or obstructions during bulldozing.**
- **DO NOT drive machine into the excavation or onto loose soil, which will cause an unstable condition, tipping the machine.**

1. Raise or lower the dozer blade by pressing and holding the dozer blade activation button on the right-hand joystick. Move joystick forward to lower the blade, rearward to raise the blade. See Figure 3-16.
2. The boom must be fully raised and the bucket curled in (up) when bulldozing.
3. When bulldozing, the material may be pushed to the front or to the side.
4. Raise the dozer blade slightly if excessive resistance occurs.
5. When the blade is in position, use the travel controls to move the machine as in normal travel.

Superstructure Tilt (Model 373 Only)

The optional superstructure tilt control enables the operator to tilt model 373 15° to the operator's right when the cab is facing dozer blade. Cab tilts 15° to the left when cab faces away from the dozer blade.

To tilt the superstructure, press and hold the swivel frame tilt button on the right hand joystick, and move the joystick to the left or right. See Figure 3-17.




Figure 3-17 Superstructure Tilt (Optional)

Using Flow Control Valve for Attachments and Auxiliary Hydraulics

When using front end attachments, like a breaker, rotate the flow control selector valve to the full flow position – with lever (1, Figure 3-18) in line with the valve and hose. This will enable a higher hydraulic fluid flow to the unit, enabling more efficient operation.




Figure 3-18 Flow Control Valve




Figure 3-19 Flow Control Valve Position Decal

Operator's Seat Adjustments

WARNING

Never adjust the seat when the machine is in operation. Adjust the seat only when the machine is not in motion.

After adjustments, make sure the seat adjustment latches are fully engaged before using the machine.

Note: The operator's left console must be raised to exit the cab. In the lowered ("work") position, all operational functions are activated, and operator exit is blocked by the left console. In the raised position, the left-hand console locks out all hydraulic functions of the machine. See page 3-1.




Figure 3-20 Seat Suspension Adjustment

1. Seat Suspension Adjustment

Rotate knob / lever (1, Figure 3-20) to adjust the seat suspension for the operator's weight. An indicator on the front of the seat base shows the weight adjustment.

2. Seat Adjustment

The seat adjustment lever (2, Figure 3-20) allows the operator to move the seat (without consoles) forward or rearward.




Figure 3-21 Seat Backrest Adjustment

CAUTION

Use care when adjusting the backrest to avoid damaging the rear window. Make sure the backrest does not touch the rear window when adjusting the backrest.

Select a seat position which will not damage the window panels when working with the machine.

3. Seat Backrest Adjustment

Lift lever (3, Figure 3-21) and adjust backrest to the desired position. Release lever 3 and make sure backrest is locked in position.

Seat Belt



WARNING

ALWAYS fasten the seat belt securely and properly. Never operate the machine without the seat belt fastened around the operator.

Keep the seat belt clean because dirt can impair seat belt operation. Check seat belt condition regularly and have damaged or worn belts immediately repaired by an authorized workshop.

After an accident the seat belt strap is stretched and must be replaced with a new strap installed by an authorized workshop.

Make sure the seat belt is not twisted when it is fastened, and that it is fastened over the hips and not the stomach.

Fasten the seat belt tightly and securely. Remove hard, edged or fragile objects from your pockets or clothes that might lie between the seatbelt and your body.

Fastening/Unfastening the Seat Belt

Fasten the seat belt around your hips and waist and insert tab (3, Figure 3-22) into buckle (4) until it clicks securely in place. Slack in the seat belt should automatically retract into seat belt spool (6).

Unfasten the seat belt by pressing button (5).




Figure 3-22 Seat Belt

Ventilation

Windshield

WARNING

When the windshield is opened, be sure both latches are locked. When closing the windshield, keep hands on the handles and away from path of the windshield.

The windshield can be opened for ventilation. Squeeze latches (1, Figure 3-23) located at the upper corners of the windshield, pull/push the top of the windshield backwards/forward and release latches. Pull/push the top of the window until the catch locks the top of the windshield securely in place.

To close the windshield, squeeze/turn the latches and then lower the windshield. Lock the latches in the closed position.

CAUTION

Support the windshield when releasing it from the ceiling catches to avoid possible head injury.




Figure 3-23 – Windshield Locks

Side Window

The right side window can be opened for ventilation. Squeeze the latch located on the window, slide window to desired position and release the latch.

Cab Door Latch

When fully opened, the cab door will lock in position to the side of the cab. To release the lock, use the black knob located on the right side of the door jamb.

Remote Engine and Hydraulic Valve Cover Latches

The engine cover and hydraulic valve cover latches are located below the operator's seat, on the right-hand side. See Figure 3-24.

To unlatch a cover, pull the respective latch handle. The cover can then be opened. Excavators equipped with canopies have a key lock for the latches to prevent unauthorized access.




Figure 3-24 Access Cover Latches

Cab Heater Shut-off Valve

During the warmer months, the engine coolant can be blocked from flowing to the operator's cab. Turn the shut-off valve (1, Figure 3-25) 90° to the closed position. All engine coolant will be directed to the main engine radiator. Open the valve when heat is needed in the cab.




Figure 3-25 Shut-off Valve (newer machines)




Figure 3-26 Shut-off Valve (older machines)

MACHINE OPERATION



WARNING

- Read and understand this entire manual. Follow warnings and instructions for operation and maintenance. Failure to follow instructions can result in injury or death.
- Read and understand all safety decals before operating the machine. **DO NOT** operate the machine unless all factory installed guards and shields are in place.
- Operators must be familiar with all safety devices and controls before operating the machine.
- Know how to stop the machine before starting.
- Use only with Gehl Company approved accessories or referral attachments. The Gehl Company cannot be responsible for safety if the unit is used with non-approved attachments.
- Check for correct function after adjustments or maintenance.

Pre-operation Checklist

IMPORTANT

See the list of recommended lubricants in Maintenance on page 4-1 for proper grade of engine oil and hydraulic oil. Only use oils specified on the list.

Check the following items at the beginning of each work day or after every 12 working hours:

- Seat belt and mounting hardware
- Safety decals and replace as necessary
- Air cleaner and intake hoses
- Engine coolant level and system for leaks
- Clean engine area of any flammable materials
- Engine oil level and fill if low
- Water drained from fuel pre-filter
- Hydraulic system for leaks and hydraulic fluid level
- All pivot points for proper operation
- Track tension
- Windshield washer reservoir level (cab machines)
- Broken and loose parts, and repair
- Left armrest down in operating position
- Attachment safely locked on machine
- Engine cover closed
- Fuel level

IMPORTANT

Do not run the engine until the fuel tank is empty. If this happens, air will enter the fuel system, and the fuel system will have to be bled. Always fill the tank with fresh fuel at the end of the working day.

WARNING

Never use ether starting aids. Glow plugs are used for cold starting. The glow plug can cause ether or other starting fluid to detonate, causing injury.

Engine Start and Stop

Note: *When all machine controls are stationary (no pilot control pressure), the swing motor and travel*

motor brakes are automatically applied. When any control is activated, the appropriate brake is automatically released.

Note: *All hydraulic functions are locked out with the operator's left-hand console in the raised position.*

Engine Start Procedure



DANGER

DO NOT run an engine in an enclosed area. Make sure that there is adequate ventilation if the machine is being used in an enclosed area.

1. Adjust the operator's seat to desired settings.
2. Be sure all levers and controls are in neutral positions.

Insert ignition key into switch and turn right (clockwise) to the first position. All indicators, lights, including indicator lamps for oil pressure and battery voltage will light. In cold weather the glow plug indicator lamps will come on while the glow plugs warm the intake air.

3. Turn the key fully clockwise and hold until the engine starts, and then release the key.

Note: *The key must be returned to the OFF position between attempts to start the engine to activate the glow plug system.*

IMPORTANT

Do not engage the starter motor for longer than 20 seconds at each starting attempt. If the engine does not start, turn the key fully off, wait 30 seconds, and then attempt to start the engine again.

IMPORTANT

Indicator lamps must go out when engine starts. If they do not, turn the engine off IMMEDIATELY. Do not use machine until the problem has been identified and repaired.

-
4. Allow engine to warm up at idle speed for approximately 10 - 15 minutes to fully warm up all systems.

Cold Weather Engine Starting Procedure

Note: *For easier cold weather starting, install an in-block or tank-type engine heater, which will keep engine block and oil warm.*

Note: *Be sure engine oil is correct type and viscosity for the ambient (air) temperature.*

Note: *Be sure battery is fully charged.*

1. Follow all steps in Engine Start Procedure, above.
2. Advance the throttle to 1/4 engine speed for a faster warm up.
3. As the engine warms up, move the throttle lever to the idle position.

Engine Shut Down

IMPORTANT

If the engine is shut down without a cool down period, damage to the engine can occur.

Mandatory Safety Shutdown Procedure

Before leaving the machine:

1. Bring the machine to a complete stop on a level surface. Avoid parking on an incline or a hillside, but if this is not possible, park across the slope.
2. Lower the working equipment to the ground and support it securely.
3. Run the engine at idle speed for a few minutes to allow systems to cool after operation at full speed.
4. Turn the key fully counter-clockwise to shut off the engine. Wait for all movement to stop.
5. Move the joysticks in all directions to verify the hydraulic system is de-pressurized.
6. Lock out controls by raising left control console.
7. Remove the ignition key and take it with you. Exit the machine using the hand-holds.

New Machine Break-in Procedure

A new machine requires reduced operational speed during the first 100 operating hours to properly break in various parts. If the machine is subjected to hard use during the break-in period, damage to operating systems may occur.

Perform the following when operating a new machine:

- Perform all steps in Pre-operation Checklist on page 3-16.
- Start engine and let it idle for 10 - 15 minutes so all components and systems can warm up.
- Operate the machine at about 80% of maximum loads and speed.
- At the end of the first 100 operational hours, drain and replace the engine oil and engine oil filter.

Travel



WARNING

- **Before operating the travel levers, the operator must know which direction the machine is pointing. If the dozer blade is not visible from the operator's cab, the cab is facing rearward and the travel controls will be the reverse of normal operation.**
- **Before moving, make sure that there are no personnel in the way of the machine. Sound the horn to alert workers that the machine is about to be moved.**
- **Be sure the path is clear during travel.**
- **Use extreme caution when reversing travel. Be sure there is a clear path behind the machine.**
- **Operate the travel control levers smoothly to avoid sudden starts or stops.**

Travel Speed Change

Two travel speeds ranges can be selected by using the Auto2Speed switch located on the control console (page 3-4, item 36) or momentary speed adjustment by pressing the button on the left travel lever. See (1) Figure 3-27.

Slow Speed Maximum = 2 mph (3.2 km/h)

High Speed Maximum = 4 mph (6.4 km/h)

Note: *If the travel speed switch on the console is in the high-speed position, the machine will not turn right or left. It will only move straight forward and rearward.*

CAUTION

The slow-speed setting should be selected to prevent whenever conditions warrant.



Figure 3-27 Travel Levers and Overdrive Button

General Travel Instructions

1. Avoid sudden movements and sharp turns.
2. On rough, frozen or uneven terrain, travel slowly.
3. Travel straight up or down slopes, never travel across the slope. See Figure 3-28. Extend the dipper arm and lower the boom to keep the bucket about 12" (300 mm) off the ground. If the machine starts to slide or becomes unstable, lower the bucket to regain control. If the engine stalls, lower the bucket, make sure all controls are in the neutral position and restart the engine.
4. To travel straight, push both travel control levers (or pedals) fully forward (or rearward). The farther the levers (or pedals) are moved, the faster the travel speed.
5. Pivot (or wide) turns are made by rotating only one track forward (or rearward). The machine will pivot on the non-moving track.
6. Spin turns are made by rotating one track forward and one track backward. The machine will spin around its center.
7. The excavator can travel in water that comes up to the top of the upper track rollers. Be sure that the footing is solid so the machine will not sink.

Traveling on Slopes

WARNING

- **Do not travel up a slope steeper than 15°. Do not travel down a slope steeper than 25°. Keep the boom centered while traveling.**
- **Keep attachments as low as possible when traveling on slopes and or rough terrain.**

Traveling on a slope is hazardous. When traveling, use the following guidelines:

- Travel straight up and down slopes—never across. See Figure 3-28.

- See Figure 3-28 on where to place the dipper arm, boom and bucket for uphill and downhill travel. Raise the bucket no higher than 12" (300 mm) off the ground for better stability. If the machine starts to slide or becomes unstable, lower the bucket to regain control. If the engine stalls, lower the bucket, be sure that all controls are in the neutral position and restart the engine.
- When traveling down a slope, control the speed with the travel levers and the throttle control; reduce engine speed.
- To achieve the best stability while excavating, lower the dozer blade to the ground.
- Avoid traveling over objects such as rocks, trees, stumps, etc.
- Stop the machine travel before moving the bucket or dozer blade controls.




Figure 3-28 Traveling Up or Down Slopes

Water Operation

1. In cold weather, mud and water should be removed from the machine before parking. If possible, park the machine on solid ground, or wood planks, to prevent the track or undercarriage from freezing to the ground.
2. Do not operate or immerse the machine in water higher than the tracks.
3. Thoroughly grease the machine if it has been operated in deep water.

Operating Instructions

Joystick Controls

Extending and retracting the cylinders (boom, arm and bucket) are controlled by the joysticks located on the consoles attached to the operator's seat. See *Equipment and Controls* on page 3-2 for control configurations.

Note: *The joystick controls are pilot-operated. The farther the controls are moved from center, the faster the machine will function.*

Hydraulic Swivel Unit Brake

The upper carriage's rotation is sufficiently braked by moving the control lever back to the initial position. Moving the control lever in the opposite direction brakes the upper carriage with full hydraulic pressure.

IMPORTANT

Hydraulic swivel unit brake function is not optimal if the hydraulic system has not reached operating temperature.

Mechanical Stop Brake

A multi-disc brake integrated into the rotation drive has an additional mechanical brake effect with a time delay. This brake is used to stop the swivel unit from rotating in any position.

Operating Precautions



DANGER

- **DO NOT push down with the dozer blade to elevate the front end of the tracks. This will cause the machine to become unstable.**
- **DO NOT excavate underneath the machine.**
- **Always be sure that there is adequate support when working near trenches. Be aware of conditions that could cause the earth to collapse, resulting in risk of injury or death.**
- **Do not position the machine directly underneath structures during demolition. Falling objects or structure collapse could cause severe damage or personal injury.**
- **Be sure that there is the proper clearance from overhead electrical lines.**
- **Be sure that all underground electrical power and gas supply lines are clearly marked and avoided.**



WARNING

- **DO NOT rest feet on the travel pedals during normal machine operation. Unexpected machine movement may occur in this situation.**
- **When working close to the excavated edge, be sure that the ground on which the machine is sitting is solid. Keep the travel motors to the rear. See Figure 3-29.**

DO NOT use machine travel or swing to provide additional breakout force when the bucket is in the ground.

DO NOT jam bucket into the ground and use machine weight to provide additional breakout force.

When working on soft or muddy ground, be sure that the machine is not sinking.

DO NOT use the bucket as a hammer or ramming device.

IMPORTANT

When digging at maximum excavation depth, **BE SURE** that the dozer blade does not contact the boom cylinder. Damage to the boom cylinder may occur if it contacts the dozer blade.




Figure 3-29 Machine Position for Excavating

Slope Operation

WARNING

- Do not travel up or across a slope steeper than 15°. Do not travel down a slope steeper than 25°. Keep boom centered while traveling.
- Keep attachments as low as possible when traveling on slopes or rough terrain.

Operating on a slope is hazardous. It is recommended to level the work area as shown in Figure 3-30. If this is not possible, observe the following guidelines:




Figure 3-30 Level Work Area on Slope

- Travel straight up and down slopes — never across. See the top of Figure 3-31. Extend arm and lower boom to keep the bucket about 12" (300 mm) off the ground. If the machine starts to slide or becomes unstable, lower the bucket to regain control. If the engine stalls, lower the bucket, be sure that all controls are in the neutral position and restart the engine.
- When traveling down a slope, put the machine in the position shown at the bottom of Figure 3-31, control the speed with the travel levers and the throttle controls, and reduce engine RPM.




Figure 3-31 Travel Down Slopes

- To achieve the best stability while excavating, lower the dozer blade to the ground.
- Operate as slowly as possible and avoid sudden changes in direction.
- Avoid traveling over objects such as rocks, trees, stumps, etc.
- Stop the machine travel before moving the bucket or dozer controls.
- Slow the work cycle. Take your time.
- Avoid working with the tracks positioned across the slope. Position the machine with the blade downhill and lowered.
- Avoid swinging or extending the bucket farther than necessary in a downhill direction. If you must swing the bucket downhill, keep the boom low and skid the bucket along the ground.
- When working with the bucket on the uphill side, keep the bucket as close to the ground as possible. Unload far enough away from the excavation to prevent the possibility of a cave-in.

Cold Weather Operation

In cold weather, mud should be removed from the machine before parking. See Track Cleaning on page 4-23 for cleaning mud off of the tracks. If possible, park the machine on solid ground, or on wood planks, to prevent the track or undercarriage from freezing to the ground.

Swiveling the Boom



WARNING

Working with the boom swiveled to the side reduces lifting capacity.

Overloading the bucket can cause an unstable condition, tipping the machine.

The excavator boom can be swiveled 50° to the right and 80° to the left from the front position. This allows excavation of trenches along walls, fences, etc. See Figure 3-32.




Figure 3-32 Boom Swiveled to the Left

Press and hold the swivel activation/changeover valve button (1), located on top of the left hand joystick, and press the auxiliary hydraulics pedal (2) toe or heel. Pressing down the toe of the pedal swivels the boom to the left. Pressing down the heel of the pedal swivels the boom to the right.

Note: *Bucket controls do not change when swiveling the boom*

Grading

Bulldozing

WARNING

- **Be sure there is proper clearance for the front end attachments when bulldozing.**
- **Be sure that the front end attachments do not contact overhead power lines or obstructions during bulldozing.**
- **DO NOT drive the machine into the excavation or onto loose soil, which can cause an unstable condition, and could possibly tip the machine.**

1. Raise or lower the dozer blade using control lever/pedal (1, Figure 3-33) located to the right of the travel levers/pedals. Move the lever forward to lower the dozer blade, rearward to raise the dozer blade.
2. The boom must be fully raised and the bucket curled in (up) when grading.
3. When grading, the material may be pushed away to the front or the side.
4. Raise the dozer blade slightly if excessive resistance occurs.
5. When the blade is in position, use the travel controls to move the machine as in normal travel.




Figure 3-33 Dozer Blade Control

Mounting/Removing Buckets

ALWAYS wear protective goggles, helmets, gloves, steel-toed shoes, etc.

DO NOT service the bucket while the engine is running.

DO NOT stand behind the bucket when removing the pins.

DO NOT use hands or fingers to align the bucket and dipper arm holes.

ALWAYS verify the bucket is safely locked before starting the engine and resuming operation.

WARNING

- **DO NOT hammer directly on a securing pin to loosen it. Hammering may cause splintering, which may lead to serious injury.**
- **The bucket can crush hands and feet. DO NOT use hands or feet as substitutes for the correct equipment.**

Bucket Removal

1. Lower the bucket to the ground with the flat side down (1, Figure 3-34).

IMPORTANT

Place the bucket against the ground with minimum pressure. More pressure increases resistance, which will make it more difficult to remove the pins.

2. Stop the engine.
3. Remove the two lynch pins (2A and 2B, Figure 3-34).




Figure 3-34 Bucket Removal/Mounting

4. Remove the lower securing pin first (3B, Figure 3-34) and then the other (3A). Carefully remove the pins with a hammer and brass punch if they are stuck. After pin 3B is removed, pin 3A might have more pressure applied against it, making it difficult to remove. If this happens:
 - a. Start the engine.
 - b. Slightly raise and lower the boom to relieve pressure from the pin.
 - c. Turn off the engine.
 - d. Try removing the pin again, using a hammer and brass punch if needed.

Attaching A Bucket

1. Grease the dipper arm and bucket holes.
2. Because the bucket is on the ground and stationary, move the machine until the dipper arm holes align with the bucket holes.



WARNING

DO NOT use your hands or fingers to align the bucket and dipper arm holes.

3. Stop the engine.
4. Insert the upper securing pin first (3A, Figure 3-34). If needed, use a hammer and brass punch to gently tap the pin through the hole. Insert a lynch pin (2A, Figure 3-34) through the hole in the pin and lock.

IMPORTANT

The flat side of each securing pin head must align with the flat guide on each side of the hole; see 3A and 3B in Figure 3-34 for how the pins look when properly installed.

5. Insert the lower securing pin (3B, Figure 3-34). If needed, use a hammer and brass punch to gently tap the pin through the hole. Insert a lynch pin (2B, Figure 3-34) through the hole in the pin. Lock the lynch pin securely in place.
6. Verify that the bucket is locked and secure before starting the engine and resuming operation.

Auxiliary Hydraulics Connections

IMPORTANT

Follow the instructions in the operator's manual from the attachment manufacturer for connecting the attachment to the machine's auxiliary hydraulics.

Figure 3-35 shows the quick couplers on the dipper arm for auxiliary hydraulics;

- **1:** Left side pressure line (male connector)
- **2:** Right side return line (female connector)




Figure 3-35 Auxiliary Hydraulics Couplers

Connecting the Quick Couplers

1. Park the machine on firm and level ground.
2. Extend the dipper arm cylinder halfway and position the boom/dipper arm so the auxiliary hydraulic connectors are positioned as shown in Figure 3-36.
3. Stop the engine.
4. Turn the ignition key to position 1.
5. Release pressure from the bucket cylinder by moving the left joystick to the left and right.
6. Lift the left console as a safety precaution.
7. To connect each coupler:
 - a. If necessary, rotate lock sleeve (2, Figure 3-36) so notch (3) aligns with lock ball (4).
 - b. Pull lock sleeve (2) down in the direction of arrow (5).
 - c. Insert the attachment coupling into the corresponding auxiliary hydraulics connection coupling.
 - d. Release lock sleeve (2) so it snaps into place and locks the couplings together. Verify the

lock sleeve (2) is snapped closed and the coupling is securely locked together.

- e. Twist lock sleeve (2) so notch (3) is NOT aligned with lock ball (4), to help prevent accidental de-coupling.

Disconnecting the Quick Couplers

1. Perform steps 1 through 6 in “Connecting the Quick Couplers” on page 3-26, before proceeding to the next step.
2. To disconnect each coupler:
 - a. Pull lock sleeve (2, Figure 3-36) down in the direction of arrow (5).
 - b. Listen for the hissing sound to verify that any pressure has been released from the connection.
 - c. Twist lock sleeve (2) so notch (3) is aligned with lock ball (4).
 - d. Push lock sleeve (2) up in the direction of arrow (6) to disconnect the coupling.




Figure 3-36 Quick Coupler Connections


Excavating

The following section applies to an excavator with a standard bucket, which is used mainly for digging into the ground to loosen, excavate and load loose or solid material.




IMPORTANT

Never use the excavator bucket to perform actions other than digging, grading, loading and excavating. Damage to the excavator could result.

- Do not use the swiveling force of the excavator so the bucket serves as a hammer or battering ram (1).
 - Do not lower the bucket into the ground while rotating the upper carriage or driving the excavator (2).
 - Do not use the falling force of the dipper arm so the bucket serves as a hammer or pile-driver (3).
 - Do not cause the excavator to tip, bounce or fall to amplify digging or excavating (4) force.
- Use caution when retracting the bucket to prepare for driving or transport. Hitting the bucket into the dozer blade might damage either attachment, especially the bucket teeth.
 - The dozer blade is intended for grading only; using it as a battering ram risks serious damage to the blade, its cylinder and connections.



- When excavating, lower the dozer blade to the ground to aid machine stability. It is best to position the dozer blade on the same side as the excavation, but position the blade on the opposite side of the excavation if the situation prevents the former.



Proper Digging Techniques

Proper Bucket Position

Move the flat side of the bucket so it is parallel to the ground (1, Figure 3-37).

IMPORTANT

Positions 2 and 3 in Figure 3-37 show improper positions for using the bucket. Position 2 forces the bucket downward into the ground, slowing down work and subjecting the engine and hydraulic pump to overloading.

Position 3 forces the bucket upward toward the ground surface, reducing productivity because of smaller loads being dug.




Figure 3-37 Proper Bucket Position

Proper Digging Technique

1. Lower the bucket into the ground (4, Figure 3-38).
2. After the bucket penetrates the ground, adjust it so the flat side of the bucket is parallel to the ground (5, Figure 3-38).
3. Pull the bucket towards the excavator by:
 - a. Moving the dipper arm toward the excavator, and...
 - b. Lowering the boom.

4. After the bucket is sufficiently filled:
 - a. Continue moving the dipper arm toward the excavator,
 - b. Extend the dipper arm cylinder so the bucket is tilted upward (6, Figure 3-38), and...
 - c. Raise the boom.




Figure 3-38 Proper Digging Technique

Trench Excavating

Trench excavating is most efficient when the machine tracks are parallel to the line of the trench (Figure 3-39). For larger trenches, excavate each side first and then the center.




Figure 3-39 Efficient Trench Excavating

When trench excavating is needed in confined areas, the excavating can be done by rotating the upper carriage and swiveling the boom (Figure 3-40).




Figure 3-40 Excavating Trenches Sideways

- Working alongside trenches and deep excavation are two applications where the dozer blade might restrict bucket movement. When working alongside trenches, lower and place the dozer blade on the ground to avoid damage to the boom cylinder. When deep excavating, position the machine so the lowered dozer blade is on the opposite side of the excavation (Figure 3-41).




Figure 3-41 Dozer Blade Positioning

WARNING

Placing the dozer blade on the opposite side of the excavation decreases machine stability. Always consider operator safety when operating the machine, especially when less-than-ideal working conditions.

Loading Vehicles

When loading vehicles, consider the following:

- Whenever loading in a confined area with a limited range of motion, position the truck so maximum visibility is ensured for the excavator operator.
- When work conditions permit, position the truck so the excavator can load material at the rear of the truck instead of the sides (1, Figure 3-42). The most effective way to load into the rear of the truck is when the truck and excavator form a 45° angle (2, Figure 3-42).
- Raise the boom and dipper arm to dump height just before rotating toward the truck.
- Whenever possible, dump upwind to keep dust and airborne debris away from the operator, and the excavator air filters and fans.




Figure 3-42 Loading Vehicles

TRANSPORTING

Towing

WARNING

- When towing the machine, make sure no one is close to the towing apparatus, or in between the vehicles. The machine may only be towed using suitable towing equipment, in connection with suitable towing apparatus, such as a towing coupling, hooks and eyes.
- Do not use a towing apparatus that is kinked, twisted, or otherwise damaged.
- Do not apply high loads abruptly to the retrieval apparatus. The towing bracket has a maximum admissible load 1-1/2 times greater than the weight of the machine. See "Specifications", beginning on page 1-4 for machine weights.
- The towing bracket is designed for retrieving the machine only. Do not use the excavator to tow other vehicles.
- Do not tow the machine if the travel drive is damaged. Damage to the machine cause by towing is not covered under warranty.

The excavator can be towed by using the towing bracket (1, Figure 3-43). Secure a towing shackle, shackle pin and lock (2) of adequate size to the towing bracket (1) as shown. Tow the machine slowly and only short distances.




Figure 3-43 Towing

Lifting the Machine

WARNING

- Use a lifting device and rigging with sufficient capacity for the weight of the machine plus any attachments.
- Maintain the center-of-gravity and balance points on the machine (Figure 3-44).
- Do not swing the boom.
- Never lift the machine with the operator aboard.

Lifting point decals on the boom and dozer blade (page 2-14) identify the lifting point locations. Secure the lifting fixture sling to these lift points on the machine as follows:

Required lengths L1 and L2 of the lifting gear:

Model	Length	Dimension
253	L1	88.2" (2240 mm)
	L2	144.5" (3670 mm)
303 / 353 / 373	L1	89.4" (2270 mm)
	L2	157.5" (4000 mm)

Authorized Lift Point Loads	Force
Boom	8992 lbf (40 kN)
Dozer blade	

Do not exceed rated load capacity of the lifting machine. See Specifications on page 1-4 for excavator weights.




Figure 3-44 Machine Lifting Points

Loading and Transporting

Use only transporters that are in proper working order and are approved for use on public roads.

When using ramps to load the machine onto a transporter:

- Do not exceed an incline of 17°.
- Clean dirt, mud, ice and snow from the ramps and tracks.
- Use metal loading ramps with a slip-resistant surface, and with beveled ends to prevent damage to rubber tracks.

Loading Procedure:

1. Attach ramps securely to the transporter to prevent them from slipping off during loading.
2. Load the transporter on solid, even ground.
3. Engage the transporter parking brake and chock the tires.
4. Determine the direction of track movement (blade facing forward) before moving the excavator onto the ramps.
5. After the excavator is on the transporter, perform the Mandatory Safety Shutdown Procedure on page 2-2.
6. Lock the cab door.
7. Place chocks around the excavator tracks.

8. Secure the excavator to the transporter at the tie-down points (2, Figure 3-45) to prevent the excavator from slipping, overturning or moving during transport.

Note: The tie-down points on the excavator are identified by decals (3, Figure 3-45).




Figure 3-45 Loading and Transporting

Notes:

CHAPTER 4 – MAINTENANCE

GENERAL INFORMATION



WARNING

Read and understand this entire manual before operating and/or servicing the machine. Follow warnings and instructions for operation and maintenance. Check for correct function after adjustments or maintenance. Failure to follow instructions can result in injury or death.



WARNING

Be sure you are familiar with all safety devices and controls before operating or servicing the machine. Know how to stop before starting. The machine is designed for use only with approved accessories or referral attachments. Manitou Americas, Inc. cannot be responsible for safety if the machine is used with non-approved attachments.



WARNING

The hydraulic reservoir is under pressure. Avoid contact with leaking hydraulic fluid and diesel fuel under pressure because they can penetrate the skin and eyes.

Care and Servicing

Care and servicing have a significant influence on the operational condition and the service life of the machine.

Use of lubricants not corresponding to the manufacturer's recommendations may invalidate warranty claims.

More frequent servicing, other than the recommended intervals, may be required under extreme conditions (extremely dusty or hot conditions).

Always dispose of waste lubrication oils and hydraulic fluids according to environmental laws or take to a recycling center for proper disposal. **DO NOT** pour fluids onto the ground or down a drain.

DO NOT power-wash the main hydraulic pumps and controls, throttle solenoids and sealed bearings. High pressure water can be forced through seals and trapped within these components, causing premature failure.

The operating pressure settings of the hydraulic system should only be adjusted by trained, qualified personnel. If malfunctions are caused by unauthorized alteration of operating pressure settings, all warranty responsibilities of the manufacturer are invalidated.

Maintenance Safety

- Never service the machine without reading the applicable instructions.
- Always lower bucket and dozer blade to the ground before performing any maintenance.
- Use correct procedures to lift and support the machine. Always lift the dozer blade fully before installing jackstands.
- Keep the engine cover and hydraulic valve covers closed except for service. Close and latch covers before operating the machine.
- Be sure to have the work area properly ventilated when grinding or welding parts. Wear a dust mask.
- Exhaust fumes can kill. Exhaust system must be tightly sealed. If working in an enclosed area, vent exhaust to outside if the engine must be run for service.
- Never perform unapproved modifications or add unapproved attachments.
- Stop the engine and let cool, then clean any flammable materials from the engine before checking fluid levels.
- Never service or adjust the machine with the engine running unless it is required by the service procedure.
- Avoid contact with leaking hydraulic fluid and diesel fuel under pressure. The pressurized fluids can penetrate the skin and eyes. NEVER use your hands to search for hydraulic fluid leaks — use a piece of paper or cardboard. Escaping fluid under pressure can be invisible, and if it penetrates the skin it can cause serious injury. If any fluid is injected into your skin, see a doctor at once. Injected fluid MUST be surgically removed by a doctor familiar with this procedure or gangrene may result.
- Never fill the fuel tank with the engine running, while smoking or when near open flame.
- Wipe up fuel spills immediately.
- Keep your body, jewelry and clothing away from moving parts, electrical contacts, hot parts and exhaust.
- Wear eye protection when servicing the machine.
- Lead-acid batteries produce flammable and explosive gas. Keep arcs, sparks, flames and lighted tobacco away from batteries.
- Batteries contain acid, which burns eyes and skin on contact. Wear protective clothing. If acid contacts body, flush well with water. For eye contact, flush well with water and get immediate medical attention.

MAINTENANCE SCHEDULE

The following service schedule is a recommended. Maintenance work must be done at regular intervals. Failure to perform scheduled maintenance work will result in excessive wear and early machine failures. The following service schedule is a recommended.

Check, Clean and Inspect

Service Activity	Daily	Every 50 Hours	Every 250 Hours	Every 500 Hours	Every 1000 Hours	Customer	Dealer
Engine oil level	x					x	
Engine coolant level	x					x	
Hydraulic oil level	x					x	
Check engine/hydraulic oil radiator and air conditioning for debris; clean if necessary	x					x	
Cab machines: windshield wipers condition; replace if necessary	x					x	
Cab machines: windshield washer reservoir; fill if necessary	x					x	
Check cooling system, heating and hoses for leaks and pressure (visual check)	x					x	
Air filter for damage; squeeze dust valve	x					x	
Serial Numbers AG00580 and up: drain approx. 1/2 oz. (10 ml) fuel/water mixture from fuel filter. Dispose properly.	x					x	
Inspect water separator pre-filter; drain water if necessary	x					x	
Check V-belt condition and tension	x					x	
Check exhaust system for damage	x					x	
Check tracks for cracks or cuts	x					x	
Check track tension; adjust if necessary	x					x	
Inspect cylinder piston rods for damage	x					x	
Ensure bucket and attachment pins are secure and locked	x					x	
Pin lock (dipper arm and attachment)	x					x	
Inspect hydraulic line clamps for tightness/damage; hydraulic system for leaks	x					x	
Clean hydraulic couplings/dirt build-up on the hydraulic system dust caps	x					x	
Grease central lubrication system	x					x	
Inspect engine cover gas strut	x					x	
Check battery electrolyte; fill with distilled water if necessary.		x				x	
Check primary pressure relief valve pressure ^a		x		x			x
Travel final drive gearbox oil level		x					x
Check fasteners for tightness ^a		x		x			x
Check indicator lights for correct function ^a		x		x			x

a. Check after first 50 hrs; every 500 hrs thereafter.

Check, Clean & Inspect (continued)

Service Activity	Daily	Every 50 Hours	Every 250 Hours	Every 500 Hours	Every 1000 Hours	Customer	Dealer
Cab/canopy tilt lock/support components ^a		x		x			x
Insulating mats in the engine compartment		x					x
Warning decals and Operator's Manual in place/undamaged		x					x
Clean water separator			x				x
Clean battery				x		x	
Replace cab air filter for heating and air conditioning				x			x
Empty diesel fuel tank ^a				x			x
Check alternator, starter and electrical connections, starter bearing play and function				x			x
Preheating system and electrical connections				x			x
Check air filter restriction indicator				x			x
Check bearing play on tread rollers, track carrier rollers and front idlers				x			x
Fuel injection pump, injection and pressure, injection nozzles and valves					x		x
Check injection timing; adjust if necessary					x		x
Check engine valve clearance; adjust if necessary					x		x
Check pilot control valve filter/restrictor; clean/replace if necessary					x		
Clean drain holes in cab/canopy					x		x

a. After emptying the tank, water must be removed and air must be purged from the fuel system before use. See "Water Separator" on page 4-13 and "Purging Air from the Fuel System" on page 4-13.

Fluid and Filter Changes

Service Activity	Daily	Every 50 Hours	Every 250 Hours	Every 500 Hours	Every 1000 Hours	Customer	Dealer
Engine oil		x ^a	x ^b	x			x
Engine oil filter		x ^a		x			x
Fuel filter		x ^c		x			x
Hydraulic oil filter		x ^c		x			x
Gearbox oil		x ^d			x		x
Hydraulic oil				x			x
Breather-hydraulic oil tank					x		x
Air filter element when indicator light comes on					x	x	
Engine coolant					x		x

a. Change after first 50 hrs; every 500 hrs thereafter.

b. Dusty work environment, high temperature, high rate of hammer use, and similar intensive use conditions.

c. Change after first 50 hrs; every 500 hrs thereafter.

d. Change after first 50 hrs; every 1000 hrs thereafter.

Swing Gear Ring

Service Activity	Daily	Weekly	Every 50 Hours	Every 125-250 Hours	Every 500 Hours	Every 1000 Hours	Annually
Check gear ring					x		
Check bearing system		x					x

Cab Heating System

Service Activity	Daily	Weekly	Every 50 Hours	Every 125-250 Hours	Every 500 Hours	Every 1000 Hours	Annually
Check fan			x				
Check system function			x				
Check heating system for leaks			x				
Check seals			x				

Bucket, Boom and Dozer Blade

Service Activity	Daily	Weekly	Every 50 Hours	Every 125-250 Hours	Every 500 Hours	Every 1000 Hours	Annually
Lubricate daily service points	x						
Lubricate weekly service points		x					
Check bucket teeth for wear	x						
Check hydraulic fittings for leaks	x						
Check hydraulic cylinder under load						x	
Check bearing play				x			

Lubrication

Use a heavy-duty lithium complex grease with 3% molybdenumdisulfide, such as Chevron RPM Heavy Duty Grease No. 2, Mobilgrease Moly 52 or BP Energrease Moly EP2. See “Fluid Capacities/Lubricants” on page 1-4




Figure 4-1 Lubrication Points

Note: The Model 253 remote lubrication point for the swing gear and swivel cylinder base end is located to the left side of the boom base attachment point. Models 303, 353 and 373 all have the remote lubrication point located to the right of the boom base attachment point, beneath the cab/canopy.

RECOMMENDED LUBRICANTS

Engine Oil

IMPORTANT
Be sure to read the engine manual supplied with the machine for detailed engine specifications.

See “Fluid Capacities/Lubricants” on page 1-4 for proper engine oil specifications.

Hydraulic Oil

See “Fluid Capacities/Lubricants” on page 1-4 for proper hydraulic oil specifications.

Swing Ring

Lubricate with a heavy-duty lithium complex grease with 3% molybdenum disulfide, such as Chevron RPM Heavy Duty Grease No. 2, Mobilgrease Moly 52 or BP Energrease Moly EP2.

Final Drive Unit

An EP grade gear oil that conforms to API GL5, such as Chevron Delo Gear 80W90 or BP Transgear 80W90.

All Lubrication Points - See Figure 4-1

Ranges of Applications

From -13° F to +104° F (-25° C to + 40° C) outside temperature.

ENGINE

Checking Engine Oil Level


IMPORTANT

See “Fluid Capacities/Lubricants” on page 1-4 for engine oil grade. Only use the engine oil specified or an equivalent quality and grade, or damage to the engine could occur.

To check the engine oil, the machine must be on a level surface with the engine turned off.

1. Run the engine until it is at operating temperature, then turn off the engine.
2. Pull the engine cover latch lever (see “Remote Engine and Hydraulic Valve Cover Latches” on page 3-14) and raise the engine cover.
3. Check the engine oil level using the dipstick located at the side of the engine near the engine cover latch (1, Figure 4-2).
4. Add oil if required.

Newer Machines



Earlier Machines




Figure 4-2 Engine Oil Dipstick Locations

Note: Marks on the dipstick indicate the minimum and maximum oil levels.

Changing Engine Oil and Filter

1. Perform the “Mandatory Safety Shutdown Procedure” on page 2-2, but do not allow the engine to fully cool because warm oil will drain more completely.

IMPORTANT

The machine must be positioned on a level surface for the oil to drain completely.


2. Pull the engine cover latch handle (located below the right side of the operator’s seat) and raise the engine cover.
3. Position waste oil collection container under engine oil pan.
4. Remove the drain plug from the oil pan and allow oil to drain into waste oil collection container.
5. Remove the oil filter (1, Figure 4-3), using a filter wrench as necessary.
6. Clean the filter housing surface. Put a film of clean oil on the filter gasket. Install the new filter with gasket and hand tighten.

IMPORTANT

Dispose of used oil and filters according to environmental laws or take to a recycling center for proper disposal. DO NOT pour oil onto the ground or down a drain.

7. Reinstall the drain plug.
8. Remove the oil filler cap from the engine. Pour in new oil. Crankcase capacity is 7 qts. (7 L).
9. Reinstall oil filler cap.
10. Start the engine and let it run for several minutes. Watch the engine oil pressure indicator light on the control panel. The light should turn off after several seconds. If it does not, shut off engine and determine the cause.
11. Stop the engine and check for leaks at the oil filter and oil drain plug.
12. Check the oil level again and add oil if necessary.

Newer Machines



Earlier Machines







Figure 4-3 Oil Filter

AIR CLEANER SERVICE

1. Perform the “Mandatory Safety Shutdown Procedure” on page 2-2.
2. On machines with serial numbers AD00001 and up, squeeze dust valve daily to purge accumulated dust from the air cleaner housing.
3.
 - On machines with serial numbers AD00001 and up, the air cleaner is located in the back of the hydraulic valve compartment. Pull the valve cover latch handle (located below the right side of the operator’s seat) and open the valve cover.
 - On machines with serial numbers before AD00001, the air cleaner is located in the engine compartment. Pull the engine cover latch handle (located below the right side of the operator’s seat) and raise the engine cover.
4. On machines with serial numbers AD00001 and up:
 - a. Unlatch clips securing the air filter cover (B, Figure 4-4). Remove the air filter cover.
 - b. Pull the air filter (C) out of the air filter enclosure. It may be necessary to wiggle the filter gently to free it from the enclosure.
 - c. If necessary, remove the inner filter (D).
5. On machines with serial numbers before AD00001:
 - a. Turn the air cleaner cover bolt to remove the air cleaner cover and gasket.
 - b. Remove wingnut (F) and remove air cleaner element.
 - c. Clean air cleaner element with 30 psi (200 kPa) compressed air from the inside.
6. Replace both the inner (D) and outer (C) air cleaner elements as necessary: when dirty or when the indicator light comes on. See “Fluid and Filter Changes” on page 4-4.
7. Clean the inside of the air filter housing components with a lint-free cloth.
8. Reinstall air cleaner element, any gaskets, air cleaner cover and any securing hardware. Tighten cover bolt/latches.
9. Close and secure engine cover or hydraulic valve cover.

909772/GP1211

Serial Numbers AD00001 and up



Serial Numbers Before AD00001




Figure 4-4 Air Filter Service

IMPORTANT

Do not knock air cleaner elements against a solid object to remove dust. The element may become distorted and damaged.

Do not operate engine without the air cleaner element installed or damage to the engine could occur.

FUEL SYSTEM


Filling the Fuel Tank

WARNING

Stop the engine and let it cool before adding fuel. **NO SMOKING!** Failure to obey warnings can cause an explosion or fire.


The fuel level in the tank is indicated by the fuel gauge on the console (1, Figure 4-5).

To fill the tank, remove the fuel filler cap (1, Figure 4-5) located inside the engine compartment on the left. Fill using clean diesel fuel with a cetane rating over 45. See “Fluid Capacities/Lubricants” on page 1-4 for proper fuel grade/type. Re-install fuel cap.



Serial Numbers AD00001 and up

2 - Air Cleaner Located in Hydraulic Valve Compartment



Serial Numbers Before AD00001



Figure 4-5 Fuel Filler Cap, Air Cleaner and Coolant Reservoir

IMPORTANT

Unless draining fuel tank for servicing, never operate the machine until the fuel tank is completely empty. The fuel system has to be bled of air whenever the fuel tank is run empty. Always fill the fuel tank after use.

IMPORTANT

When using the machine in cold weather, make sure to use the proper fuel blend to prevent the fuel filters from “jelling” up. If this happens, the fuel filter and water separator elements will have to be replaced, and the fuel will have to be replaced with the proper fuel.

WARNING

Always clean up spilled fuel and oil. Keep heat, flames, sparks and lighted tobacco away from fuel and oil. Failure to use care around combustibles can cause explosion or fire, which can result in injury or death.

WARNING

When handling fuel, there is a high risk of fire. Never work on the fuel system around open flames or sparks. **DO NOT** smoke when working on the fuel system or refueling. Before refueling, turn off the engine and remove the ignition key. Do not refuel in closed rooms. Wipe up fuel spills immediately. Keep the machine clean to reduce the risk of fire.

Fuel Filter

WARNING

Use care to catch any spilled fuel when servicing the fuel filter. Spilled fuel can cause a fire.

On machines with serial numbers AD00001 and up the fuel filter is located on a bracket attached to the engine to the right of the fuel fill. On earlier machines, the fuel filter is located below the engine hood latch.

Note: Fuel filter installations may differ slightly from that shown in Figure 4-6.

Draining Water from Fuel Filter (Serial Numbers AG00593 and up)


Note: daily, before starting the machine, drain about 1/2 oz. (10 ml) fuel/water mixture from the fuel filter and dispose of properly.

Hold a container under valve (2, Figure 4-6) on the bottom of the fuel filter to catch draining fuel/water. Open drain valve (2) on the bottom of the fuel filter. Discard fuel/water according to environmental laws. DO NOT pour fluids onto the ground or down a drain.

Fuel Filter Replacement

1. Perform the “Mandatory Safety Shutdown Procedure” on page 2-2.
2. Shut off fuel using the fuel filter shut-off valve (2, Figure 4-6 and Figure 4-7).
3. Clean dirt from the filter housing and bracket.
4. On machines with serial numbers AD00001 and up:
 - a. Unscrew, remove and discard old filter element properly.
 - b. Clean around the filter housing.
 - c. Put oil on the seal of the new filter element.
 - d. Install the fuel filter and hand-tighten.

Serial Numbers AD00001 and up



Serial Numbers Before AD00001




Figure 4-6 Fuel Filter

5. On machines before serial numbers AD00001:
 - a. Unscrew the clear plastic housing (1, Figure 4-6) to change the filter element
 - b. Remove and discard old filter element properly.
 - c. Clean around the filter housing.
 - d. Put oil on the seal of the new filter element.
 - e. Install the fuel filter and hand-tighten.
6. Open fuel valve.


The fuel system must be purged of air after changing the fuel filter, or if the fuel tank has been run dry. See “Purging Air from the Fuel System” on page 4-13.

Water Separator

If water is seen in the water separator bowl, the water will need to be drained.

1. Twist the fuel shut-off valve lever (2, Figure 4-7) on the water separator to the (OFF) position.
2. Unscrew plug (3) and collect the water that drains out of the water separator. Allow the water to drain until the indicator ring (1) falls to the bottom of the water separator.
3. Tighten plug (3) and discard fuel/water according to local regulations. DO NOT pour fluids onto the ground or down a drain.
4. Twist the fuel shut-off valve (2) on the water separator to the (ON) position.
5. Purge air from the fuel system.

Serial Numbers AD00001 and up



Serial Numbers Before AD00001




Figure 4-7 Water Separator

Purging Air from the Fuel System



WARNING

DO NOT air bleed a hot engine. Spilled fuel can cause a fire danger.

If the fuel tank has been run dry, or the fuel filter, water separator or fuel lines have been replaced, trapped air must be removed (bled), from the fuel system.

Purging air on machines with serial numbers AD00001 and up

1. Fill the fuel tank.
2. Make sure that the valve on the water separator (2, Figure 4-7) is in the “open” (ON) position.
3. Turn the ignition key to the “I” (ON) position.
4. Wait about five minutes while the fuel system automatically bleeds itself.
5. Start the engine.

If the engine runs smoothly and then stops, or if it does not run smoothly, switch off the engine and bleed the system again as described in this procedure. If the engine still does not run smoothly, contact your dealer.

Purging air on machines with serial numbers before AD00001:

1. Rotate the fuel air bleed valve (1, Figure 4-8) counterclockwise to the open position.
2. Turn the engine over for approximately 10 seconds, which will cause fuel and any entrained air to be returned to the fuel tank.
3. Close the air bleed valve by rotating the valve clockwise until it stops turning.

IMPORTANT

If the air bleed valve is not fully closed, the engine will not start.

Serial Numbers Before AD00001




Figure 4-8 Bleeding Air from Fuel System on Machine with Serial Numbers Before AD00001

COOLANT SYSTEM

Checking Coolant Level

- Engine must be cold.
 - Be careful to avoid burns when removing the radiator cap.
1. Pull the engine cover latch handle (located under the right side of the operator's seat) and raise the engine cover.
 2. Check the coolant level in the expansion reservoir (C, Figure 4-9).

Serial Numbers AD00001 and up



Serial Numbers Before AD00001



Figure 4-9 Coolant Level for Serial Numbers AD00001 and up

3. If low, remove reservoir cap and fill reservoir to FULL line.

CHECKING AND ADJUSTING V-BELT TENSION

1. Position the machine on a level surface.
2. Lower the bucket and dozer blade to the ground. Move the joysticks in all directions to verify the hydraulic system is de-pressurized.
3. Shut off the engine. Remove the ignition key and take it with you. Lock out the controls by raising left control console. Wait for the engine to cool down.
4. Pull the engine cover latch handle (located under the right side of the operator's seat) and raise the engine cover.
5. Carefully inspect the V-belt (1, Figure 4-10) for damage. If the V-belt (1) is damaged, have it replaced by your dealer.
6. Press on the center of a span on the V-belt to check deflection. The belt deflection should be no more than 5/16" (8 mm).
7. If deflection is more than 5/16" (8 mm):
 - a. Loosen adjustment bolt (2) and rotate the alternator (3) in the direction of the arrow until V-belt tension is correct.
 - b. Tighten adjustment bolt (2) and re-check V-belt tension.




Figure 4-10 Checking & Adjusting V-belt Tension

ELECTRICAL SYSTEM



WARNING

Inspect and check the machine's electrical equipment at regular intervals. Defects, such as loose connections or scorched cables must be repaired before using the machine.

Work on the machine's electrical system must be done only by a trained technician.

Fuses

On machines with serial numbers AD00001 and up, The fuse panel (1, Figure 4-11) is located below and to the right of the operators seat, in the kick panel. On machines with serial numbers before AD00001, the fuse panel (1, Figure 4-11) is located on the right-hand console, toward the rear, below the switches.

To replace a fuse, remove the panel cover and pull the old fuse from the socket. Install a new fuse of the same rating and re-install the fuse panel cover.

Refer to "Fuse Panel" on page 1-8 for fuse identification and assignments.

IMPORTANT

Blown fuses indicate electrical system malfunctions. Determine what caused the fuse to blow and repair the problem before replacing the fuse.

Serial Numbers AD00001 and up



Serial Numbers Before AD00001




Figure 4-11 Fuse Panel

Battery



WARNING

Before servicing the battery or electrical system, disconnect the negative cable from the negative battery terminal, or if the machine is equipped with a battery disconnect switch, turn the switch to the “OFF” position.

Explosive gas is produced while a battery is in use or being charged. Keep flames or sparks away from the battery area. **ALWAYS** charge the battery in a well ventilated area.

Do not jump-start a frozen battery, or it may explode. A discharged battery can freeze at 14°F (10°C).

To prevent short circuits keep metal parts on your clothing and metal watchbands away from the positive (+) terminal of the battery.



WARNING

Never lay a metal object on top of a battery, because a short circuit can result. Battery acid is harmful to skin and fabrics. If acid spills, follow these first-aid tips:

Immediately remove any clothing on which acid spill.


- If acid contacts skin, rinse the affected area with running water for 10 to 15 minutes.
- If acid contacts eyes, flood eyes with running water for 10 to 15 minutes. See a doctor at once. Never use any medication or eye drops unless prescribed by the doctor.
- To neutralize acid spilled on the floor, use one of the following mixtures:
 - 0.5 kg (1 lbs.) of baking soda in 4 L (4 qts.) of water.
 - 0.5 L (0.5 qts.) of household ammonia in 4 L (4 qts.) of water.

Battery Access

The battery is located under the engine cover, near the right rear counterweight (Figure 4-11).

To access the battery, pull the engine cover latch handle (“Remote Engine and Hydraulic Valve Cover Latches” on page 3-14) and open the engine cover.

Loosen bolts (A and B, Figure 4-12) on the counterweight at the right side of the engine compartment. Carefully slide the counterweight rearward on the support rails to access battery.

**WARNING**

Loosen only bolts A and B shown in Figure 4-12. Loosening any other bolts may cause the counterweight to fall and cause injury.

The battery cables must be clean and tight. Remove any acid or corrosion from the battery and cables using a sodium bicarbonate and water solution. Cover the battery terminals and cable ends with battery-saver grease.

The battery is maintenance-free and requires no other service.

Return counterweight to the stored position and fully tighten bolts A and B.




Figure 4-12 Battery Location

Using a Booster Battery (Jump-Starting)

WARNING

- Keep arcs, sparks, flames and lighted tobacco away from batteries. When jump-starting from booster battery, make final connection (negative) at the engine frame away from the battery. A discharged battery can create flammable gases. Sparks or open flames can cause the gas to explode.
- Do not jump-start a frozen battery, or it may explode. A discharged battery can freeze at 14°F (10°C). Warm battery to 60°F (16°C) before connecting to a charger. Unplug the charger before connecting or disconnecting cables to the battery.

IMPORTANT

When jump-starting from another machine, be sure the second machine is not running while using the unstarted machine's glow plugs. High voltage spikes from a running machine can damage the glow plugs.

IMPORTANT

Damage to the alternator can occur if:

- the engine is operated with the battery cables disconnected,
- the battery cables are connected when using a fast charger or when welding on the machine (When welding on the machine, remove both cables from the battery and ground the welder to the machine frame near the repair area), or
- battery booster cables incorrectly connected.

IMPORTANT

The booster battery must be 12 volt.

1. Turn ignition key on the machine with the discharged battery to the "P" position.
2. Access the battery according to "Battery Access" on page 4-17.
3. Connect one end of the cable to the positive (+) terminal on the booster battery. Connect the other end of the same cable to the positive (+) terminal on the battery of the machine to be started.
4. Connect one end of the second cable to the negative (-) terminal on the booster battery. Connect the other end of the same cable to the frame of the machine to be started.
5. Start the engine. After the engine is running, remove the cable connected to the frame first. Disconnect the other cable from the machine battery positive (+) terminal.
6. Close battery compartment according to "Battery Access" on page 4-17.




Figure 4-13 Jump-Starting

IMPORTANT

DO NOT allow the cable ends to touch when removing them from the batteries. Arcs and short circuits can cause severe damage to the electrical system of the running

HYDRAULIC SYSTEM



WARNING

Hydraulic reservoir is under pressure. Never use your hands to search for hydraulic fluid leaks; use a piece of paper or cardboard to find leaks. Escaping fluid under pressure can be invisible and can penetrate the skin, causing a serious injury. If any fluid is injected into your skin, see a doctor at once. Injected fluid **MUST** be surgically removed by a doctor familiar with this procedure, or gangrene may result.

Checking Hydraulic Oil Level

1. Position the machine on a level surface.
2. Fully retract the bucket, dipper arm cylinders, and position the boom as shown in Figure 4-14.
3. Lower bucket and dozer blade to the ground. See Figure 4-14. Turn off the machine.




Figure 4-14 Checking and Changing Hydraulic Oil

4. Check the hydraulic oil level sight gauge. Oil level should be visible in the sight gauge (1, Figure 4-15). If hydraulic oil is required, proceed to step 5.




Figure 4-15 Hydraulic Reservoir

5. Slowly open the hydraulic oil filler cap (3) to relieve pressure, then remove cap (3).
6. Add hydraulic oil until oil level is about half way up the sight gauge, approximately at the point shown at (2).
7. Re-install hydraulic oil filler cap (3) and tighten securely.
8. Start engine and let it idle for a few minutes.
9. Check hydraulic functions. Recheck hydraulic oil level.

Changing Hydraulic Oil

1. Position the machine on a level surface.
2. Fully retract the bucket and dipper arm cylinder, and position the boom as shown in Figure 4-14. Lower bucket and dozer blade to the ground. Stop the engine.
3. Slowly open the filler cap (3, Figure 4-15) to relieve pressure. Remove cap (3) and clean strainer of any debris.
4. Remove the hydraulic reservoir cover as shown in Figure 4-16.
5. Open the drain plug and drain oil into a suitable container. Re-install drain plug and tighten securely.




Figure 4-16 Hydraulic Reservoir

IMPORTANT

Always dispose of hydraulic fluids according to local regulations or take to a recycling center for proper disposal. DO NOT

6. Remove bolts and filter cover. Remove and discard old filter. Put clean hydraulic fluid on the filter gasket and install gasket and new filter into reservoir (Figure 4-16).
7. Reinstall filter cover and bolts.
8. Fill reservoir with hydraulic oil until oil is seen on sight gauge.
9. Re-install hydraulic oil filler cap and tighten securely.
10. Start engine and let it idle for a few minutes.
11. Cycle all front attachment hydraulic functions. Recheck hydraulic oil level.

Hydraulic Hose Maintenance

WARNING

- Hydraulic hoses and connections must be inspected by a trained technician before the first use of the machine, and at least annually thereafter, for leaks and/or damage.
- Leakages and damaged pressure lines must be immediately repaired or replaced by an authorized service center.
- Never use your hands to check for suspected hydraulic leaks. Always use a piece of wood or cardboard.
- Leaks from hydraulic hoses or pressurized components can be difficult to see, but pressurized oil can have enough force to pierce the skin and cause serious injury.
- Obtain immediate medical attention if pressurized oil pierces the skin. Failure to obtain prompt medical assistance could result in gangrene or other serious damage to tissue.
- Always relieve hydraulic system pressure before performing any maintenance on the machine. Do not tighten leaking connections when the hydraulic system is under pressure.
- Never weld or solder damaged or leaking pressure lines and/or screw connections. Always replace damaged hydraulic components.
- Hydraulic hoses must be replaced every six years from the date of manufacture, even if they do not appear damaged. The date of manufacture (month or quarter and year) is indicated on hydraulic hoses. See Figure 4-17.




Figure 4-17 Hydraulic Hose Manufacture Date

TRACK SYSTEM

Track Cleaning

If dirt or mud builds up in the track frame, raise the track frame using the boom and dipper arm and then operate the elevated track to clean it. Be sure that the build-up has been cleared from the track. Repeat for the other track. See Figure 4-18.




Figure 4-18 Track Cleaning

Note: When using the boom and dipper arm to lift any portion of the machine, roll the bucket until the round base is against the ground. The angle of the dipper arm to the boom should be at 90°. See Figure 4-18.

Changing Final Drive Oil

1. Position the machine on a level surface with final drive plugs positioned as shown in “Drain Position” (Figure 4-19). Turn off the engine.
2. Shut off the engine. Remove the ignition key and take it with you. Lock out the controls by raising left control console.
3. Open both plugs and drain oil into a suitable container. Re-install plugs.

IMPORTANT

Always dispose of oil according to environmental laws or take to a recycling center for proper disposal. DO NOT pour fluids onto the ground or down a drain.

4. Start the engine and move the machine slightly until plugs are positioned as shown in “Fill Position” (Figure 4-19). Turn off the engine.
5. Shut off the engine. Remove the ignition key and take it with you. Lock out the controls by raising left control console.

6. Remove both screw plugs. Pour fresh oil (Chevron Delo Gear 80W90 or BP Transgear 80W90) into the top hole until oil runs out of the bottom hole.
7. Re-install both plugs securely.




Figure 4-19 Track Final Drive Oil Change

Checking and Adjusting Track Tension

1. Position the machine on a level surface. On machines equipped with rubber tracks, position the excavator so the tracks are positioned with mark (1, Figure 4-20) on the top span of the track in between drive pinion (2) and track tension roller (3).




Figure 4-20 Rubber Track Tensioning Positioning

2. Use the bucket and dozer blade to lift the unit up until a track is just clear of the ground as shown in Figure 4-21.
3. Shut off the engine. Remove the ignition key and take it with you. Lock out the controls by raising left control console.
4. Measure the clearance of the raised track at the second track roller from the drive gear. Deflection should be between 3/4-1" (20-25 mm).
5. Using a grease gun, pump grease into the fitting until the track is properly tensioned (Figure 4-21).

Note: A grease gun is supplied with machine tool kit.

IMPORTANT

Do not over-tension the track. If the track is too tight, loosen the grease fitting to relieve the pressure.



WARNING

Do not loosen the grease fitting more than two turns, or the fitting could be ejected under pressure and cause injury. Keep your face and body away from the fitting when loosening.

6. Start the engine. Lower the unit to the ground.
7. Repeat this procedure for the other track.




Figure 4-21 Track Adjustment

Windshield Washer Fluid

1. Turn off the engine.
2. Pull the valve cover latch handle and open the hydraulic valve cover.
3. Open the windshield washer tank cover (1, Figure 4-22) and fill the tank with windshield washer fluid.
4. Close the windshield washer tank cover securely.
5. Close and latch the hydraulic valve cover.




Figure 4-22 Windshield Washer Tank

CAB/CANOPY REMOVAL/ REPLACEMENT

WARNING

- Always tighten cab lock-down hardware before driving or using the machine.
- Always close the cab door before lifting the cab/canopy.
- Stay clear from underneath the cab when it is lifted.

Cab/Canopy Removal Procedure

1. Position the machine to allow for removal of the cab/canopy by a lifting device of sufficient capacity.
2. Follow “Mandatory Safety Shutdown Procedure” on page 2-2.
3. Disconnect cab/canopy wiring at plug (B, Figure 4-23) (X28), located next to the seat at the right rear of the cab/canopy.
4. On cabs, disconnect the windshield washer hose (C) from the windshield washer reservoir tank, located at the front right inside the engine compartment.
5. Remove fasteners (E) at the rear corners of the cab/canopy.
6. Lift the front corners of the floor mat and remove fasteners (F) at the front corners of the cab/canopy.








Figure 4-23 Cab/Canopy Removal/Installation

7. Fasten lifting rigging of sufficient capacity to lifting points (1, Figure 4-24) on the top of the cab/canopy.

IMPORTANT

Spans (L1) of lifting rigging (1) must be 39.4" (1000 mm) long.




Figure 4-24 Cab/Canopy Lifting

8. Carefully lift the cab/canopy off the machine and set in a secure storage area on solid, secure footing.

! WARNING

Stay clear from underneath the cab when it is lifted. Position the cab/cabin so it will stand safely and not tip over. Serious injury can occur if the cab/canopy tips over onto a person.

Cab/Canopy Installation Procedure

1. Fasten lifting rigging of sufficient capacity to lifting points (1, Figure 4-24) on the top of the cab/canopy.

IMPORTANT

Spans (L1) of lifting rigging (1) must be 39.4" (1000 mm) long.

2. Carefully lift the cab/canopy. Align the cab/canopy with the fasteners on the machine and carefully lower the cab unto the machine.

! WARNING

Stay clear from underneath the cab when it is lifted.

3. Fasten the front corners front corners of the cab/canopy and tighten the hardware (F, Figure 4-23) securely. Replace the floor mat over the fasteners.
4. Fasten the rear corners of the cab/canopy and tighten hardware (E) securely.
5. Remove the lifting rigging from the cab/canopy.
6. On cabs, connect the windshield washer hose (C) to the windshield washer reservoir tank located at the front right inside the engine compartment.
7. Connect cab/canopy wiring at plug (B, Figure 4-23) (X28), located next to the seat at the right rear of the cab/canopy.

LONG-TERM STORAGE

If the machine will not be operated for a month or longer, prepare and store the machine using the following procedure:

Before Storage

Perform the following prior to placing the machine in storage:

1. Wash the entire machine.
2. Lubricate all grease fittings as directed in “Lubrication” on page 4-6.
3. Change the engine oil and filter as directed in page 4-9.
4. If the machine will not be operated for a month or longer, retract all cylinders so rod exposure is minimized. Apply grease to any rod areas that remain exposed.
5. Add a fuel stabilizer to the fuel system according to the fuel supplier’s recommendations.
6. Remove and fully charge the battery. Store the battery in a cool, dry location.
7. If the ambient temperature (at any time during the storage period) is expected to drop below freezing, make sure the engine coolant is either completely drained from the radiator and engine block or that the amount of anti-freeze in it is adequate to keep the coolant from freezing. Refer to the engine manual for anti-freeze recommendations and quantities.
8. Protect the machine against extreme weather conditions such as moisture, sunlight and temperature.

During Storage

About once each month, connect the battery and check all fluid levels to make sure they are at the proper level before starting the engine.

Start the engine and allow it to run until it warms up and then move the machine a short distance to help re-lubricate the internal parts. Run the engine until the battery has a chance to recharge and then shut it off.

IMPORTANT

If it is desired to operate the hydraulic cylinders at this time, BE SURE to wipe the protective grease (and any adhering dirt) from the cylinder rods prior to starting the engine. After operating, BE SURE to re-coat the cylinder rods with grease if the machine is to be returned to storage.

After Storage

After removing the machine from storage and before operating it, perform the following:

1. Replace and re-connect the battery.
2. Wipe off grease (and any adhering dirt) from cylinder rods
3. Check V-belt tension.
4. Check all fluid levels and top-off as necessary.
5. Lubricate all grease fittings as directed in “Lubrication” on page 4-6.
6. Start the engine. Observe all indicators. If all indicators are functioning properly and reading normally, move the machine outside.
7. When outside, park the machine and let the engine idle for at least five minutes.
8. Shut off the engine and walk around machine. Make a visual inspection looking for evidence of leaks.
9. Review and re-familiarize yourself with all safety precautions starting on page 2-1.
10. Follow the starting and warm-up procedures according to starting on page 3-15.

Notes:

CHAPTER 5 – TROUBLESHOOTING

ENGINE

Problem	Possible Cause	Corrective Action
Engine hard -starting or fails to start	No fuel	Add fuel to tank; bleed air from fuel system
	Incorrect engine oil SAE grade	Replace engine oil with proper grade; see “Fluid Capacities/Lubricants” on page 1-4
	Incorrect fuel grade	Replace fuel with proper grade; see “Fluid Capacities/Lubricants” on page 1-4
	Loose, or corroded starter circuit connections	Repair starter circuit; contact authorized service center
	Incorrect engine valve clearance	Adjust valve clearance; contact authorized service center
	Battery power insufficient	Charge battery or replace if necessary. See “Battery” on page 4-16
	Fuel filter contaminated	Replace fuel filter; see “Fuel Filter” on page 4-12
	Malfunctioning fuel injector(s)	Repair fuel injector(s); contact authorized service center
	Starter not working / pinion fails to engage	Repair starter/pinion; contact authorized service center
	Glow plug system not working	Replace glow plug system. Contact authorized dealer
Rough running engine	Incorrect fuel grade	Replace fuel with proper grade; see “Fluid Capacities/Lubricants” on page 1-4
	Incorrect engine valve clearance	Adjust valve clearance; contact authorized service center
	Fuel line leakage	Replace fuel line; contact authorized service center
	Malfunctioning fuel injector(s)	Repair fuel injector(s); contact authorized service center.
Insufficient engine power	Fuel line leakage	Replace fuel line; contact authorized service center
	Air filter contaminated	Service air filter; see “Air Cleaner Service” on page 4-10
	Engine not at operating temperature	Warm up the engine
	Incorrect fuel grade	Replace fuel with proper grade; see “Fluid Capacities/Lubricants” on page 1-4
	Incorrect engine valve clearance	Adjust valve clearance; contact authorized service center
	Oil level too high	Adjust oil level; see “Changing Engine Oil and Filter” on page 4-9
	Malfunctioning fuel injector(s)	Repair fuel injector(s); contact authorized service center
	Engine overheated	Check cooling system

Problem	Possible Cause		Corrective Action
Engine overheats	Oil level too low		Add engine oil; see "Checking Engine Oil Level" on page 4-8
	Fouled oil cooler fins		Clean oil cooler; contact authorized service center
	Damaged fan. Damaged or loose V-belt		Replace the fan / service V-belt; see "Checking and Adjusting V-belt Tension" on page 4-15; contact authorized service center
	Coolant level too low		Add coolant; see "Checking Coolant Level" on page 4-14
	Oil level too high		Adjust oil level; see "Changing Engine Oil and Filter" on page 4-9
	Oil level too low		Add engine oil; see "Checking Engine Oil Level" on page 4-8
	Malfunctioning fuel injector(s)		Repair fuel injector(s); contact authorized service center
High engine oil consumption	Oil level too high		Adjust oil level; see "Changing Engine Oil and Filter" on page 4-9
	Machine inclination too high		15° maximum inclination up and across slopes; 25° maximum inclination down slopes
	Incorrect engine oil SAE grade		Replace engine oil with proper grade; see "Fluid Capacities/Lubricants" on page 1-4
Engine smoke	Blue	Oil level too high	Adjust oil level; see "Changing Engine Oil and Filter" on page 4-9
		Machine inclination too high	15° maximum inclination up and across slopes; 25° maximum inclination down slopes
	White	Incorrect fuel grade	Replace fuel with proper grade; see "Fluid Capacities/Lubricants" on page 1-4
		Engine starting temperature too low	Wait for engine pre-heat cycle to complete before starting engine
		Incorrect engine valve clearance	Adjust valve clearance; contact authorized service center
		Malfunctioning fuel injector(s)	Repair fuel injector(s); contact authorized service center
	Black	Air filter contaminated	Service air filter; see "Air Cleaner Service" on page 4-10
		Incorrect engine valve clearance	Adjust valve clearance; contact authorized service center
		Malfunctioning fuel injector(s)	Repair fuel injector(s); contact authorized service center

INDICATOR LAMPS

Problem	Possible Cause	Corrective Action
Engine oil pressure indicator light comes on during operation	Engine oil pressure too low	Stop engine immediately; check oil level and add oil if necessary; see "Checking Engine Oil Level" on page 4-8; if oil level is correct, oil pump may have failed
	Engine oil level too low	Add oil; see "Checking Engine Oil Level" on page 4-8
	Oil pump not working	Stop engine immediately; replace oil pump. Contact authorized service center
	Machine inclination too high	15° maximum inclination up and across slopes; 25° maximum inclination down slopes
	Incorrect engine oil SAE grade	Replace engine oil with proper grade; see "Fluid Capacities/Lubricants" on page 1-4
Water temperature indicator illuminates during operation	Coolant level too low	Add coolant; see "Checking Coolant Level" on page 4-14
	Fan blades rotating too slowly	Adjust V-belt tension; see "Checking and Adjusting V-belt Tension" on page 4-15
	Air filter contaminated	Service air filter; see "Air Cleaner" on page 4-12
	Coolant system malfunction	Service cooling system; contact authorized service center
Battery voltage indicator illuminates during operation	Alternator not charging properly / malfunctioning alternator	Adjust V-belt tension; see "Checking and Adjusting V-belt Tension" on page 4-15
	Loose, or corroded charging circuit connections	Repair charging circuit; contact authorized service center
Fuel light indicator illuminates	Low fuel	Add fuel
Air filter light comes on	Air filter contaminated	Service air filter; see "Air Cleaner Service" on page 4-10

SEALS AND HOSES

Problem	Possible Cause	Corrective Action
Oil, coolant or fuel leakage under engine	Loose hose connection	Tighten hose connection(s)
	Seals or hoses damaged	Change seals or hoses and check engine oil, engine coolant or fuel levels; add engine oil, coolant or fuel if necessary
Hydraulic fluid losses from hydraulic system	Loose hose fittings	Tighten hose connection(s)
	Seals, hoses or lines damaged	Service seals, hoses and/or lines; contact authorized service center

TRAVELING GEAR

Problem	Possible Cause	Corrective Action
Machine will not travel	Obstruction jamming track mechanism	Remove object
	Gears inoperative	Repair gear; contact authorized service center
Machine will not travel straight forward or backward	Obstruction jamming track mechanism	Remove object
	Unequal track tension	Adjust track tension; see "Checking and Adjusting Track Tension" on page 4-23
	Travel valves damaged	Repair/replace valves; contact authorized service center

BUCKET, BOOM AND DOZER BLADE

Problem	Possible Cause	Corrective Action
Rotating swing frame is difficult or impossible	Swing brake does not release	Contact authorized dealer
	Insufficient lubrication	Lubricate swing gear using remote grease fitting
Front end attachments do not work or work only at a low performance level	Low hydraulic fluid level	Add hydraulic fluid; see "Checking Hydraulic Oil Level" on page 4-19
	Low engine power	See "Engine" troubleshooting on page 5-1; contact authorized service center
	Engine-to-pump coupling or hydraulic pump damaged	Contact authorized dealer
	Pressure limiting valve set too low	Contact authorized dealer
	Hydraulic cylinder damaged	Contact authorized dealer
	Control valve damaged	Contact authorized dealer
Hydraulic cylinders lower too quickly	Seals contaminated or damaged	Contact authorized dealer
	Heavy internal leakage at control spools	Contact authorized dealer
	Secondary cartridge damaged	Contact authorized dealer
Hydraulic lines overheat	Hydraulic oil filter blocked	Clean or replace filter
	Low hydraulic fluid level	Add hydraulic fluid; see "Checking Hydraulic Oil Level" on page 4-19
	Secondary cartridges set too low	Contact authorized service center
	Hydraulic fluid cooling system not in working order	Service hydraulic fluid cooling system; contact authorized service center

Index

A

Air Cleaner Service	4-10
Purge Valve	4-10
Air Intake Filter	4-10
Auxiliary Hydraulics	
Flow Control Valve	3-11
Quick Couplers/Connectors	3-26

B

Battery	4-16
Jump-Starting	4-18
Battery Access	4-17
Boom Swivel	3-9
Bucket Attachment	3-25
Bucket Removal	3-24
Bulldozer	3-24

C

Cab Door Latch	3-14
Cab Equipment and Controls	3-2
Cab Heater Shut-off Valve	3-14
Cab/Canopy Removal	4-25
Changing Final Drive Oil	4-22
Changing Hydraulic Oil	4-20
Checking Coolant Level	4-14
Checking Engine Oil Level	4-8
Checking Hydraulic Oil Level	4-19
Checklists	1-17, 1-19
Cold Weather Engine Starting Procedure	3-17
Cold Weather Operation	3-23
Component Names	1-3
Coolant System	4-14
Checking Coolant Level	4-14

D

Decals	
ANSI-Style Safety Decal Locations	2-16
Delivery Checklists	1-17
Digging	
Proper Technique	3-28
Dozer Blade Control	3-10

E

Electrical System	4-15
Battery	4-16
Battery Access	4-17

Fuses	4-15
Jump-Starting	4-18
Engine	
Air Cleaner Service	4-10
Changing Engine Oil and Filter	4-9
Checking Engine Oil Level	4-8
V-Belt	4-15
Engine Cover	
Latch Release Handle	3-14
Engine Maintenance	4-8
Engine Shut Down	3-18
Engine Speed Control	3-6
Engine Start and Stop	3-16

F

Filling the Fuel Tank	4-11
Flow Control Valve	3-11
Fuel Filter	4-12
Draining Water	4-12
Fuel System	4-11
Filling the Fuel Tank	4-11
Fuel Filter	4-12
Fuel Tank Filling	4-11
Purging Air	4-13
Water Separator	4-13
Fuses	1-8, 4-15

G

General Information	1-1
Grading	3-24

H

Hydraulic Hose Maintenance	4-21
Hydraulic Swivel Unit Brake	3-21
Hydraulic System	4-19
Changing Hydraulic Oil	4-20
Checking Hydraulic Oil Level	4-19
Hydraulic Valve Cover Latch	3-14

I

Ignition Key Switch	3-6
Instrument Panel, Switches and Indicators	3-4

J

Joystick Controls	3-8, 3-21
Joysticks	

Index

Joystick Buttons	3-9	R	
Joystick Controls	3-8	Recommended Lubricants	1-4, 4-7
L		S	
Lifting the Machine	3-30	SAE/ISO Operating Controls	
Load Diagrams	1-13	ISO Operating Controls	3-8
Model 253 Load Diagram	1-13	ISO/SAE Selector Valve	3-7
Model 303 Load Diagram	1-14	SAE Operating Controls	3-8
Model 353 Load Diagram	1-15	Safety	2-1
Model 373 Load Diagram	1-16	ANSI-Style Safety Decal Locations	2-16
Long Term Storage	4-27	Exposure to Crystalline Silica	2-5
Lubricants, Recommended	1-4	Mandatory Safety Shutdown Procedure	2-2
Lubrication	4-6		
M		Seat Belt	3-13
Machine Operation	3-15	Serial Number Location	1-1
Machine Orientation	3-1	Engine Serial Number Location	1-2
Maintenance	4-1	Specifications	1-4
Lubrication	4-6	Fluid Capacities/Lubricants	1-4
Maintenance Safety	4-2	Model 253 Specifications	1-5
Maintenance Schedule	4-3	Model 303 Specifications	1-7
Bucket, Boom and Dozer Blade	4-5	Model 353 Specifications	1-9
Check, Clean and Inspect	4-3	Model 373 Specifications	1-11
Fluid and Filter Changes	4-4	Superstructure Tilt	3-11
Swing Gear Ring	4-5	Swiveling the Boom	3-23
Mandatory Safety Shutdown Procedure	2-2	T	
Mechanical Stop Brake	3-21	Towing	3-30
Mounting/Removing Buckets	3-24	Track System	4-22
N		Changing Final Drive Oil	4-22
New Machine Break-in	3-18	Track Cleaning	4-22
O		Track Tension Adjustment	4-23
Operating Controls	3-1	Transporting	3-30
Operating Instructions	3-21	Travel Controls	3-6
Operating Precautions	3-21	Travel Drive Operation	3-18
Operation	3-1	Traveling on Slopes	3-19
Grading	3-24	Trench Excavating	3-28
Operator's Seat Adjustments	3-12	Troubleshooting	5-1
Optional Joystick Buttons	3-9	U	
P		Using the Excavator	3-27
Pre-Operation Checklist	3-16	V	
Proper Digging Techniques	3-28	V-Belt	
Purge Valve, Air Cleaner	4-10	Checking and Adjusting Tension	4-15
Purging Air from the Fuel System	4-13	Ventilation	3-14

Index

W

Water Operation3-20

Water Separator4-13

Windshield Washer Fluid4-24

Index

TORQUE SPECIFICATIONS

*Note: Use these torque values when tightening **Gehl** hardware (excluding: locknuts and self-tapping, thread forming and sheet metal screws) unless specified otherwise.*

Hydraulic fittings with various seals (light application). All torque values are in lb.-ft. (Nm) unless marked otherwise.

Thread	Straight pipe fitting with thread and screwed plug (GE)			Non-return valve with elastic seal	Identification aid outside Ø
	Sealing washer	Elastic seal	O-ring		
M10X1.0	7 (9)	13 (18)	11 (15)	13 (18)	0.4 in. (10 mm)
M12X1.5	15 (20)	18 (25)	18 (25)	18 (25)	0.5 in. (12 mm)
M14X1.5	26 (35)	33 (45)	26 (35)	26 (35)	0.6 in. (14 mm)
M16X1.5	33 (45)	41 (55)	30 (40)	37 (50)	0.6 in. (16 mm)
M18X1.5	41 (55)	52 (70)	33 (45)	52 (70)	0.7 in. (18 mm)
M22X1.5	48 (65)	92 (125)	44 (60)	92 (125)	0.9 in. (22 mm)
M27X2.0	66 (90)	133 (180)	74 (100)	107 (145)	1.0 in. (27 mm)
M33X2.0	111 (150)	229 (310)	118 (160)	155 (210)	1.3 in. (33 mm)
M42X2.0	177 (240)	332 (450)	155 (210)	266 (360)	1.7 in. (42 mm)
M48X2.0	214 (290)	398 (540)	192 (260)	398 (540)	1.9 in. (48 mm)
G1/8A	7 (9)	13 (18)	11 (15)	13 (18)	0.4 in. (9.73 mm)
G1/4A	26 (35)	26 (35)	22 (30)	26 (35)	0.5 in. (13.16 mm)
G3/8A	33 (45)	52 (70)	33 (45)	37 (50)	0.7 in. (16.66 mm)
G1/2A	48 (65)	66 (90)	41 (55)	48 (65)	0.8 in. (20.96 mm)
G3/4A	66 (90)	133 (180)	74 (100)	103 (140)	1.0 in. (26.44 mm)
G1A	111 (150)	229 (310)	118 (160)	140 (190)	1.3 in. (33.25 mm)
G1 1/4A	177 (240)	332 (450)	155 (210)	266 (360)	1.7 in. (41.91 mm)
G1 1/2A	214 (290)	398 (540)	192 (260)	398 (540)	1.9 in. (47.80 mm)

Hydraulic fittings with various seals (heavy application). All torque values are in lb.-ft. (Nm) unless marked otherwise.

Thread	Straight pipe fitting with thread and screwed plug (GE)			Non-return valve with elastic seal	Identification aid outside Ø
	Sealing washer	Elastic seal	O-ring		
M12X1.5	15 (20)	26 (35)	26 (35)	26 (35)	0.5 in. (12 mm)
M14X1.5	26 (35)	41 (55)	33 (45)	33 (45)	0.6 in. (14 mm)
M16X1.5	33 (45)	52 (70)	41 (55)	41 (55)	0.6 in. (16 mm)
M18X1.5	41 (55)	66 (90)	52 (70)	52 (70)	0.7 in. (18 mm)
M20X1.5	41 (55)	92 (125)	59 (80)	74 (100)	0.8 in. (20 mm)
M22X1.5	48 (65)	100 (135)	74 (100)	92 (125)	0.9 in. (22 mm)
M27X2.0	66 (90)	133 (180)	125 (170)	100 (135)	1.0 in. (27 mm)
M33X2.0	111 (150)	229 (310)	229 (310)	155 (210)	1.3 in. (33 mm)
M42X2.0	177 (240)	332 (450)	243 (330)	266 (360)	1.7 in. (42 mm)
M48X2.0	214 (290)	398 (540)	310 (420)	398 (540)	1.9 in. (48 mm)
G1/8A	26 (35)	41 (55)	33 (45)	33 (45)	0.5 in. (13.16 mm)
G1/4A	33 (45)	59 (80)	44 (60)	44 (60)	0.7 in. (16.66 mm)
G3/8A	48 (65)	85 (115)	55 (75)	74 (100)	0.8 in. (20.96 mm)
G1/2A	66 (90)	133 (180)	125 (170)	107 (145)	1.0 in. (26.44 mm)
G3/4A	111 (150)	229 (310)	229 (310)	192 (260)	1.3 in. (33.25 mm)
G1A	177 (240)	332 (450)	243 (330)	266 (360)	1.7 in. (41.91 mm)
G1 1/4A	214 (290)	398 (540)	310 (420)	398 (540)	1.9 in. (47.80 mm)

With coarse-pitch thread. All torque values are in lb.-ft. (Nm) unless marked otherwise.

Thread	Threads according to DIN 912, DIN 931, DIN 933, etc.			Threads according to DIN 7984	
	8.8	10.9	12.9	8.8	10.9
M5	4.1 (5.5)	6 (8)	7 (10)	4 (5)	5 (7)
M6	7 (10)	10 (14)	13 (17)	6.3 (8.5)	9 (12)
M8	18 (25)	26 (35)	31 (42)	15 (20)	22 (30)
M10	33 (45)	48 (65)	59 (80)	30 (40)	44 (59)
M12	64 (87)	81 (110)	108 (147)	51 (69)	74 (100)
M14	100 (135)	133 (180)	170 (230)	81 (110)	118 (160)
M16	155 (210)	203 (275)	258 (350)	125 (170)	184 (250)
M18	207 (280)	302 (410)	354 (480)	181 (245)	254 (345)
M20	302 (410)	420 (570)	509 (690)	251 (340)	361 (490)
M22	406 (550)	575 (780)	686 (930)	339 (460)	487 (660)
M24	524 (710)	738 (1000)	878 (1190)	435 (590)	620 (840)
M27	767 (1040)	1092 (1480)	1305 (1770)	642 (870)	922 (1250)
M30	1047 (1420)	1482 (2010)	1770 (2400)	885 (1200)	1254 (1700)

With fine-pitch thread. All torque values are in lb.-ft. (Nm) unless marked otherwise.

Thread	Threads according to DIN 912, DIN 931, DIN 933, etc.			Threads according to DIN 7984	
	8.8	10.9	12.9	8.8	10.9
M8X1.0	18 (25)	27 (37)	32 (43)	16 (22)	24 (32)
M10X1.0	37 (50)	55 (75)	65 (88)	32 (43)	48 (65)
M10X1.25	36 (49)	52 (71)	61 (83)	31 (42)	46 (62)
M12X1.25	64 (87)	96 (130)	111 (150)	55 (75)	81 (110)
M12X1.5	61 (83)	92 (125)	107 (145)	53 (72)	77 (105)
M14X1.5	100 (135)	148 (200)	173 (235)	89 (120)	129 (175)
M16X1.5	155 (210)	229 (310)	266 (360)	133 (180)	195 (265)
M18X1.5	232 (315)	332 (450)	391 (530)	199 (270)	284 (385)
M20X1.5	325 (440)	465 (630)	538 (730)	277 (375)	391 (530)
M22X1.5	435 (590)	620 (840)	723 (980)	369 (500)	524 (710)
M24X2.0	546 (740)	789 (1070)	922 (1250)	465 (630)	664 (900)
M27X2.0	811 (1100)	1143 (1550)	1328 (1800)	679 (920)	959 (1300)
M30X2.0	1106 (1500)	1586 (2150)	1844 (2500)	959 (1300)	1364 (1850)



WARNING



**THIS OPERATOR'S MANUAL IS
PROVIDED FOR OPERATOR USE**

**DO NOT REMOVE
FROM THIS MACHINE**

Do not start, operate or work on the machine until you carefully read and thoroughly understand the contents of this Operator's Manual.

Failure to follow safety, operating and maintenance instructions can result in serious injury to the operator or bystanders, poor operation, and costly breakdowns.

If you have any questions on proper operation, adjustment or maintenance of the machine, contact your dealer or the Gehl Company Service Department before starting or continuing operation.

California Proposition 65 Warnings:

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer and birth defects and other reproductive harm.

Battery post, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and birth defects and other reproductive harm. **Wash hands after handling battery.**

GEHL[®]

Manitou Americas, Inc.
P.O. Box 179
West Bend, WI 53095-0179 U.S.A.
www.gehl.com