
Form No. 907398

1438/1448 PowerBox® Self Propelled Paver



OPERATOR'S MANUAL

PowerBox® Indicator & Operation Symbols




Table of Contents

Chapter	Description	Page
	International Symbols	Cover
1	Introduction	1
2	Specifications	4
3	Check Lists	5
4	SAFETY	8
5	Controls, Attachments & Accessories	14
6	Operation & Adjustments	21
7	Lubrication	29
8	Trouble Shooting	31
9	Service & Storage	39
10	Decal Locations	50
11	Maintenance Log	54
	Index	57
	Standard Hardware Torque Data	59
	Schematics	60
	Warranty	Cover

IDENTIFICATION INFORMATION

Write your Gehl PowerBox® Model (1438 or 1448) and Serial Number in the space provided below. Refer to these numbers when inquiring about parts or service from your Gehl dealer.



The Model and Serial Numbers for this machine are on a Decal located on the Backwall.

Chapter 1 I

The information in this Operator's Manual was written to give the owner/operator assistance in preparing, adjusting, maintaining and servicing of the paver. More importantly, this manual provides an operating plan for safe and proper use of the machine. Major points of safe operation are detailed in the **SAFETY** chapter of this manual.

The GEHL Company asks that you read and understand the contents of this manual COMPLETELY and become familiar with your new machine, BEFORE attempting to operate it.

Throughout this manual, information is provided which is set in *italic* type and introduced by the word **NOTE** or **IMPORTANT.** Be sure to read carefully and comply with the message or directive given. Following this information will improve your operating or maintenance efficiency, help you to avoid breakdowns or damage and extend your machine's life. A chart of standard hardware torques is located in the back of this manual.

A plastic container is provided on the unit for storing the Operator's Manual. After using the manual, please return it to the container and keep it with the unit at all times! If this machine is resold, **GEHL** Company recommends that this Manual be given to the new owner.

"Right" and "left" are determined from a position standing on the screed platform and facing forward.


Our wide dealership network stands by to provide you with any assistance you may require, including genuine **GEHL** service parts. All parts should be obtained from **GEHL** dealer. Give complete information about the part and include the model and serial number of your machine. Record the serial number in the space provided on the previous page, as a handy record for quick reference.

GEHL Company reserves the right to make changes or improvements in the design or construction of any part without incurring the obligation to install such changes on any unit previously delivered.


The GEHL Company, in cooperation with the Society of Automotive Engineers, has adopted this


Safety Alert Symbol

to pinpoint characteristics which, if NOT properly followed, can create a safety hazard. When you see this symbol in this manual or on the machine itself, you are reminded to BE ALERT! Your personal safety is involved!



Identification





Chapter 2

SPECIFICATIONS

Paving Performance

Minimum variable paving width: 4 ft (1219 mm)

Standard variable paving width: 8 ft (2438 mm)

Maximum variable paving width: 12 ft (3658 mm)

Minnimum variable paving depth: 0-1/2 in (0-13 mm)

Maximum variable paving depth: 6 in (152.4 mm)

Gravity feed hopper capacity: 4 Ton (3624 kg)

Hydraulic feed augers: Two

Hydraulic material flow gates: Two

Minimum operating speed: 1 FPM (305 mm/min)

Left and right side operator controls: Standard

General Dimensions

Length: 7 ft 4 in (2235 mm)

Maximum width (transport): 8 ft 5 in (2265 mm)

Maximum width (operating): 9 ft 10 in (2997 mm)

Overall height: 7'-9" (2.36 mm)

Weight (tire suspension): 1438: 6440 lb (2917 kg) 1448: 6720 lb (3044 kg)

Weight (track suspension): 1438: 7300 lb (3803 kg) 1448: 7540 lb (3533 kg)

Truck clearance

(Height from ground to hopper floor): 21 in (533 mm)

Screed

Maximum variable crown/invert: 2 in (51 mm)

Width: 13 in (330 mm)

Hydraulic vibrator:

Standard, 67 Hz (4000 c/min).

Heat medium (exhaust): Standard Heat medium (propane): Option Variable hydraulic max. extension lgth: 24 in (610 mm)

Single span operator platform: Standard.

Service Capacities

Engine cooling system, Isuzu - 3LBl:

1438: Not available 1448: 5.3 Qt (5 L)

Engine oil w/filter, Kohler - Command:

1438: 2.1 qt (1.99 L) 1448: Not available Engine oil w/filter, Isuzu 3LB1: 1438: Not available

1448: 4.75 qt (4.79 L)

Hydraulic reservoir: 18 gals (68.1 L) Fuel reservoir: 8 gals (30.3 L)

Washdown tank w/

electric pump: 5 gals (18.9 L)

Engine

1438: Kohler-Command 25 HP (18.7 Kw) Gas: Air-cooled, 12 volt elec. start, 25 amp alternator, 550 CCA battery.

1448: Isuzu - 3LB1 25 HP (18.7 Kw) Diesel: Water-cooled, 12 volt elec. start, 20 amp alternator, 550 CCA battery.

Drive System

Standard: Hydrostatic steel track suspension. Singles-speed, positive/self-adjusting.

Option: Hydrostatic 8-tire suspension: Single-speed and 2-speed option.

Maximum ground speed: Single-speed: 80 FPM (24.4 mm/mim)

Two-speed: 160 FPM (49 mm/mim)

Hydraulic System

Variable hydrostatic drive pump: Maximum flow: 17 GPM (64.4 L/min)

Variable hydrostatic drive pump, Maximum Relief Pressure.

Track system, 2100 psi (14,480 kPa) Tire system, 1800 psi (12,357 kPa)

Hydraulic accessory pump - Max. flow: 8 GPM (30.3 L/min)

Hydraulic accessory pump: Maximum Relief Pressure, 1800 psi (12,411 kPa) Return filter: 5 micron Suction Strainer: 100 micron Aux. oil cooler capacity: 12 GPM (45.4 L/min)

Chapter 3 CHECKLISTS

PRE-DELIVERY

The following Checklist is an important reminder of valuable information and inspections which MUST be made before delivering the Paver to the Customer. Check off each item after prescribed action is taken.

	F
V	Check that:
	NO parts of Paver have been damaged in shipment. Check for such things as dents and loose or missing parts; correct or replace components as required.
	Battery is securely mounted and NOT cracked. Cable connections are tight. Electrolyte at proper level.
	Cylinders, hoses and fittings are NOT damaged, leaking or loosely secured.
	Oil, fuel and air filters are NOT damaged leaking or loosely secured.
	All grease fittings have been properly lubricated and NO fittings are missing; see LUBRICATION chapter of this manual.
	Hydraulic system reservoir, engine crankcase, and engine coolant are filled to the proper operating levels.
	All adjustments have been made to comply with the settings given in this manual and in the separate Engine manual.
	All Guards, Shields and Decals are in place and securely attached.
	Model and Serial Number for this unit is recorded in space provided on this page and page 1.
in	art the Paver and test-run the unit while check- g that proper operation is exhibited by all con- ols.
V	Check that:
	All indicator lamps, meters, etc. function properly.
	Proper operation of all Hopper and Screed Controls.
	Dynamic braking in effect with Drive Motors in neutral.
	No hydraulic system leaks when under pressure.
	Listen for abnormal noises or vibrations; if detected, deter-

mine their cause and repair as necessary.

I acknowledge that pre-delivery procedures were performed on this unit as outlined above.

	Dealership's Name
	Dealer Representative's Name
	Date Checklist filled-out
	Paver Model# Paver Serial # Engine Serial #
	DELIVERY
V	Check that:
able the	e following Checklist is an important reminder of value information that MUST be passed on to the Customer at time the unit is delivered. Check off each item as you lain it to the Customer.
	Review with the Customer the contents of this manual especially:
	The INDEX at the back, for quickly locating topics;
	The SAFETY, INDICATORS/CONTROLS, and OPERATION/ADJUSTMENTS Chapters for information regarding safe use of the machine.
	The LUBRICATION, SERVICE/STORAGE and TROUBLESHOOTING Chapters, for information regarding proper maintenance of the machine. Explain that regular lubrication and maintenance are required for continues afe operation and long life.
	Give this Operator's Manual to the Customer and instructional to the Customer to be sure to read and completely understantists contents BEFORE operating the unit.
	Explain that the Customer MUST consult the Engir Manual (provided) for related specifications, operating adjustments and maintenance instructions.
	Completely fill out the Owner's Registration, including Customer's signature and, return it to the company.

Date Delivered

Customer's Signature

(Dealer's File Copy - Remove at Perforation)

INTENTIONALLY BLANK

(To be removed as Dealer's file copy)

Chapter 3 CHECKLISTS

PRE-DELIVERY

The following Checklist is an important reminder of valuable information and inspections which MUST be made before delivering the Paver to the Customer. Check off each item after prescribed action is taken.

V	Check that:
	NO parts of Paver have been damaged in shipment. Check for such things as dents and loose or missing parts; correct or replace components as required.
	Battery is securely mounted and NOT cracked. Cable connections are tight. Electrolyte at proper level.
	Cylinders, hoses and fittings are NOT damaged, leaking or loosely secured.
	Oil, fuel and air filters are NOT damaged leaking or loosely secured.
	All grease fittings have been properly lubricated and NO fittings are missing; see LUBRICATION chapter of this manual.
	Hydraulic system reservoir, engine crankcase, and engine coolant are filled to the proper operating levels.
	All adjustments have been made to comply with the settings given in this manual and in the separate Engine manual.
	All Guards, Shields and Decals are in place and securely attached.
	Model and Serial Number for this unit is recorded in space provided on this page and page 1.
in	art the Paver and test-run the unit while check- g that proper operation is exhibited by all con- ols.
V	Check that:
	All indicator lamps, meters, etc. function properly.
	Proper operation of all Hopper and Screed Controls.
	Dynamic braking in effect with Drive Motors in neutral.
	No hydraulic system leaks when under pressure.
	Listen for abnormal noises or vibrations; if detected, determine their cause and repair as necessary.

I acknowledge that pre-delivery procedures were performed on this unit as outlined above.

Dealership's Name		
Dea	ller Representative's N	Name
Date Checklist filled-out		
Paver Model#	Paver Serial #	Engine Serial #

DELIVERY

✓ Check that:

The following Checklist is an important reminder of valuable information that MUST be passed on to the Customer at the time the unit is delivered. Check off each item as you explain it to the Customer.

- Review with the Customer the contents of this manual; especially:
- ☐ The INDEX at the back, for quickly locating topics;
- ☐ The SAFETY, INDICATORS/CONTROLS, and OPERA-TION/ADJUSTMENTS Chapters for information regarding safe use of the machine.
- ☐ The LUBRICATION, SERVICE/STORAGE and TROU-BLESHOOTING Chapters, for information regarding proper maintenance of the machine. Explain that regular lubrication and maintenance are required for continued safe operation and long life.
- Give this Operator's Manual to the Customer and instruct the Customer to be sure to read and completely understand its contents BEFORE operating the unit.
- Explain that the Customer MUST consult the Engine Manual (provided) for related specifications, operating adjustments and maintenance instructions.
- Completely fill out the Owner's Registration, including Customer's signature and, return it to the company.

Customer's Signature

Date Delivered

(Pages 5 & 6 have been removed at Perforation)

Chapter 4



SAFETY



The above Safety Alert Symbol means ATTENTION! ALWAYS BE ALERT! YOUR SAFETY IS INVOLVED! It stresses an attitude of "Heads Up for Safety" and can be found throughout this Operator's Manual and the machine itself.

Before you attempt to operate this equipment, read and study the following safety information. In addition, make sure that every individual who operates or works with this equipment, whether family member or employee, is familiar with these safety precautions.

The Gehl Company ALWAYS takes the operator's safety into consideration when designing its machinery and guards exposed moving parts for his/her protection. However, some areas cannot be guarded or shielded in order to assure proper operation. Further, this Operator's Manual, Safety Manual for operating and maintenance personnel and decals on the machine, warn of additional hazards and should be read and observed closely.



DANGER

"DANGER" indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



WARNING

"WARNING" indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION

"CAUTION" indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. Also alerts to unsafe practices.

REMEMBER! It is the owner's responsibility for communicating information on the safe use and proper maintenance of this machine! This includes providing understandable interpretations of these instructions for operators who are not fluent in reading English.

It is the responsibility of the operator to read and understand the Operators Manual and other information provided and use the correct operating procedure. Machines should be operated only by qualified operators.

MANDATORY SAFETY SHUTDOWN PROCEDURE

BEFORE cleaning, adjusting, lubricating or servicing the unit:

- 1. Bring paver to full parking stop on level surface (AVOID park on a slope or hill side, but if necessary, park across the slope and block the tracks).
- 2. Lower the hopper and screed assembly to the "full down" position.
- 3. Place controls in Neutral.
- **4.** Move the throttle to low idle.
- **5.** Shut off the engine and remove the key.

ONLY when you have taken these precautions can you be sure it is safe to proceed. Failure to follow the above procedure, could lead to death or serious bodily injury.





ADDITIONAL SAFETY REMINDERS

- ➡ USER/OPERATOR SAFETY PRACTICES, as established by industry standards, are included in this Operator's manual and intended to promote SAFE OPERATION of the paver. These guidelines do NOT preclude the use of good judgment, care and common sense as may be indicated by the particular jobsite work conditions.
- ☐ It is essential that operators be physically and mentally free of mind altering drugs and chemicals and thoroughly trained in the safe operation of the paver. Such training should be presented completely to all new operators and not condensed for those claiming previous experience. Information on operator training is available from several sources including the manufacturer.
- Some illustrations used in this manual may show doors, guards and shields open or removed for illustration purposes only. BE SURE that all doors, guards and shields are in their proper operating positions BEFORE starting the engine to operate the paver.
- ⇒ ALWAYS wear appropriate personal safety gear called by the job or working conditions. Hard hats, protective glasses, protective shoes, gloves, reflector type vests, respirators and ear protection are examples of types of equipment that may be required. DO NOT wear loose fitting clothing, long hair, jewelry or loose personal items while operating or servicing the machine.
- → ALWAYS maintain safe clearance from electrical power lines and avoid contact with any electrically charged conductor. Contact can result in electrocution. Contact proper local authorities for utility line location BEFORE starting a job.
- **○** ALWAYS check the job site for obstructions and bystanders!

- → ALWAYS start and operate the machine only while standing on the screed platform. DO NOT bypass the machine's neutral-start system. The neutralstart system must be repaired if it malfunctions.
- NEVER use your hands to search for hydraulic fluid leaks. Use a piece of paper or cardboard. Escaping fluid under pressure can be invisible and can penetrate the skin causing serious injury. If any fluid is injected into your skin, see a doctor at once. Injected fluid MUST be surgically removed by a doctor familiar with this type of injury or gangrene may result!
- → ALWAYS keep the screed platform clean. Face the paver backwall when stepping up and down from the platform. DO NOT jump off the paver.
- **○** DO NOT dismount while the paver is in motion.
- → DO NOT attempt to move HOT asphalt mix with your hands or feet. Contact can cause serious skin burns!
- DO NOT allow minors or any unqualified personnel to operate or be near the paver unless properly supervised! DO NOT allow any riders.
- → DO NOT operate the paver in an enclosed area without adequate ventilation! Internal combustion engines deplete the oxygen supply within enclosed spaces and may create a serious hazard unless the oxygen is replaced!
- DO NOT leave the paver unattended with the engine running. ALWAYS lower the hopper to "full down" position, shut off the engine and place all controls in neutral BEFORE leaving the machine!
- Should the paver stall or become disabled on a slope or grade, be sure to follow the mandatory safety shutdown procedure, and block the tracks.





- → ALWAYS position the safety stops when leaving the hopper raised for inspection, cleaning or service!
- **⊃** DO NOT refill the fuel reservoir when the engine is hot. Allow engine to cool down BEFORE refilling to prevent hot engine from igniting the fuel if it should spill or splash!
- **⊃** DO NOT smoke while filling the fuel reservoir, while working on the fuel or hydraulic systems, or while working around the battery!
- DO NOT attempt to loosen or disconnect ANY hydraulic lines, hoses or fittings without first relieving hydraulic circuit pressure. Also, be careful NOT to touch any hydraulic components that have been in recent operation because they can be extremely HOT and can burn you!.
- **⊃** ALWAYS disconnect the battery connection to prevent unintentional starting while working on this machine!
- DO NOT attempt to remove the radiator cap after the engine has reached operating temperature or if it is overheated. At operating temperatures, the engine coolant will be extremely HOT and under pressure. ALWAYS wait for the engine to cool down before attempting to relieve pressure and remove the radiator cap. Failure to heed this warning could result in severe burns!

Screed Propane Heater - General Safety

- 1. This equipment is designed to be used only with propane gas.
- 2. Wrench tighten all fittings.
- 3. NEVER use oil or grease for lubrication.
- 4. DO NOT use oxygen with this equipment.
- 5. Keep cylinder upright at all times.

A WARNING

DO NOT smoke in the area around a Paver equipped with propane burners.

ALWAYS make sure a suitable fire extinguisher is readily available.

ALWAYS light burner with a striker. NEVER use a match.

Burner flame may be invisible in sunlight. DO NOT place burner near your skin or clothing. Severe burns will result.

- 6. Keep equipment free from dirt and oil.
- 7. Use a regulator on supply cylinder.
- 8. Check equipment carefully each time before lighting.
- 9. Always light with a striker, never with matches.
- 10. DO NOT operate in an enclosed area or near flammable material
- 11. Close all valves when not in use.
- 12. Comply with all federal, state and local regulations when operating this equipment.

Modifications, Nameplates, Markings And Capacities

→ Modifications and additions, which affect capacity or safe operation, shall NOT be performed without the manufacturer's prior written approval. Where such authorization is granted, tags or decals shall be changed accordingly.





Protective Guards And Warning Devices


→ The paver is fitted with protective covers over the engine area in accordance with industry standards. They are intended to offer protection to the operator from physical injury. A horn is provided which can be activated from either side of the paver.


Replacement Parts

→ To ensure continued safe operation, replace damaged or worn-out parts with genuine GEHL service parts, BEFORE attempting to operate this equipment.










🏚 WARNING

- BEFORE OPERATING THIS MACHINE READ AND FULLY UNDERSTAND THE OPERATOR'S MANUAL.
- 2. ALWAYS START AND OPERATE THIS MACHINE FROM THE SCREED PLATFORM.
- 3. NO RIDERS ALLOWED.
- 4. NEVER LEAVE SCREED PLATFORM WITH THE ENGINE RUNNING AND DRIVE TRACKS ENGAGED.
- 5. DO NOT RAISE FLOOR AGAINST TRUCK FRAME.
- FAILURE TO OBSERVE WARNING COULD RESULT IN DEATH OR SERIOUS INJURY TO OPERATOR OR BYSTANDERS.

204100







Chapter 5

INDICATORS AND CONTROLS



A CAUTION

Become familiar with and know how to use ALL safety devices and controls on the paver BEFORE attempting to operate it. Know how to stop the machine operation BEFORE attempting to operate it. This paver is designed and intended to be used ONLY with GEHL Company accessories or a GEHL Company approved accessory. The GEHL Company cannot be responsible for operator safety if the paver is used with an unapproved accessory or attachment.

GUARDS AND SHIELDS

Whenever possible and without affecting paver operation, guards and shields are used to protect potentially hazardous areas. In many places, decals are also provided to warn of potential dangers and/or to display special operating procedures.



WARNING

Read and understand ALL safety decals on the paver BEFORE operating it. Do NOT operate the machine unless ALL factory-installed guards and shields are properly secured in place.

CONTROL PANEL

The control panel on the backwall console area contains the following:

Starter Keyswitch

Off Position: When the key is vertical in the key switch, power from the battery is disconnected to the

control and instrument panel electrical circuits. Also, this is the only position in which the key can be inserted or removed from the key switch.

RUN Position: When the key is turned one position clockwise from the vertical (OFF) position, power from the battery is supplied to all Control and Instrument Panel electrical circuits.

Start Position: Turn the keyswitch clockwise two positions from the vertical (OFF) position to activate the engine starter. The keyswitch will return to the RUN position automatically as soon as the engine starts.


NOTE: If the engine requires repeated attempts to start, the key MUST be returned to the OFF position between starting attempts to prevent battery run down.

Pre-Heat Glow Plug Indicator (1448): As an engine starting aid, pre-heating is required in a cold engine starting condition. This pre-heating uses glow plugs which are activated by rotating the keyswitch counterclockwise to the pre-heat position.

Engine Throttle: This controls the engine speed. Idle position is with the cable fully in. Operating position is with the cable 1 to 1-1/2 in. (25-38 mm) out. Release the lock ring, depress the red button on the knob and pull the knob out to set speed. Rotate the knob left or right to fine adjust the speed during operation.


Battery Charge gauge: Indicates the condition of the charging system. During normal operation, the needle should show charge condition.

Coolant Temperature Gauge: Indicates Engine coolant temperature. Under normal operating conditions, this Gauge should indicate approximately 185°F (85°C).



Control Panel

- 1. Choke (1438 only)
- 2. Throttle
- 3. Battery Charge Gauge
- 4. Circuit Breaker (1438 only)
- 5. Keyswitch
- 6. Glow Plug Indicator (1448 only)
- 7. Coolant Temperature Gauge (1448 only)
- 8. Engine Oil Pressure (1448 only)
- 9. Spray Down Pump Switch
- 10. Hourmeter
- 11. Exhaust Diverter



Top Console Indicators, Switches

Engine Oil Pressure (1448 only): This lamp indicates whether sufficient engine lubricating oil pressure is present or not. During normal operation, with the Engine running, this lamp should be off. During starting and when the engine is not running, this lamp will be on

IMPORTANT: If this lamp comes on during normal operation with the engine running, stop the engine immediately. After allowing the oil to drain down for a few minutes, check the engine oil level. Maintain oil level at the FULL mark on the dipstick

Circuit Breaker (1438 only): The 15 Amp Breaker protects electrical circuits. If it is not in the "depressed position", the gauges and indicators on the control panel will not work and the engine will shut off.

In-Line Fuses (1448 only): These are located behind the control panel and protect the engine and gauges and indicators circuits.

Hourmeter: Indicates the operating time of the machine and should be used for keeping up the Maintenance Log chapter of this manual.

Exhaust Diverter (1448 Only): Pull this cable handle OUT to divert the engine exhaust down through the screed. This heats up the screed bottom surface when paving. Push handle IN to divert exhaust out through the muffler.

TOP CONSOLE & LOWER FRAME

Fuel Level Gauge: The gauge needle pointer indicates the amount of fuel remaining in the reservoir.

Horn Buttons: The horn may be activated from a pushbutton on the left side or right side of the console.

Washdown Sprayer System: Sprayer is used periodically each day to wash down parts of the paver which contact asphalt. An asphalt releasing agent is used for this.




DO NOT spray releasing agent on a HOT engine.


Hydraulic Fluid Reservoir: The Access/Fill Plug on top may be removed to check fluid level.

IMPORTANT: Before removing the access/fill plug, allow the fluid to cool for 10-15 minutes. Take a wrench and slowly loosen the hydraulic breather cap on the backwall top console to release system pressure.

Paving Alignment Guide: This is adjustable so the chain will align with a curb or the edge of a previously laid mat of asphalt.



Top Console & Lower Frame Controls/Indicators



Travel Controls

Travel Control Levers

These controls are used to maneuver the paver around on the jobsite or for road travel. Decals on the backwall top console area provide graphic representation of the various control actions. (See illustration).

Hydraulic Pump Variable Speed: This lever increases or decreases power to the drive motors. Push the lever FORWARD to increase speed, pull BACK to decrease speed. Place the lever in neutral when not operating.

Track Travel: These two levers control the track drive motors for forward and rearward movement and also turning of the paver. Both levers are mechanically linked to levers on the right side for control from either side.

NOTE: "Right" and "left" are determined from a position standing behind the unit and facing the direction of forward travel. Pivot the machine at slow speeds only.


Movement of the travel levers and the expected results are as follows: (See travel action illustration)

Move both levers FORWARD to go forward. Move both levers REARWARD to go backwards. Move the left track lever FORWARD to pivot turn right. Move the left track lever REARWARD to pivot turn left.

Move the right track lever FORWARD to pivot turn LEFT. Move the right track lever REARWARD to pivot turn right.

Move both levers in opposite directions to spin the machine about its center position. Returning both levers to "neutral" position stops the drive tracks.

Two-Speed Steering: This control is used only with the rubber tire drive option, and when maneuvering with an empty hopper. Single-speed operation is with the knob in. Pull out for two-speed operation.



Track Travel Action

Hopper Control Levers

These controls are used to position the hopper, gates and activate the augers. Decals on the backwall top console area provide graphic representation of the various control actions. (See illustration)

Hopper Floor: Move lever BACK to raise hopper. Move lever FORWARD to lower hopper. This lever is mechanically linked to a dual control lever on the right side.

Right & Left Flow Gates: These control flow of asphalt out of the hopper. One lever controls each gate. Move lever BACK to open gate. Move lever FORWARD to close gate.

Right & Left Feed Augers: These are used intermittently only with extensions "out". One lever controls each auger. Move lever BACK to turn on auger. Return lever to "neutral" to turn off auger. The right auger lever is mechanically linked to a dual control lever on the right side.

Screed Platform Controls

These controls are used to the screed position and paving action. Decals on the backwall top console area provide graphic representation of the various control actions. (See illustration)

Up & Down Position: Move the Lever BACK to lower Screed so that it floats over asphalt feed forming the finished mat surface. Move the lever FORWARD to raise screed off mat. Make sure the cylinder is fully extended.


Vibrator: This is used to agitate the mat of asphalt passing under the screed. Move the lever BACK to turn the vibrator on. Allow the lever to return to "neutral" to turn off the vibrator.

Left & Right Extensions: These allow adjusting and paving width beyond 9 feet. One lever controls each extension. Move the lever FORWARD to shift the extension inword. Move the lever BACK to shift the extension outward. The right extension lever is mechanically linked to dual control levers on both sides of the machine


Depth Adjustment: The screed has manually operated adjustment screws on each end that are used to set the thickness of the asphalt mat. Turn the screws CLOCK-WISE to increase the depth. Turn the screws COUNTER CLOCKWISE to decrease the depth. A depth indicator on each end shows approximate adjustment setting in inches of mat thickness. These indicator numbers are only used as a reference. Actual mat thickness must be measured with a depth gauge.

Crown Adjustment: This is made with two turnbuckles at the center of the screed platform. Manually turn so screw ends push OUTWARD to decrease the mat crown. Turn opposite so screw ends feed INWARD to decrease the mat invert or valley.


Side Shoe Plate: Loosen wing nuts for adjustment and re-tighten.



Hopper Controls On Backwall Console



Screed Controls On Backwall Console



Adjustments On Screed (Right End Shown)

Screed Propane Heat Kit

To operate the propane heater:

- 1. Check equipment carefully each time before lighting.
- 2. DO NOT operate in enclosed areas or near flammable materials.
- 3. Close the tank valve and the valves on both handles.
- 4. Slowly open tank valve.
- 5. Adjust regulator 15-20 psi (103-138 kPa).
- 6. Remove one burner from the burner tube Support and light with a striker. Place burner back into burner support tube.
- 7. Light the second burner in the same way.

- 8. Re-adjust the regulator to 15-20 psi (103-138 kPa).
- 9. DO NOT leave paver unattended with burners on. If the flame is extinguished quickly close valves. Wait 5 minutes before you re-light burner to allow fumes to dissipate.
- 10. When burners are not in use, close valve on tank, crack and close valves on handles to release gas pressure in hoses.

ACCESSORIES

Gehl offers special accessories such as hopper cut-off and block-off plates, and bolt-on screed extensions. Contact your area Gehl dealer for specifications and ordering information.

NOTE: All accessories are field installed unless otherwise noted. Information and parts for field installing of all of the accessories will be provided by the factory or GEHL paver dealers.

Chapter 6

OPERATION & ADJUSTMENTS

GENERAL INFORMATION



A CAUTION

BEFORE starting the engine and operating the paver, review and comply with all safety recommendations set forth in the SAFETY chapter of this manual. Know how to STOP the paver BEFORE starting it.

ENGINE BREAK-IN

Your new engine does not require extensive "breakin". However, for the first 100 hours of operation, keep the following in mind. Allow the engine to idle for a few minutes after every cold start. DO NOT idle the engine for long periods of time. DO NOT operate the engine at maximum power for long periods of time. Check the oil level frequently and replenish, as necessary.

A special "break-in" oil is not used. The oil in the engine crankcase is the same specified for regular oil changes. Change the oil and replace the oil filter at the intervals specified in the Service chapter. DO NOT add special additives or special "break-in" components to the crankcase.

BEFORE STARTING ENGINE

Before starting the engine and running the paver, refer to the Controls & Accessories chapter and familiarize yourself with the various operating controls, Indicators and safety features.

STARTING THE ENGINE

BEFORE mounting the screed platform, walk completely around the machine to make sure no one is, on, or close to it. Let others near the area know you are going to start up and wait until everyone is clear of the machine.

Place all hydraulic function controls and the hydraulic Pump speed control lever in "neutral" position.

For 1438 Gas Models

- 1. Pull the throttle control 1/4 to 1/2 open.
- 2. Pull choke control to full "out" position (close choke valve) for cold engine starts. If re-starting a warm engine, little or no choking is required..
- 3. Turn the key to START position. When engine starts, release the keyswitch and it will automatically return to the RUN position.
- 4. Gradually return the choke control to full "in" position (open choke valve) as engine warms up and begins to operate smoothly.

For 1448 Diesel Models

- 1. Set the throttle control to 1/3 open.
- 2. Turn the key to the START position. When the engine starts, release the keyswitch and it will automatically return to the RUN position.
- 3. In cold weather starting, first turn the key counterclockwise to activate glow plug. When the indicator lamp comes on, proceed as in Step 2.

NOTE: Crank the starter until the engine starts. If the engine fails to start within 15 seconds, return the key to the "OFF" position, wait 2 minutes, and try to restart the engine. Cranking the engine for longer than 15 seconds will result in premature failure of the starter.

After the above steps proceed as follows:

- 1. Allow a sufficient engine warm-up time before attempting to operate the controls.
- 2. Check that indicators are in normal condition.
- 3. Check the color of the exhaust gas. It should be light blue or colorless.
- 4. Check that there are no fuel, oil or engine coolant leaks, and no abnormal noises or vibrations.



Be SURE the area being used for test-running is clear of spectators and obstructions. Initially operate the paver with an empty hopper.

If the battery becomes discharged and fails to have sufficient power to start the engine, jumper cables can be used to obtain starting assistance. Refer to the jump starting instructions in the Service chapter of this manual for safe jump-start procedure.

FIRST TIME OPERATION

Make sure the engine is warm and then go through the following procedures:

Familiarize yourself with various control levers. Raise the screed. Control the paver travel forward and backward, then make left and right turns using the track control levers. While stopped, lower the screed and activate the vibrator. Divert the exhaust down to the screed. Position the side gates and extensions in and out. Raise and lower the hopper and turn the auger motors on and off

STOPPING THE PAVER

The following procedure is the recommended sequence for stopping the machine:

- 1. Place both track control levers in "neutral."
- 2. Lower the hopper and screed to full "down" positions.
- 3. Place all function control levers in "neutral."
- 4. Move the throttle to "idle" position.
- 5. Turn the keyswitch to "off" position. Always remove the key and take it with you for security reasons.

GENERAL PAVER OPERATION

Walk Around Inspection

- 1. Inspect suction hose. Should be firm, not soft.
- 2. Check for hydraulic leaks.
- 3. Check hopper sides and floor clearance.

WARNING

To prevent a fire or explosion, allow the engine to cool down BEFORE refilling the fuel reservoir. A hot engine could ignite the fuel and burn you. Also, do NOT smoke while refilling the fuel reservoir.

- 4. Inspect the screed.
- 5. Check the safety guards and covers.

Hands-On Check

- 1. Check the fuel gauge. Fill the reservoir before paving and as necessary.
- 2. Check the engine oil level and replenish as necessary.

IMPORTANT: Follow the manufacturer recommendations regarding the use of proper fuel, lubricants and oil.

- 3. Check the cooling air intake on the radiator (1448) and the engine cooling fins (1438).
- 4. Check the air cleaner for cleanliness and make sure that components are tight to prevent intake of unfil-



Clean external surface of tracks with asphalt releasing agent, using the wash down sprayer. DO NOT spray agent Onto tracks immediately before loading or unloading. Wet tracks can slip and lose traction.

tered air.

- 5. Check the hourmeter against fuel filter change schedule in the Maintenance Log of this manual.
- 6. Check the pump speed control lever for full travel movement.
- 7. Clean external area of both tracks (clean 3 to 4 times during working day).
- 8. Check for and remove as necessary, any asphalt



NEVER operate the paver with safety guards or covers removed.

buildup in the screed platform exhaust ports (located to the front and rear of each end).

- 9. Check for and remove as necessary, any asphalt buildup inside the tracks.
- 10. Make a general inspection of the machine for loose bolts and/or components.
- 11. Make sure safety guards and covers are in place.

If the paver is found to be in need of repair or in any way unsafe, or contributes to an unsafe condition, the matter shall be reported immediately to the user's designated authority. The machine shall NOT be operated until it has been restored to a safe operating condition.

PAVING AT THE JOBSITE

The following areas should be "sprayed down" with asphalt releasing agent (use the spray down hose) before paving and four times or more during the work day. These areas should also be cleaned thoroughly after each use of the machine:

Hopper, augers and screed (bottom).

Push rollers.

Hydraulic fluid reservoir.

Asphalt depth adjustment screws.



DO NOT spray tracks before loading or unloading as this could cause loss of traction.

External track and sprockets.

Any part of the machine which contacts asphalt.

With the engine warmed up, proceed as follows:

Positioning The Paver

1. Place throttle in full "open" position and pull out

the exhaust diverter handle. The exhaust will preheat the screed in preparation to lay asphalt material. When operating, the throttle should ALWAYS be at full RPM's. The exhaust can be re-diverted out through the muffler periodically if desired.

- 2. Maneuver the paver into position for laying asphalt with the track control levers.
- 3. With paver in position, move the screed control lever to "down" and hold until the screed lift cylinder is fully extended. This permits the screed to float free. Screed should be lowered onto a starting pad of asphalt or blocks of the desired paving thickness.
- 4. Manually adjust the screed depth control screws up or down, as required, to a neutral or free position. Slowly turn the screws toward the "up" position until a slight amount of tension is felt. The screed is now set to lay asphalt to the approximate thickness of the starting pad or blocks onto which the screed has been lowered
- 5. Move the right and left flow gate control levers to the the "closed" position and hold until both gates are fully closed. Set the alignment guide on each side of the lower front frame.

Filling The Hopper

- 6. Have the dump truck back up to the front of the paver until the truck tires are 1 to 2 in. (25-50 mm) from the push rollers. Then move the paver forward until the push rollers contact the rear tires of the truck. DO NOT raise the screed.
- 7. Move the hopper control lever to the "up" position and hold until the hopper almost touches the frame or dump body of the truck.
- 8. Signal the truck driver to slowly raise the dump body, allowing asphalt to flow from the truck into the hopper. Be prepared to lower the hopper to prevent the truck dump body from striking and damaging the hopper as the truck dump body is raised. Fill the hopper with asphalt.
- 9. Move the flow gate control levers to the "open" position and hold until flow gates are completely open. Asphalt will then gravity feed down to and form a head of asphalt at the leading edge of the screed.
- 10. If the area to be paved is level and pushing the truck is desired, place the hydraulic pump speed control lever forward approximately 1/3. The engine throttle should be set at full power. Signal the driver to

leave the truck in neutral with the dump body raised a sufficient height to allow asphalt to flow slowly but continuously into the hopper.

Laying The Asphalt

- 11. Position the extension control levers to adjust the desired paving width if it is to be more than 8 ft. (2438 mm).
- 12. Move the track control levers to the "forward" position. Continue forward, laying asphalt and pushing the truck approximately 36 to 48 in. (900-1200 mm) If vibration is desired on the screed, move the vibrator control lever to "on" position at approximately the same time the track control levers are moved to the "forward" position.
- 13. Move the track control levers to "neutral" position, stopping the paver. ALWAYS move the vibrator control lever to "off" position when stopping forward motion of the paver. It may be necessary to signal the truck driver to stop, if the truck is moving.

NOTE: The truck should NOT be in gear nor should the driver "ride" the brakes. Always advise the truck driver of the procedure for pushing the truck with the paver.

14. Check thickness/depth of asphalt in the 36 to 48 in. (900-1200 mm) mat and make necessary adjustment using the manual depth adjustment screws. Make adjustments up or down gradually to avoid porpoising effect or ripples in the mat as a result of adjusting too much in either direction. If the base on which the asphalt is being laid is on grade and level, only infrequent adjustments will be required after initial asphalt thickness/depth setting is made.

NOTE: Refer to the Troubleshooting chapter in this manual for paver related, or material delivery and compaction related paving mat application problems.

15. Move the track control levers to "forward" and continue to pave until the truck is empty and the hopper is approximately 50% full.

NOTE: Leave a small head of asphalt at the leading edge of the screed while waiting for the next load of asphalt. If the wait is longer than 10 to 15 minutes, pave 12 to 18 in. (300-450 mm) further and again leave a small head of asphalt. Repeat in 10 to 15 minute intervals using asphalt remaining in the hopper until next load arrives.

If the paver is to be used independently of the dump truck, disregard procedures involving pushing the dump truck for continuous feed while paving (discussed in Steps 10-13) and refer to the following:

- 16. After the hopper is fully loaded, signal the truck driver to lower the dump body, stopping the flow of asphalt to the paver. Simultaneously, the paver operator should move the hopper control lever to the "up" position raising the hopper to avoid asphalt spills from the front of the hopper.
- 17. The paver operator should then signal the truck driver to move forward to the next place to reload the paver. This next reloading place may be directly in front of the paver at a point where the paver operator expects the hopper to be emptied, or another location on the jobsite.

PRECAUTIONS WHILE PAVING

The right side control levers for auger, extension, track and hopper modes allow a two-man operation to avoid making "blind" joints and to reduce cycle time when paving in two directions.

The screed vibrator should be operated ONLY when the paver is moving to avoid undue compaction in the mat when the paver is stopped.

DO NOT raise the hopper against the truck frame or the dump body of the truck.

When pushing a truck on level ground, the truck should NOT be in gear and the truck brakes should NOT be held. The paver will NOT push a truck with the brakes on.

The two independently operated augers need ONLY be used when the extensions are out and then only "off and on". The augers are used ONLY for keeping the extended area fully charged with asphalt.

NOTE: DO NOT leave the augers operating continuously unless required!

If the hopper is loaded and the operator wishes to close the flow gates to transport material to an area inaccessible to the truck, or reposition the paver for the next pass, etc., the following procedure should be employed. ALWAYS lower the hopper as low as possible without spilling asphalt. Close one flow gate and then the other. Lowering the hopper substantially decreases the weight being lifted by each flow gate. Make sure screed extensions are also closed.

DO NOT pull paver with another vehicle except in an emergency situation (loss of hydraulic power or engine failure). The track control levers MUST be locked in the "float" position. Remove the lock lever and place control levers all the way forward. Replace the lock lever. DO NOT pull the paver backwards! DO NOT pull the paver at high speeds

When paving uphill, lower the hopper as needed, placing more weight directly over the tracks to increase traction.



DO NOT attempt to move HOT asphalt mix with your hands or feet. Contact can cause serious skin burns!

Handling Asphalt Spills

NOTE: ALWAYS remove asphalt spill (large or small) from the path of the paver tracks to prevent loose asphalt from getting in the tracks, or building up on the sprockets.

The following procedure should be used if the asphalt truck drives away from the paver when loading or pushing the truck, resulting in a large asphalt spill in front of the paver:

- 1. Stop the paver.
- 2. Lower the hopper as low as possible without spilling more asphalt.
- 3. Close one flow gate and then the other.
- 4. Windrow spilled asphalt material to the center and in front of the paver, making sure the asphalt is removed from the path of the paver tracks.
- 5. Move the track control levers to "forward", continuing to pave with asphalt previously gravity fed from the hopper. As the asphalt head from the hopper begins to run thin, the windrow asphalt should be at the leading edge of the screed. If this is the case, continue to pave using the windrow asphalt, opening both flow gates as the windrow asphalt begins to run thin.

If this is not the case, open both flow gates approximately 1/3, maintaining a full head of asphalt at the

leading edge of the screed until the leading edge strikes the windrow asphalt. Continue to pave.

IMPORTANT: Failure to follow this procedure, in the event of asphalt spills, will result in asphalt buildup and eventual damage to the flow gate cylinders and the tracks.

HIGHWAY TRAVEL

For short distance highway travel, attach a SMV (Slow Moving Vehicle) emblem, purchased locally, to the back of the paver

NOTE: ALWAYS follow ALL state and local regulations regarding the operation of equipment on or across public highways! Also, whenever any appreciable distance exists between jobsites or if operation on public highway is prohibited, BE SURE to transport the paver using a vehicle of appropriate size and weight.

TRANSPORTING BETWEEN JOBSITES

When transporting the paver, know the overall height to allow clearance of obstructions. Remove or tape over the Slow Moving Vehicle (SMV) emblem if it will be visible to traffic.




ALWAYS abide by the following recommended procedures and guidelines, when attempting to use ramps to load the paver onto (or unload it from) a truck or trailer. Failure to heed can result in damage to equipment and a serious personal injury or death!

Tie-down slots are provided on the front of the hydraulic reservoir portion of the frame and the lower rear sides of the backwall. Chains can be inserted through these brackets and slots to secure the paver while transporting.

NOTE: A matched pair of ramps is required.

1. *(See illustration next page)* The ramps MUST be of sufficient strength to support the machine. Whenever possible, the use of strong wood covered steel ramps is recommended as well as some type of center supporting block.



- 2. The ramps MUST be firmly attached to the truck or trailer bed with NO step between the bed and the ramps.
- 3. Incline of ramps MUST be less than 15 degrees (ramp length MUST be at least 16 ft. (5 m) long).
- 4. Ramp width MUST be at least 1-1/2 times the track width.
- 5. Block the front and rear of the tires on the truck or trailer (if so equipped, engage the parking brake).

Unloading With Ramps





WARNING

ALWAYS place the pump speed control lever in "slow" position when operating the paver on the truck bed. ALWAYS unload the paver in "forward."

DO NOT walk beside, behind or in front of the paver during unloading procedures.

- 1. Remove chain binder from tiedown points on the front of the paver.
- 2. Start the engine according to starting procedure in this manual.
- 3. With pump speed control lever in "slow" position and throttle open about 1/4, place the track Control levers in "reverse." The paver will move backwards, releasing tension from the two tiedown chains on the rear of the paver.
- 4. *(See illustration)* Remove the chains from both tiedown points on the rear of the paver.






Tiedown Points Reference

- 5. Move the screed control lever to "up" position and hold until screed is raised completely.
- 6. To avoid bumping the rear edge of the Screed on the bottom of the ramps, turn the depth adjustment screws 7 or 8 turns counterclockwise. (See illustration) This raises the rear edge of the screed approximately 1 in. (25 mm).
- 7. Using the track control levers, align the paver tracks with the ramps. When unloading from the rear, rotate and align the paver tracks. To rotate place one track control lever in "forward" and the other lever in "reverse"
- 8. Move the paver forward to the ramps and stop the paver by placing both track control levers in "neutral" position.



NEVER attempt to adjust travel direction (even slightly) while traveling on the ramps. Instead, back up and onto the truck bed, off of the ramps, and re-align the paver with the ramps.



Screed Adjust For Ramp Unloading

- 9. Move the pump speed control lever to "slow" position. This will prevent the machine from "freewheeling" down the ramps.
- 10. The throttle should be set at 1/2 minumum to full open.
- 11. Clear the area at the bottom of the ramps of all personnel and other obstructions.
- 12. Simultaneously place both track control levers in "forward" position, allowing the Paver to travel to the ground.



The operator should ride on the paver with one hand on both track control levers at all times, to maintain positive control of the paver. Emergency stops are accomplished by placing both track control levers in "neutral" position.

Loading With Ramps

- 1. Move the paver to a position that aligns with the ramps so the paver will be in position to load in reverse. Stop the paver.
- 2. Move the pump speed control lever at 1/3 to 1/2 speed.
- 3. Place the throttle control at full open position.
- 4. Raise the screed to the "full up" position with the screed control lever.
- 5. To avoid bumping the rear edge of the screed on the ramps, turn the depth adjustment screws counterclockwise (7 or 8 turns).
- 6. Fully engage both track control levers rearward, allowing the paver to move slowly up the ramps. The operator should ride on the paver with a hand on both track control levers at all times to stop the paver if travel is not straight.



NEVER attempt to adjust travel direction (even slightly) while traveling on the ramps. Instead, back up and onto the truck bed, off of the ramps, and re-align the paver with the ramps.

DO NOT walk beside, behind or in front of the paver during loading procedures.

ALWAYS place the pump speed control lever in "slow" position when operating the paver on the truck bed. ALWAYS load the paver in "reverse."

Check for and remove oil, grease, fuel or other substance on the ramps that may cause the tracks to lose traction or slip.

DO NOT wash down the paver with asphalt releasing agent just before loading on the vehicle. The paver track may become wet and may slip on the ramps.

- 7. Immediately after the paver is on the vehicle flat bed, STOP the paver.
- 8. Move the pump speed control lever to "slow" position and reduce the throttle to "idle" position.

- 9. Using the track control levers, maneuver the paver on the trailer or truck for best transporting and balanced position.
- 10. Rear loading: After the paver is on the vehicle bed, place one track lever in "forward" and one in "reverse". The machine will rotate to legal width for transport.
- 11. Return the screed to flat position by turning the depth adjustment screws in a clockwise direction (7 or 8 turns).
- 12. Lower the screed and place chains in the two tiedown points at the rear of the paver. Drive the paver forward allowing chains to tighten slightly.
- 13. Place a tiedown chain in the tiedown point on the front of the paver and bind down to the vehicle bed.
- 14. Turn the keyswitch to "off" position and remove the key.

In Transit

If in transit for a few days: (a) Disconnect the battery. (b) Clean all bright surfaces and coat with heavy, very high flash point grease to prevent rusting.

THEFT DETERRENTS

THE CERTAINTY OF APPREHENSION IS A STRONG DETERRENT TO THIEVERY OF CONSTRUCTION EQUIPMENT! GEHL has recorded Part Numbers and Serial Numbers. Users should take as many of the following actions as possible to discourage theft, to aid in the recovery in the event that the machine is stolen, or to reduce vandalism:

- 1. Remove keys from unattended machines.
- 2. Attach, secure, and lock all anti-vandalism and anti-theft devices on the machine.
- 3. Inspect the gates and fences of the equipment storage yard. If possible, keep machines in well lighted areas. Ask the law enforcement agency having jurisdiction to make frequent checks around the storage or work sites, especially at night, during weekends, or on holidays.
- 4. Report the theft to the dealer and insurance company. Provide the model, and all serial numbers.
- 5. Request that your dealer forward this same information to **GEHL** Co.

Chapter 7 LUBRICATION

GENERAL INFORMATION



WARNING

NEVER service this unit when any part of the machine is in motion. ALWAYS BE SURE to exercise the MANDA-TORY SAFETY SHUT-DOWN PROCEDURE (page 8) BEFORE proceeding to lubricate or service this equipment.

NOTE: The Maintenance Log chapter in this manual has provisions for recording the dates and Hourmeter readings after lubrication or other service has been performed; use those spaces to keep a log for maintaining a current service interval record. Proper routine lubrication is an important factor in preventing excessive part wear and early failure.

LUBRICANTS

The following chart lists the locations, temperature ranges and types of recommended lubricants to be used when servicing this machine. Also refer to the separate Engine Manual (provided) for additional information regarding recommended engine lubricants, quantities required and grades.

NOTE: Refer to Operator Services topic in Service/Storage chapter of this manual for detailed information regarding periodical checking and replenishing of lubricants.

IMPORTANT: Always dispose of waste lubricating oils, anti-freeze and hydraulic fluids according to local regulations or take them to a recycling center for disposal. Do NOT pour them onto the ground or into a drain.

Hydraulic System Reservoir



Use SUNVIS 846, or equivalent which contains anti-rust, anti-foam and anti-oxidation additives & conforms to ISO VG46ROAW.

Capacity:

18 Gals. (68 liters)

All Grease Fittings



Use No. 2 Lithium-based Grease

Engine Crankcase Oil



Ambient Temperature	Grade
Below 32 ^o F (0°C)	SAE 10 or 10W-30
32-77°F (0-25°C)	SAE 30 or 10W-30
Above 77°F (25°C)	SAE 40 or 20W-40

Capacity

2.1 Quarts (2 liters) - Gas Engine 4.75 Quarts (4.5 liters) - Diesel Engine

Torque Hubs Gear Oil



Use API-GL-5 80w90 Capacity (each Hub): 17 Fl.oz. (0.50 liter)

Replacement Filters Chart

1448 Diesel Engine

Oil Filter Element Gehl P/N P700113 Fuel Filter Element Gehl P/N 123828

1438 Gas Engine

Oil Filter Element Gehl P/N P700002 In-Line Fuel Filter Gehl P/N P700003

Hydraulic System Filters

Screw-On Filter Element Gehl P/N 074830 Reservoir Sump Strainer Gehl P/N 128299

Air Cleaner

Dry Element (Diesel Eng.)

Dry Element (Gas Eng.)

Pre-Cleaner Ring (Gas Eng.)

Gehl P/N P700004

Gehl P/N P700005

GREASING

Refer to the illustration below for fitting locations. Wipe dirt from the grease fittings before greasing them to prevent contamination. Replace any missing or damaged fittings. To minimize dirt build- up, avoid excessive greasing.

GREASE FITTINGS LOCATION

Every 10 Hours (or daily)


1. Grease Depth Adjustment Screws (2 ea.ch).


Every 40 Hours (or weekly)

2. Grease Track Adjuster Yoke (1 per Track).

Every 500 Hours

3. Grease Pump Speed Control Linkage (2 each.).





Grease Fittings Location

Chapter 8

TROUBLESHOOTING

The following Troubleshooting Guide lists potential problems, as well as possible causes and remedies, for the Gehl paver.

When a problem occurs, don't overlook simple causes. A malfunction could be caused by something as simple as an empty fuel tank. After a mechanical failure has been corrected, be sure to locate the cause of the problem.

IMPORTANT: DO NOT attempt to service or repair major components, unless authorized to do so by your GEHL dealer. Any unauthorized repair will void the Warranty.

GENERAL PAVER PROBLEMS DURING OPERATION

PROBLEM	POSSIBLE CAUSE	REMEDY
Engine operation erratic.	Refer to Engine malfunction.	Refer to engine troubleshooting.
Paver difficult to steer.	One forward/reverse lever not fully engaged.	Engage lever.
NOTE: Normal lead off to one side may be as much as 1 to 2 ft. in (300 to 600 mm) in 100 ft. (30 m) travel under little or no load conditions	Linkage for dual controls binding. Tracks not properly aligned.	Free up linkage. Correct alignment.
Soft or uneven terrain may cause lead off which may be interpreted as steering problems. Actual operating conditions will cause the lead off to change.		
Paver slowing down or excessive power loss.	Engine not running at rated speed.	Check air filter Refer to engine manual.
NOTE: Travel speed (0-80 fpm (0-24 m/min.) single-speed (0-160 fpm (0-49 mm) two-speed	Failure of hydraulic system component (filter, motor, pump, etc.)	Check fuel filter. Refer to hydraulic component(s) troubleshooting.
Hydraulic controls stall to freely or won't operate under a load.	Hydraulic system leaks.	Locate leaks and correct. Repair faulty component. Refer to hydraulic components

GENERAL PAVER PROBLEMS DURING OPERATION (Cont.)

PROBLEM	POSSIBLE CAUSE	REMEDY
Screed not hot enough.	Engine not running at high enough RPM.	Refer to engine troubleshooting.
	Excessive exhaust leakage.	Check for and correct leaks.
	Exhaust ports at end of screed plugged.	Clear ports.
	Outside air too cold/or windy.	Use diverter valve or propane heater.

PAVER RELATED MAT PROBLEMS

PROBLEM	POSSIBLE CAUSE	REMEDY
Wavy surface (ripples).	1. Fluctuating head of materials.	Maintain full head of material.
	2. Finisher speed too fast.	Reduce speed with the fast-slow lever.
	3. Excessive play in screed mechanical connection.	Replace attaching bolts.
	4. Screed riding on lift cylinder.	Lower cylinder completely.
Wavy surface (long waves)	See Causes 1, 3, 4.	
(long waves)	5. Overcorrecting thickness control Screws.	Make more moderate corrections as infrequently as possible.
	6. Running hopper empty between loads.	Stop paver before head of material reaches screed area.
	7. Sitting long period between loads.	Empty hopper completely if waiting period lets asphalt cool.
Tearing of mat (full width)	See Cause 2.	
(tun wiath)	8. Screed plates worn or warped.	Replace wear plate.
	9. Cold screed	a) Check exhaust ports in screed.b) Check for exhaust leaks.
Tearing of mat (center streak)	See Causes 8, 9.	
	10. Too little crown in screed.	Increase lead crown.
Tearing of mat (outside streak)	See Causes 8, 9.	
(outside streak)	11. Too much lead crown in screed.	Decrease lead crown.
	12. Screed extensions installed incorrectly.	Raise extension strike offs.

PAVER RELATED MAT PROBLEMS (Cont.)

PROBLEM	POSSIBLE CAUSE	REMEDY
Mat texture not uniform	See Causes 1, 2, 4, 7-9, 12	
Screed marks	See Cause 3.	
Screed not responding to correction.	See Causes 2-4.	
Poor pre-compaction.	See Cause 2.	
Poor longitudinal joint.	13. Improper joint overlap.	Overlap 2 in. (50 mm) maximum.
Poor transverse joint.	See Cause 3.	
	14. Incorrect nulling of screed.	Increase "pitch" of screed before starting.

MATERIAL-DELIVERY-COMPACTION RELATED MAT PROBLEMS

PROBLEM	POSSIBLE CAUSE	REMEDY
Wavy surface	1. Improper base preparation.	Review base installation.
(short waves - ripples)	2. Improper rolling operation.	Decrease speed.
	3. Improper mix design (aggregate).	See Asphalt Paving Manual.
	4. Improper mix design (asphalt)	See Asphalt Paving Manual.
	5. Mix segregation.	Asphalt plant mixing too long.
	6. Variation of mix temperature.	Asphalt plant burners not heating consistantly.
Wavy surface	See Causes 1, 5, 6	
(long waves)	7. Trucks bumping finisher.	Stop truck short of paver and drive paver to truck.
	8. Truck holding brakes.	Driver must apply only enough so that truck stays "in paver."
	Reversing or turning too fast of rollers	Cycle must be slow but deliberate.
	10. Parking roller on hot mat.	Move to cooler surface before parking. Park at 45° angle.

MATERIAL-DELIVERY-COMPACTION RELATED MAT PROBLEMS (Cont.)

PROBLEM	POSSIBLE CAUSE	REMEDY
Tearing of mat	See Causes 3-7.	
(full width)	11. Improper mat thickness.	Mat thickness must be twice size of. the largest aggregate.
	12. Cold mix temperature	Check with asphalt plant for hotter asphalt mix.
Mat texture (center or outside streaks)	See Cause 12.	
Mat texture (non uniform)	See Causes 1, 3-6, 11, 12.	
Screed marks	See Causes 7, 8.	
Screed not responding to correction	See Causes 6, 11, 12.	
Auger shadows	See Causes 3-5.	
Poor pre-compaction	See Causes 1, 11, 12.	
Poor longitudinal or transverse joint.	See Causes 2, 12.	
Transvers cracking (checking).	See Causes 1-4, 6.	
Mat shoving under Roller.	See Causes 1-4, 6, 9.	
Bleeding or fat spots in mat.	See Cause 3, 4, 6.	
Roller marks.	See Causes 1, 2, 6, 9, 10.	
Poor mix compaction.	See Causes 1-4, 6, 9, 10, 12.	

DRIVE AND MAIN CONTROL VALVES

PROBLEM	POSSIBLE CAUSE	REMEDY
Incapable of maintaining.	Internal oil leak at the spool.	Replace entire valve housing & spool.
the load.	Oil leaking at relief valve port.	Disassemble and clean or replace relief valve.
	Load check poppet or seat damaged (located inside sections).	Replace poppet and seat assembly.
Spool sticking or does NOT move.	Hydraulic oil contaminated.	Drain and replace with fresh oil. Also replace filters.
	Valve clogged with dirt.	Remove dirt and clean assembly.
	Inside of plunger cap filled with oil.	Replace seal on end of cap.
	Foreign matter at spool internal stop.	Remove foreign matter or replace entire valve section & spool assembly.
	Pressure too high	Using pressure gauge, readjust pressure.
	Lever or link bent.	Remove and replace.
	Spool bent.	Replace entire valve assembly.
	Return spring failing.	Replace spring.
	Return spring or cap misaligned.	Loosen, realign and retighten.
	System oil temperature distribution NOT uniform.	Allow sufficient warm-up for entire system.
Oil leaking at seals.	Paint sticking at seal.	Remove and clean the seal.
	Back-pressure in valve.	Replace hydraulic oil filter.
	Dirt in seal.	Remove and clean the seal.
	Seal plate has loosened.	Replace valve housing assembly.
	Seal broken or damaged.	Remove and replace seal.
Controls feel heavy.	Foreign matter in control valve spool.	Clean control valve.
	Valve spool sticking.	Replace entire valve housing.
	Control linkage lacking lubrication. Proper	

HYDRAULIC PUMP AND MOTORS SYSTEM

PROBLEM	POSSIBLE CAUSE	REMEDY
System will not operate in either direction	1. Oil supply low.	Check oil level and fill.
in either direction	2. Oil filters clogged.	Replace filter element.
	3. Oil too heavy.	Use proper viscosity oil.
	4. Control linkage misadjusted.	Check to see if control linkage is binding or unfastened
	5. Low charge pressure	See remedy for Causes 6-9. Pressure should be 300-350 psi (2070-2413 kPa)
	6. Charge pump key sheared	Inspect charge pump for damage and replace key.
	7. Charge pump relief damaged	Remove parts, examine parts and seat. Replace necessary parts.
	8.Charge pump gears worn or scored.	Remove parts and examine. Replace defective parts. If severe scoring is indicated, dissassemble complete assembly, clean and inspect for damage.
	9. Internatal charge pump damage	Dissassemble, inspect for damage.
	10. Relief valve stuck open.	Remove, clean or replace.
	11. Damaged check valve.	Dissassemble and check if valve is faulty or damaged.
System noisy.	12. Air in system.	Low oil level in reservoir.
	13. Loose suction line.	Tighten fittings or lose hose.
	14. Clogged suction filter.	Replace element.
	15. Internal pump or motor damage.	Dissassemble, inspect, repair or replace.
Sluggish response to	See Cause 12.	Also see remedy for Causes 1-3.
acceleration or decceleration.	See Cause 14.	
	16. Low charge pressure.	See remedy for Causes 6, 7, 9.
	17. Relief valve dirty or damaged.	Remove, clean or replace.
Oil leaking from pump or motor.	18. Defective seal.	Replace seal and/or complete assembly.

HYDRAULIC CYLINDERS

PROBLEM	POSSIBLE CAUSE	REMEDY	
Insufficient hydraulic cylinder power	Relief valve pressure setting decreased.	Readjust valve pressure setting.	
	Cylinder internal oil leakage	Replace seals.	
	Cylinder piston or seals defective.	Replace piston or seals.	
	Control valve internal oil leakage. Replace entire valve housing		
Hydraulic cylinder	Cylinder seals defective.	Replace seals.	
external oil leakage	Cylinder rod damaged.	Replace rod.	
Piston does NOT	Oil temperature is abnormally high.	Lower the oil temperature.	
move smoothly.	Air being taken into system.	Replenish oil and retighten suction connections.	
	Seals defective	Replace seals.	

ELECTRICAL SYSTEM

PROBLEM	POSSIBLE CAUSE	REMEDY
Starter will NOT turn.	Keyswitch is in OFF or RUN position.	Turn Keyswitch to START position.
	Speed control not in OFF position.	Move speed control to OFF position.
	Faulty wiring and/or terminations, or Fuse open.	Troubleshoot circuit and repair.
	Faulty Starter switch	Replace.
	Battery NOT adequately charged.	Recharge.
Battery discharges and/ or will NOT recharge.	Terminal or cables are loose or corroded, Battery is defective, and/or Alternator (or Regulator) defective.	Clean terminals and cables and retighten or replace Battery; have dealer check Alternator (or regulator).
	Battery electrolyte level low.	Replenish with distilled water.
	Alternator defective.	Replace or repair.
Operating Horn, etc. does NOT function.	Fuse blown.	Check cause ,correct and/or replace Fuse
Charge Indicator does NOT activate before Engine starts.	Faulty Alternator Battery is NOT sufficiently charged.	Replace. Recharge.

ENGINE

PROBLEM	POSSIBLE CAUSE	REMEDY	
Engine will NOT turn over.	Starter motor defective or faulty wiring connections.	Replace motor and/or repair wiring connections.	
Starter motor has insufficient power to turn engine over.	Battery is run down, starter is defective and/or wiring connections are broken or loose.	Charge battery, repair/replace Starter, and/or tighten connections.	
Engine cranks-over but will NOT start.	Fuel reservoir is empty.	Replenish fuel supply.	
but will NOT start.	Engine crankcase oil is too heavy.	Drain and replace crankcase oil with proper viscosity oil.	
	Engine is cold.	See OEM Engine manual.	
Engine cuts-out abruptly.	Out of fuel	Replenish fuel.	
авгириу.	Fuel filter is clogged and/or air is trapped in the fuel system.	Clean or replace fuel filter and/or de-aerate fuel system.	
Engine runs rough.	Fuel filter is clogged and/or air is trapped in the fuel system.	Clean or replace fuel filter and/or de-aerate fuel system.	
	Air cleaner is clogged.	Clean or replace element.	
Engine overheats.	Cooling fins blocked.	Flush-out dirt, debris.	
	Crankcase oil level too low.	Add oil as required.	
	Exhaust is restricted.	When engine cools, remove restriction.	

Chapter 9

SERVICE & STORAGE

GENERAL INFORMATION



WARNING

BEFORE servicing the paver, or unless expressly instructed to the contrary, exercise the MANDATORY SAFETY SHUTDOWN PROCEDURE (Safety chapter). After service has been performed, BE SURE to restore all guards, shields and covers to their original positions BEFORE resuming paver operation.

NOTE: All Service routines, with the exception of those described under the "Dealer Services" topic are owner-operator responsibilities. All Operator Services described under the hourly subtopics are also referred to on a decal which is located on the engine cover. Refer to the Lubrication chapter of this manual for lubrication information.

This Service chapter details procedures to follow for making routine maintenance checks, adjustments and replacements. The majority of the procedures are also referred to in both the Troubleshooting and Maintenance Log chapters of this manual. For engine related adjustments and servicing procedures, BE SURE to refer to the separate Engine manual provided.

PRECAUTIONS

DO NOT perform any maintenance or repair without the owner's prior authorization. Allow only trained personnel to service the Paver.

WARRANTY repairs can only be done by a GEHL Dealer. He will know what portions of the paver are covered under the terms of the GEHL Warranty and what portions are covered by other vendor OEM warranties.

IMPORTANT: Always dispose of waste lubricating oils, anti-freeze and hydraulic fluids according to local regulations or take them to a recycling center for disposal. DO NOT pour them onto the ground or into a drain.

DEALER SERVICES

The following areas of internal components service replacement and operating adjustments should only be attempted by (or under the direction of) an authorized GEHL paver dealer.

ENGINE COMPONENTS

All service routines, related to the internal components are precise and critical to proper engine operation. Special know-how and tools are required for servicing.

NOTE: If any area of engine is suspected of faulty operation, contact your Gehl paver dealer for further assistance.

HYDRAULIC SYSTEM COMPONENTS

Valves, pumps, motors and cylinders are also sophisticated assemblies which require special know-how and tools for servicing. All cylinders are appropriately designed with particular strokes, diameters, checks and hose connection provisions unique to the paver application requirements. A schematic (located at the end of this chapter) can be used as a guide for troubleshooting and service reference, as required.

Internal service on any of these components should only be attempted by (or under the direction of) an authorized GEHL paver dealer. WARRANTY repairs can only be done by a GEHL dealer. He will know what portions of the paver are covered under the terms of the GEHL Warranty and what portions are covered by other vendor warranties.

ELECTRICAL COMPONENTS

An electrical harness hookup reference diagram is provided (located at the rear of this manual) and can be used as a reference for troubleshooting and service.

OPERATOR SERVICES

Some of the operator-related services will require access to components located inside the superstructure under shields, hoods and covers.

Choose a clean, level work area. Make sure you have sufficient room, clearances, and adequate ventilation. Clean the walking and working surfaces. Remove oil, grease and water to eliminate slippery areas. Utilize sand or oil absorbing compound, as necessary, while servicing the Paver.

Before starting inspection and repair, move the paver onto a level surface, shut down engine, and release all hydraulic pressure. Always lower the hopper to "full down" position. If the area under the hopper requires service, raise the hopper to "full up" and swing up the two safety props. Place all controls in neutral.

Disconnect the battery and remove the ignition key. Remove only guards or covers that provide needed access. Wipe away excess grease and oil.

Excessively worn or damaged parts can fail and cause injury or death. Replace any cracked or damaged part. Care should be taken to assure that all replacement parts are interchangeable with original parts and of equal quality.

Use care not to damage machined and polished surfaces. Clean or replace all damaged or painted over plates and decals that cannot be read.



NEVER leave guards or access covers off when the paver is unattended. Keep bystanders away if access covers are removed.

After servicing, check the work performed, NO parts left over, etc. Install all guards, covers and reconnect the Battery.



DO NOT smoke or allow any open flames in the area while checking and/or servicing hydraulic, battery or fuel systems; all contain flammable liquids or explosive gases which can cause an explosion or fire if ignited.

Wear a face shield when you disassemble spring loaded components or work with battery acid. Wear a helmet or goggles with special lenses when you weld or cut with a torch.

When working beneath a raised machine, always use blocks, jack-stands or other rigid and stable supports. Wear appropriate protective clothing, gloves, shoes. Keep feet, clothing, hands and hair away from moving parts.

Always wear safety glasses or goggles for eye protection from electric arcs from shorts, fluids under pressure, and flying debris or loose material when the engine is running or tools are used for grinding or pounding.

NEVER weld on support frame without the consent of the manufacturer. Special metals may be used which require special welding techniques or have a design which should NOT have welded repairs. NEVER cut or weld on fuel lines or tanks.

If repair welding is ever required, BE SURE to attach the ground (-) cable from the welder as close as possible to the area to be repaired. Also remove battery (+) positive terminal connection before welding.

Daily or 10 Hours

SPRAY DOWN ASPHALT CONTACT AREAS

The following areas should be sprayed with asphalt releasing agent before paving, at least four times during operation, and after each use of the paver.

- 1. Hopper and Augers
- 2. Screed (bottom)
- 3. Push Roller Assembly
- 4. Hydraulic Fluid Reservoir

- 5. Asphalt Depth Adjustment Screws
- 6. Drive Tracks
- 7. Any other part of the machine which contacts asphalt

CHECK FUEL TANK LEVEL

After operation each day, the fuel reservoir should be filled to prevent water from condensing in the reservoir. To fill, remove the filler cap and add fuel.

A drain plug is provided in the bottom of the reservoir for removing condensation and other foreign materials periodically. Open the plug and allow water and fuel to drain into a container until only clear fuel is flowing from the reservoir.

CHECK FUEL FILTER

NOTE: The fuel filter will require occasional replacement to maintain a clean and adequate fuel flow for maximum engine horsepower. The frequency of filter replacement will be determined by the cleanliness of available fuel, the care used in storing fuel supplies and the operating conditions in which the paver is used.

Small amounts of water can be drained from the 1448 diesel engine fuel filter. The drain petcock should be loosened weekly to drain off water accumulation until clear fuel is flowing from the outlet.

CHECK ENGINE OIL LEVEL

With the paver on level ground, and the engine stopped for ten (10) minutes or more, remove the engine dipstick. Wipe it clean, re-insert it and remove to obtain a reading. If the oil level is down, or below the ADD mark, fill with the required amount of oil to bring the level to the FULL mark. See the Lubricants chapter for the type of oil to use.

CHECK RADIATOR COOLANT LEVEL (1448 Models)

With the paver on level ground, remove the radiator cap. Add clean engine coolant mixture of 50/50 water and Anti-Freeze if the coolant level is below the filler neck. Replace the radiator cap securely.

IMPORTANT: If the engine is operated with a loose radiator cap, the pressure bypass will NOT work and the engine will run HOT.




DO NOT remove the radiator cap when the engine is running HOT, or overheated. Coolant is extremely HOT and under pressure and it can burn your skin. Allow sufficient time for the radiator and hydraulic oil cooler to cool BEFORE relieving the pressure and removing the radiator cap.

CHECK ENGINE AIR INTAKE SCREEN & COOLING FINS (Model 1438)

Remove the top engine cover for full access. Remove any debris from the screen and fins area.

CHECK AIR FILTER ELEMENT

1438 Models: Remove the outer cover and hold down plate. Inspect the foam ring pre-cleaner for holes or clogging. Replace plate and cover.




Air Cleaner Components (1438)

1448 Models: Remove the end cap. Empty out any dust accumulation and wipe inside clean. The element should NOT be removed except at normal replacement schedule. Check the inlet cap and clean out any debris.

CHECK INSTRUMENTS OPERATION

Allow the engine to warm up for about five minutes before beginning operation. Indicator lamps should be OFF and gauges should register normal readings.



Air Cleaner Components (1448)

CHECK GENERAL MACHINE OPERATION & CONDITION

Are any decals missing or damaged? Are all guards, shields and covers in place? Do all controls function smoothly and properly? Are there any abnormal vibrations or noises? Are any hoses or fitting connections leaking? Is the engine exhaust color normal (light blue or colorless)?

CHECK FAN BELT (1448)

If the belt shows wear or cuts, it should be replaced. Order replacement belt from your engine dealer. Refer to the Engine manual relative to proper belt replacement and tension adjustment procedures.

LUBRICATE DAILY GREASE POINTS

Refer to the Lubrication chapter of this manual for daily grease fitting locations and other related details.

Weekly or 40 Hours

NOTE: The following service checks should be done at the beginning of each working week and in full conjunction with Dally Service.

CHECK HYDRAULIC OIL LEVEL

The fluid MUST be cool when checking the reservoir level, or changing the filter. By doing this, you will reduce the possibility of overfilling the hydraulic system, and also reduce potential injury due to hot fluid.



ALWAYS protect face and eyes whenever a pressure plug or cap is removed. NEVER assume that no pressure exists in a pressure vessel or system.

Before removing the fill plug, release pressure in the hydraulic system by allowing pressure to bleed-off when loosening the fill plug. This can also be done by loosening the breather cap on top of the backwall console.

NOTE: Be careful when removing the reservoir filler cap so that NO dirt or other foreign matter enters the hydraulic system while the Cap is removed. DO NOT OVERFILL.

See the Lubricants chapter of this manual for recommended hydraulic oils.

CHECK BATTERY FLUID & CABLES

Check cables for corrosion or loose connection. Check to see if fluid level is full in each cell.

NOTE: The battery on the paver is warranted by the supplier. See the punch tag on the top of the battery for warranty information.

Handling Battery Safely

The top of the battery MUST always be kept clean. Clean the battery with a brush dipped in an alkaline solution (ammonia or baking soda and water). After the foaming has stopped, flush the top of the battery with clean water. If the terminals and cable connection clamps are corroded or have a buildup, disconnect the cables and clean the terminals and clamps with the same alkaline solution.

Jump Starting

If the paver battery becomes discharged or does NOT have enough power to start the engine, use jumper cables and the following procedure to jump-start the paver engine.

NOTE: BE SURE that the jumper battery is also a 12 volt D. C. battery.

1. Turn the keyswitches on both vehicles to OFF. Make sure that both vehicles are in "Neutral" and NOT touching.

WARNING

Explosive gas is produced while a battery is in use or being charged. Keep flames or sparks away from the battery area. Make sure battery is charged in a well-ventilated area.

NEVER lay a metal object on top of a battery as a short circuit can result.

Battery acid is harmful on contact with skin or fabrics. If acid spills, follow these first aid tips:

- 1. IMMEDIATELY remove any clothing on which acid spills.
- 2. If acid contacts the skin, rinse the affected area with running water for 10 to 15 minutes.
- If acid comes in contact with the eyes, flood the eyes with ruinning water for 10 to 15 minutes. See a doctor at once. NEVER use any medication or eye drops unless prescribed by the doctor.
- 4. To neutralize acid spilled on the floor, use one of the following mixtures:
 - a. 1 Pound (0.5 kg) of baking soda in 1 U.S. Gallon (4 liters) of water.
 - b. 1 Pint (0.4 liters) of household ammonia in 1 U.S. Gallon (4 liters) of water.

Whenever battery is removed from the unit, BE SURE to disconnect the negative (-) battery terminal connection cable first.

- 2. Remove the battery filler caps and make sure that electrolyte solution is up to the proper level. In addition, place a clean cloth over the uncapped filler holes to prevent the electrolyte solution from overflowing.
- 3. Connect one end of the positive (+) Jumper Cable to the positive (+) battery terminal on the disabled vehicle first. DO NOT allow the jumper's positive (+) cable clamps to touch any metal other than the positive (+) battery terminals. Connect the other end of the positive jumper cable to the jumper battery positive (+) terminal.
- 4. Connect one end of the negative (-) jumper cable to the jumper battery negative (-) terminal.



The ONLY safe method for jump-starting a discharged battery is for TWO PEOPLE to carry-out the following process. The second person is needed for removing the jumper cables so that the operator does NOT have to leave the operator's compartment while the engine is running. NEVER attempt to make the jumper cable connections directly to the starter solenoid of either engine. Start the engine ONLY after making sure ALL controls are in "neutral".

Closely follow the jump-start procedures, in the order listed, to avoid personal injury. In addition, wear safety glasses to protect your eyes, and avoid leaning over the batteries while jump-starting.

DO NOT attempt to jump-start the paver if the battery is frozen as this may cause it to rupture or explode.

5. Make the final negative (-) jumper cable connection to the disabled paver's engine block or frame (ground) - NOT to the disabled battery negative post. If making the connection to the engine, keep the jumper clamp away from the battery, fuel lines, or moving parts.

NOTE: Twist the jumper cable clamps a couple of time on the battery terminals to insure a good electrical path for conducting current.

- 6. Start the paver. If it does not start immediately, start the jumper vehicle engine to avoid excessive drain on the booster battery.
- 7. After the paver is started and running smoothly, have the second person remove the jumper cables (negative (-) jumper cable, first) from the jumper vehicle battery, and then from the disabled paver while making sure NOT to short the two cables together.

Allow sufficient time for the paver alternator to buildup a charge in the battery before attempting to operate the machine or shut the engine off. BE SURE to discard the cloths and reinstall the vent caps removed in Step 2, above. **NOTE:** If the battery frequently becomes discharged, have the battery checked for possible dead cell(s) or troubleshoot the entire electrical system for possible short circuits or damaged wire insulation.

LUBRICATE WEEKLY GREASE POINTS

NOTE: Weekly lube is to be done in conjunction with daily lube requirements of this chapter.

CLEAN AIR PRE-CLEANER - 1438

An oil-foam pre-cleaner surrounds the paper element. This should be removed, washed and re-oiled per instructions in the Engine Manual.

Service Every 100 Hours

NOTE: Perform all other service requirements up to this point as well as the following.

HYDRAULIC FILTERS

Remove both elements and discard (see illustration). Wipe the sealing surface on the mount head with a clean cloth. Apply a thin coat of clean oil to the new oil filter gasket. Spin tighten.




Hydraulic fluid is HOT during operation. Allow to cool before relieving system pressure by loosening breather cap on top of the backwall console.

CHANGE AIR CLEANER ELEMENT-1438

(See illustration under "Checking Air Filter"). Completely wipe the outside of the air cleaner cover or body with a rag or cloth. Blow off excess dirt and dust with compressed air.

Remove the outer cover. Remove the high density paper element and replace per instructions in the Engine manual.



Hydraulic Filter Components

CHECK SCREED BOTTOM PLATE

The bottom plate of the screed should be inspected for possible wear.

Service Every 250 Hours

NOTE: Perform all other service requirements up to this point as well as the following.

CHANGE AIR CLEANER ELEMENT - 1448

(See illustration under "Checking Air Filter"). Completely wipe the outside of the air cleaner body with a rag or cloth. Blow off excess dirt and dust with compressed air. Disassemble as follows:

IMPORTANT: NEVER use an element that is damaged. Severe engine wear and eventual failure can rresult if dirt gets through a hole in the element.

- 1. Loosen the clamp ring and remove the end cap. Wipe the inside and baffle completely clean.
- 2. Remove the element wing bolt. Gently slide out the element. Check for uneven dirt patterns on the old element. If they exist, the lack of a firm seal or a dust leak exists. Make certain the cause is identified and rectified before replacing.
- 3. Use a clean, damp cloth to carefully clean the inside surfaces of the housing. Make sure any hardened dirt ridges around the gasket sealing surface are completely removed.

4. Inspect the new element for shipping damage. Slide it into the housing until the sealing gasket is seating evenly for a positive seal. Reassemble the end cap. Make sure the large o-ring is in place between the Cap and and the housing.

Install the element and reassemble the air cleaner. Make sure the large o-ring is in place between the end cap and the main body.

CHANGE ENGINE OIL

Change the engine oil using the following procedure:

1. With the engine warm, remove the crankcase drain plug. Some plugs are equipped with a magnet to gather metal particles. Completely clean and flush away all metallic filings from the plug and re-install it.

NOTE: DO NOT discharge onto ground. Catch and dispose of per local waste disposal regulations.

2. After new oil has been added, run the engine at idle speed until the oil pressure light is OFF (1448 models). Check for leaks at the drain plug. Re-tighten only as much as necessary to eliminate leakage.

CHECK TORQUE HUBS OIL LEVEL

With the hopper raised, position the track so the Check plug is in "3 or 9 o'clock" position. Plug is located on the side opposite the drive motor. Loosen plug. If oil appears, re-tighten as level is sufficient.

LUBRICATE 250 HOUR GREASE POINTS

NOTE: This lube is to be done in conjunction with previous lube requirements of this chapter.

Service Every Season or 500 Hours

CHANGE ENGINE OIL FILTER

The engine oil filter should be changed at every other oil change interval. Remove and discard the throw away filter canister. Wipe the gasket and sealing area of the block with a clean cloth.

NOTE: Use only genuine OEM engine replacement filters.

Apply a thin coat of clean oil to the new oil filter gasket. Spin tighten. Refill the crankcase with new oil. Follow specifications in the Lubrication chapter for type and viscosity of new oil to put in.


CHANGE FUEL FILTER

(See illustration). The frequency of filter replacement will be determined by the cleanliness of available fuel, the care used in storing fuel supplies and the operating conditions in which the paver is used.

NOTE: For proper replacement procedures refer to the engine manual for your machine.

Gas Engine Filters - 1438

The gas engine has a in-line filter just off the fuel reservoir. To replace it, loosen the hose line clamps and discard the old filter. Install a new filter with the "arrow" pointing toward the direction of flow. Check connections for leaks.



Fuel Filters Reference



NEVER service the fuel system while smoking, while near an open flame, or after the engine has been operated and is hot.



CAUTION

Escaping diesel fuel under pressure can have sufficient force to penetrate the skin. Before applying pressure to the fuel system, BE SURE all connections are tight and lines and hoses are NOT damaged. Use a piece of wood or cardboard to search for suspected leaks. If injured by escaping fuel, see a doctor familiar with this type of injury at once or gangrene may result.

Diesel Engine Filter - 1448

The diesel engine has a "screw-on" canister filter attached to the fuel reservoir, and a remote fuel pump mounted on the engine mount bracket. Unscrew the canister element and replace with a new one. Lightly oil the rubber gasket on the top of the filter before installing.

Fuel Bleeding Procedures

When the fuel filter is removed and replaced, or the engine runs out of fuel, air MUST be bled from the system. Refer to the Engine manual relative to proper bleeding procedures.

If the engine still will NOT start, consult your nearest authorized engine dealer.

CHECK FUEL INJECTION SYSTEM - 1448

Whenever a faulty or plugged pump or injector is indicated, refer to the OEM Engine manual.

NOTE: Only an authorized engine dealer can perform WARRANTY Service on the engine.

CHANGE RADIATOR COOLANT - 1448

Drain, flush and refill the cooling system as follows:



Remove the radiator cap only when the engine is cool, or painful burns could result.

- 1. Loosen the radiator cap to it's stop. This will release any system pressure. Remove the cap when all pressure is bled off.
- 2. Open the radiator drain cock. Remove the water jacket drain plug from the engine block. When all coolant is drained, flush the system with clean fresh water. Allow the flush to drain completely.

IMPORTANT: DO NOT discharge onto ground. Catch and dispose of per local waste disposal regulations.

- 3. Replace all drain Plugs and tighten the radiator drain cock. Clean out the cooling fins in the Radiator with water pressure or steam.
- 4. Open the bleed valve on top of the radiator. Fill the radiator until a steady stream runs out of the bleed valve.

NOTE: When cold weather is expected, fill the cooling system with a 50-50% mixture of water and ethylene glycol Anti-Freeze. When temperatures are above freezing, water only may be used. Add a summer coolant conditioner to the water to prevent rust and to lubricate the water pump.

5. Close the valve and inspect the radiator cap seal before installing it. Replace it if it appears defective. The pressure cap and engine Thermostat work in conjunction with each other to maintain proper Engine cooling.

NOTE: Check the water temperature gauge, every minute or two, after coolant has been changed. Air pockets can form. It may be necessary to refill the cooling system after a short period of use, as the air will naturally bleed out of the system.

CHECK EXHAUST SYSTEM

The exhaust provides heating for the Screed surface contacting the asphalt mat, when diverted to that area. Make sure there are no leaks or loose connections.

Service Every 2000 Hours

NOTE: Perform all other service requirements up to this point as well as the following.

REPLACE HYDRAULIC FLUID & STRAINER

Clean all dirt and debris off the area where the hydraulic system suction (large) hose connects to the inside wall of the hydraulic reservoir.

1. Remove the drain plug from the bottom of the reservoir. Allow all the oil to drain out.

IMPORTANT: DO NOT discharge onto ground. Catch and dispose of per local waste disposal regulations.

- 2. Disconnect the suction hose and remove to sump strainer from inside the reservoir. Inspect the strainer. If it shows any damage, holes, etc. it should be replaced. Otherwise wash it clean with an industrial solvent, dry with a rag and coat with fresh hydraulic oil. Install the strainer and reconnect the hose.
- 3. Flush out the bottom of the reservoir with clean hydraulic oil and wipe out any debris. Re-install the strainer, drain plug and reconnect the suction hose.
- 4. Fill the Reservoir with fresh hydraulic oil. Follow specifications found in the Lubrication chapter of this manual.

NOTE: Hydraulic fluid and filters should be replaced anytime contamination is present before the normally scheduled change.

CHECK ENGINE COMPRESSION

Refer to OEM Engine manual.

NOTE: Only an authorized OEM Engine dealer can perform WARRANTY Service on the engine.

CHECK REPLACE SPARK PLUGS - 1438

Check periodically. Refer to OEM Engine manual for replacement procedure.

LUBRICATE 2000 HOUR GREASE POINTS

NOTE: This lube is to be done in conjunction with previous lube requirements of this chapter.

Refer to the Lubrication chapter of this manual for 2000 hour grease point locations and other related details

As Required Pressure Checks

TRACK HYDRAULIC PRESSURE ADJUSTMENT

(Refer to the illustration) Hydraulic pressure on the front idler hub is achieved from an adjustable relief valve located on a backwall plate just behind the screed lift cylinder. The pressure must be maintained between 300 psi (2068 kPa) minimum and 350 psi (2413 kPa) maximum, while oil is at normal operating temperature.


If the tracks are not adjusting corrrectly, it may be necessary to check this pressure. Examples of correction would be if the tracking path veers left or right, or the track tension acts loose. Install a 0-500 psi (3448 kPa) gauge into the test port "B". The relief valve connects hydraulically on the return side of the 9-stack main valve. Increase the pressure as follows:

- 1. Remove the cap on the of the relief valve and losen the jam nut.
- 2. Increase the pressure by turning the allen screw clockwise.
- 3. The engine must be running and at minimum 1/2 throttle.
- 4. When pressure is corrected, tighten jam nut, replace cap and remove gauge from the test port.

NOTE: Tracks are NOT adjusted if engine is NOT running.

AUGERS, SCREED FUNCTION PRESSURE CHECK

Test Port "C" located down near the pump should be used to check pressures related to the following: slow auger movement or premature shutoff, and screed or hopper functions



Hydraulic Pressure Test Ports

Install a 0-3000 psi (20,685 kPa) gauge. Bottom out any screed or hopper action cylinder. Gauge reading should be 1800 psi (12,411 kPa) to 2150 psi (14,824 kPa). If not, factory set relief in 9-stack valve may require replacement.

HOLD ON GRADE PRESSURE CHECK

Test Port "A" on the top console should be used to check driving mode.

Install a 0-1500 psi (10,343 kPa) gauge. Hold left track stationary and run right track forward or back. Record pressure. Hold right track stationary and run left track. Record pressure. If the highest pressure is about 50-100 psi (345-690 kPa) greater on one track, the problem is with that track. The suspect track hydraulic motor must be removed to determine if the elevated pressure is due to a hydraulic or mechanical condition.

STORAGE

If the paver will not be operated for a long period of time, prepare and store it using the procedures as follows.

BEFORE STORAGE

Perform the following prior to placing the paver in storage:

- 1. Wash off the entire machine.
- 2. Lubricate ALL grease points as described in the Lubrication chapter of this manual.
- 3. Change engine oil as outlined in the Service chapter of this manual.
- 4. Apply grease to all exposed hydraulic cylinder rod areas.
- 5. Disconnect the battery cable clamps and cover the battery or remove the battery from the paver and store it separately.
- 6. For 1448 Diesel Engine only. If the ambient temperature (at anytime during the storage period) is expected to drop below freezing, make sure the engine coolant is either completely drained from the radiator and engine block or that the amount of anti-freeze in it is adequate to keep the coolant from freezing. Refer to the separate engine manual provided for anti-freeze recommendations and quantities.

DURING STORAGE

- 1. About once each month, connect the battery and check ALL fluid levels to make sure they are at the proper level BEFORE starting the engine.
- 2. Start the engine and allow it to run until it warms up and then move the machine a short distance to help relubricate the internal parts. Run the engine until the battery has a chance to recharge and then shut it off.

NOTE: If it is desired to operate the hydraulic cylinders at this time, BE SURE to wipe the protective grease (and any adhering dirt) from the cylinder rods prior to starting the engine. After operating, BE SURE to recoat the cylinder rods with grease if the paver is going to be returned to storage.

AFTER STORAGE

After removing the paver from storage and BEFORE operating it, perform the following:

- 1. Change engine oil and filter to remove condensation or other residuals.
- 2. Wipe off grease from cylinder rods.
- 3. Lubricate ALL grease fittings.
- 4. Review and refamiliarize yourself with all safety precautions as outlined in the Safety chapter of this manual.
- 5. Follow the starting and warm-up procedures as outlined in the Operation chapter of this manual.

Chapter 10

DECAL LOCATIONS

GENERAL INFORMATION



CAUTION

ALWAYS read and follow the safety precautions on decals. If any decals become damaged or unreadable, or if the unit is repainted, the decals MUST be replaced. If repainting, MAKE SURE that ALL decals which apply to the machine are affixed in their proper locations.

Decal locations information is provided to assist in the proper selection and application of new decals, in the event the original decal(s) become(s) damaged or the machine is repainted.

For correct replacement of decal(s) compare the location illustrations to your machine BEFORE starting to refinish the unit. Check-off each required decal using the illustration reference number to find the part number, description and quantity in the list. Refer to the appropriate illustration(s) for replacement location(s).

NEW DECAL APPLICATION

Before applying the new decals, surfaces MUST be free from dirt, dust, grease and other foreign material. To apply a solid-formed decal, remove the smaller portion of the decal backing paper and apply this part of the exposed adhesive backing to the clean surface while maintaining proper position and alignment. Slowly peel off the other portion of the backing paper while applying hand pressure to smooth-out decal surface. To apply a die-cut decal, first remove the backing paper. Then, properly orient and position the decal onto the clean mounting surface. After the decal is firmly applied and smoothly pressed down, remove the front covering paper.

PAINT FINISH


Use this list to order paint for refinishing:

906213	One Gal. Yellow
906317	One Gal. Charcoal Grey
906323	One Qt. Charcoal Grey
906214	6 (12 oz. Spray Cans) Yellow
906318	6 (12 oz. Spray Cans) Charcoal Grey
L98622	1 (12 oz. Spray Can) Yellow
L98623	1 (12 oz. Spray Can) Charcoal Grey

COMPLETE DECAL KITS

P700528	Model 1438
P700529	Model 1448

NOTE: Decals can also be ordered individually.




DECAL LIST - LOWER FRAME, HOPPER & SCREED AREAS

REF. NO.	DESCRIPTION	1438	1448
1	0-6 Thickness Indicator (2 ea.)	P201400	P201400
2	Up/Down Screed (2 ea.)	P214000	P214000
3	Hydraulic Fluid (1 ea.)	P471425	P471425
4	PB Logo (2 ea.) P470323 P470		P470323
5	WARNING - Pinch Point (3 ea.)	L65927	L65927
6	Floor Safety Prop (2 ea.)	P210200	P210200
7	PowerBox Lettering (2 ea.)	P204030	P204030
8	Model Number - 1438 (2 ea.)	P470322	
8	Model Number - 1448 (2 ea.) P4708		P470852
9	GEHL Lettering 3.38" (2 ea.)	L82282	L82282

DECAL LIST - BACKWALL AREA

REF. NO.	DESCRIPTION	1438	1448
1	Fast/Slow Control (1 ea.)	P204015	P204015
2	Hydraulic Oil Under Pressure (1 ea.)	P471310	P471310
3	Diesel Fuel Only (1 ea.)		072797
3	Gas Fuel Only (1 ea.)	P205200	
4	Operator Manual Inside (1 ea.)	L65922	L65922
5	Anti-Freeze (1 ea.)		056859
6	RH 5-Position Controls (1 ea.)	P204013	P204013
7	Coolant Under Pressure (1 ea.)		072798
8	Horn Button (2 ea.)	P204107	P204107
9	Drive Control w/Float (1 ea.)	P212750	P212750
10	WARNING - Load/Unload (1 ea.)	P204113	P204113
11	Operator Instructions (1 ea.)	P277594	P277594
12	WARNING - Operator (1 ea.)	P204100	P204100
13	Auger Control (1 ea.)	P471640	P471640
14	LH 9-Stack Controls (1 ea.)		P204012
15	DANGER - Rotate Components (1 ea.) L65924 L65924		L65924
16	WARNING - Pinch Point (1 ea. side) L65927		L65927
17	WARNING - Jump Start (1 ea.) L65933		L65933
18	WARNING - Hot Surface (1 ea.)	L65942	L65942
19	Made In USA (2 ea.)	122719	122719
20	1448 Engine Maintenance Chart (1 ea.)		P471027
21	1438 Engine Maintenance Chart (1 ea.)	P471026	
22	, ,		P471875
23	Asphalt Releasing Agent Only (1 ea.) P471816 P47		P471816
24			P20414
25	Radiator Valve (1 ea.) P47		P470960
26			P471025
27	Test Ports (1 ea.)	P471482	P471482



Chapter 11 MAINTENANCE

This maintenance interval chart was developed to match the Service chapter of this manual. Detailed information on each service procedure may be found in the Service chapter. A Maintenance Log follow the interval chart for recording the maintenance procedures performed. Recording the 10 Hour (or Daily) service intervals would be impractical and is therefore not recommended.

NOTE: Under extreme operating conditions more frequent service than the recommended intervals may be required. You must decide if your actual operation requires more frequent service based on your use.

MAINTENANCE INTERVAL CHART

SERVICE PROCEDURE	Every 10 Hours (or Daily	Every 40 Hours (or Weekly)	Every 100 Hours
Check Fuel Tank Level	•		
Check Fuel Filter	•		
Check Engine Oil	•		
Check Air Intake Screen/Coolant Fins (1438)	•		
Check Radiator Coolant Level (1448)	•		
Check Fan Belt Tension (1448)	•		
Check Instruments Operation	•		
Check General Machine Operation & Condition	•		
Check Air Cleaner Dust Cap (1448)	•		
Lubricate Appropriate Grease Points	•	•	
Change Engine Oil & Filter - initial 50 hours, New Machines			•
Check Hydraulic Oil Level		•	
Check Battery		•	
Clean Air Cleaner Pre-Cleaner Ring (1438)		•	
Change Engine Oil (1438)			•
Check Screed Bottom Plate Wear			•
Change Hydraulic Filter Elements			•
Change Air Cleaner Element (1438)			•

MAINTENANCE INTERVAL CHART (CONT.)

SERVICE PROCEDURE	Every 250 Hours	Every 500 Hours	Every 2000 Hours
Change Air Cleaner Element	•		
Change Engine Oil (1448)	•		
Check Torque Hubs Oil Level	•		
Lubricate Appropriate Grease Points	•	•	•
Change Engine Oil Filter Element (1438)	• (200 Hrs.)		
Change Radiator Coolant (1448)		•	
Check Exhaust System		•	
Change Fuel filter		•	
Inspect Fuel Injection System (1448)		•	
Check/Replace Spark Plugs (1438)			•
Change Hydraulic Reservoir Oil & Sump Strainer			•
Check Engine Compression			•

MAINTENANCE LOG

Date	Hours	Service Procedure

MAINTENANCE LOG

Date	Hours	Service Procedure

Index

A	Engine				
Accessories, 20	Clean Air Intake Screen, 41				
Adjustments	Description, 4				
Screed Platform, 23	Oil Pressure Indicator, 15, 16				
Track Pressure, 47	Starting, 14				
Air Cleaner	Temperature Gauge, 14,15				
Check, 41	Troubleshooting, 38				
Cleaning & Service Element, 44	Engine Oil				
Anti-freeze, See Radiator	Changing, 45				
	Check Level, 41				
В	Recommended Grades, 29				
Battery	Engine Oil Filter, replacing, 45				
Charging Gauge, 14	Exhaust System, check, 46				
Service, 42	F				
Battery Cables, cleaning, See Battery	•				
С	Fan Belt, 42				
	Features, See Specifications & Accessories				
Capacities, 4	Fuel, See Separate Engine Manual				
Checklists, delivery, 5	Fuel Filter				
Controls,	Check & Drain Water, 45				
Engine, 14	Replacing, 45				
Travel, 17	Fuel Gauge, 15,16				
Hopper, 18	G				
Screed Platform, 14	_				
Cylinders	Gauges, functions, 14				
Servicing, 39	Grease Fittings				
Troubleshooting, 37	Locations, 30				
D	Types of grease to use, 29				
Dealer Services. 39	Н				
Decal Locations, 50	Hourmeter, 15,16				
Decals, applying new, 50	Hydraulic Components				
Dimensions, 4	Servicing, 39				
Drain Cock, for draining coolant, 46	Troubleshooting, 35				
•	Hydraulic Oil				
E	Change, 47				
Electrical Components, servicing, 39	Check level, 42				
Electrical Schematics, 62	Recommended type, 29				
Electrical System	Hydraulic Oil Filters, replacing, 44				
Characteristics, 40	Hydraulic Oil Sump Strainer, replacing, 47				
Controls & Indicators, 14	Hydraulic Pressures, Test Port, 47				
Troubleshooting, 37	Hydraulic Schematic, 60				
	I				

Identification Numbers, 1 Ignition Switch, See Keyswitch Index, 57 Indicators, 14 International Symbols, Inside Front Cover Introduction, 2 J

Jump Starting Battery, 42

K

Keyswitch, 14

Loading, 27 Lubrication, 29 See also Service Locations, 30

M

Maintenance Log, 54

Mandatory SAFETY Shutdown Procedure, 8

0

Oils, See Lubrication Operation, 21 Operator Services, 40 Operator's Manual, storing, 2

P

Paver,

Itentification, 1 Starting, 21 Stopping, 22 Paving at jobsite, 23

Pump, delivery rates, 4

Paint, refinish, 50

R

Radiator

Check coolant, 41 Flushing & Refilling, 46 Replacement Filters, 30

S

SAFETY, 8

Schematic, Electrical, 61 Schematic, Hydraulic, 60 Service, 39 Specifications, 4 Starting Engine, 21 Steering, See Controls Storage, 48

T

Tables

Lubricants, 29 Paint Notice, 50 Theft Deterrents, 28 Torque Specifications, Standard Hardware, 59 Transporting, 25 Travel Speed, See Controls Troubleshooting, 31

W

Warranty, Inside Back Cover Water Trap, See Fuel Filter

Torque Specifications


Use these torque values when tightening GEHL hardware (excluding: Locknuts and Self-tapping, Thread-forming and Metal Screws) unless otherwise specified.

Unified National	Grade 2		Grade 5		Grade 8	
Thread	Dry	Lubed	Dry	Lubed	Dry	Lubed
8-32	19*	14*	30*	22*	41*	31*
8-36	20*	15*	31*	23*	43*	32*
10-24	27*	21*	43*	32*	60*	45*
10-32	31*	23*	49*	36*	68*	51*
1/4-20	66*	50*	9	75*	12	9
1/4-28	76*	56*	10	86*	14	10
5/16-18	11	9	17	13	25	18
5/16-24	12	9	19	14	25	20
3/8-16	20	15	30	23	45	35
3/8-24	23	17	35	25	50	35
7/16-14	32	24	50	35	70	55
7/16-20	36	27	55	40	80	60
1/2-13	35	35	75	55	110	80
1/2-20	40	40	90	65	120	90
9/16-12	55	55	110	80	150	110
9/16-18	60	60	120	90	170	130
5/8-11	75	75	150	110	220	170
5/8-18	85	85	180	130	240	180
3/4-10	130	130	260	200	380	280
3/4-16	150	150	300	220	420	320
7/8-9	125	125	430	320	600	460
7/8-14	140	140	470	360	660	500
1-8	190	190	640	480	900	680
1-14	210	210	710	530	1000	740


Metric Course	Grade 8.8		Grade 10.9 (10.9)		Grade 12.9 (12.9)	
Thread	Dry	Lubed	Dry	Lubed	Dry	Lubed
M6-1	8	6	11	7	13.5	10*
24M8-1.25	19	14	27	20	32.5	24*
M10-1.5	37.5	28	53	39	64	47
M12-1.75	65	48	91.5	67.5	111.5	82
M14-2	103.5	76.5	145.5	108	176.5	131
M16-2	158.5	117.5	223.5	165.5	271	200

^{*} All torque values are in lb-ft except those marked with an * which are in lb-in. For metric torque value (Nm) muiltiply lb-ft x 1.355 or lb-in value x 0.113.


1438/1448 Hydraulic Schematic w/Track Drive




1438/1448 Hydraulic Schematic w/Rubber Tire Drive/2-Speed Option



1438 Electrical Harness Reference



1448 Electrical Harness Reference



THIS PAGE INTENTIONALY BLANK

GEHL®

NEW CONSTRUCTION EQUIPMENT POWER BOX® PAVER

WARRANTY

GEHL CONSTRUCTION DIVISION of the **GEHL COMPANY**, hereinafter referred to as GEHL, warrants new GEHL Power Box Pavers, to the Original Retail Purchaser to be free from defects in material and workmanship for a period of twelve (12) months from the Warranty Start Date.

GEHL CONSTRUCTION WARRANTY INCLUDES:

Genuine Gehl parts and labor costs required to repair or replace equipment at the selling dealer's business location.

GEHL MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND, EXPRESS OR IMPLIED (INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR PARTICULAR PURPOSE), EXCEPT AS EXPRESSLY STATED IN THIS WARRANTY STATEMENT.

GEHL WARRANTY DOES NOT INCLUDE:

- 1. Transportation to selling dealer's business location or, at the option of the Original Retail Purchaser, the cost of a service call.
- 2. Used equipment.
- Components covered by their own non-Gehl warranties, such as tires, trade accessories and engines.
- 4. Normal maintenance service and expendable, high wear items.
- 5. Repairs or adjustments caused by: improper use; failure to follow recommended maintenance procedures; use of unauthorized attachments; accident or other casualty.
- 6. Liability for incidental or consequential damages of any type, including, but not limited to lost pofits expenses of acquiring replacement equipment.

No agent, employee or representative of GEHL has any authority to bind GEHL to any warranty except as specifically set forth herein. Any of these limitations excluded by local law shall be deemed deleted from this warranty; all other terms will continue to apply.



THIS OPERATOR'S MANUAL IS PROVIDED FOR OPERATOR USE

DO NOT REMOVE FROM THIS MACHINE

THANK YOU

DO NOT START, OPERATE OR WORK ON THIS MACHINE UNTIL YOU HAVE CARE-FULLY READ AND THOROUGHLY UNDERSTAND THE CONTENTS OF THE OPERA-TOR'S MANUAL.

FAILURE TO FOLLOW SAFETY, OPERATING AND MAINTENANCE INSTRUCTIONS COULD RESULT IN SERIOUS INJURY TO THE OPERATOR OR BYSTANDERS, POOR OPERATION, AND COSTLY BREAKDOWN.

IF YOU HAVE ANY QUESTIONS ON PROPER OPERATION, ADJUSTMENT OR MAINTENANCE OF THIS MACHINE, CONTACT YOUR DEALER OR THE SERVICE DEPARTMENT OF GEHL COMPANY BEFORE STARTING OR CONTINUING OPERATION.

California Proposition 65 Warnings

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer and birth defects or other reproductive harm.

Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. **Wash hands after handling battery.**



GEHL Company 143 Water Street, P.O. Box 179, West Bend, WI 53095-0179