


192-222

Mini-excavator



PARTS MANUAL

GEHL

CONSTRUCTION

Introduction

When ordering service parts, specify the correct part number, full description, quantity required, the unit model number and serial number.

The Mini-excavator model and serial numbers are on a plate located on the lower left front outer side of the cabin (from the driver's perspective).

OUR Company reserves the right to make changes or improvements in the design or construction of any part of the unit without incurring the obligation to install such changes on any previously delivered units.

To ensure continued safe operation, replace damaged or worn-out parts with genuine Factory service parts, BEFORE attempting to operate this equipment.

Refer to the abbreviations table located on this page for the various fastener descriptions.

In the exploded view parts list, Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in that section. Refer to the Table of Contents for locations of specific assemblies.

NOTE: *The following abbreviations may be used herein:*

AR	– As Required
ASSD	– Assembled
ASSY	– Assembly
CB	– Carriage Bolt
CCW	– Counterclockwise
CP	– Cotter Pin
CS	– Cap Screw (Hexagon Head)
CTR	– Center
CW	– Clockwise
DEG	– Degree
DIA	– Diameter
FCHC	
FCS	– Flanged Cap Screw
FHMS	– Flat Head Machine Screw
FL	– Flanged
FLN	– Flanged Lock Nut (Hexagon)
FLS	– Flanged Lock Screw (Hexagon)
FW	– Flat Washer
GA	– Gauge
GR	– Grade
HD	– Hard or Head
HLN	– Hex Lock Nut
HJN	– Hex Jam Nut
HN	– Hex Nut
HS	
INCL	– Includes
INS	
JT	– Joint
LG	– Large
LH	– Left Hand
LN	– Lock Nut
LW	– Lock Washer
M	– Metric
MM/mm	– Millimeter
NF	– National Fine
PB	– Plow Bolt
PTO	– Power Take Off
RH	– Right Hand
RHMS	– Round Head Machine Screw
RPM	– Revolutions Per Minute
RT	– Right
SERR	– Serrated
SHCS	– Socket Head Cap Screw
SHSS	– Socket Head Set Screw
SN	– Serial Number or Slotted Nut
SQ	– Square
SQSS	– Square Head Set Screw
T	– Tooth or Teeth
TFS	– Thread Forming Screw
THMS	– Truss Head Machine Screw
THRD	– Thread
WLDMT	– Weldment
ZO	– Zinc Oxide Plating
#	– Number

Table of Contents

SECTION A: UNDERCARRIAGE	5
UNDERCARRIAGE	6
MODEL 192 — UNDERCARRIAGE	6
MODEL 222 — UNDERCARRIAGE	8
MODELS 192-222 — TRACK TENSION	10
MODELS 192-222 — TRACK ROLLER	11
MODELS 192-222 — TRACK ROLLER	12
SECTION B: DOZER BLADE	13
DOZER BLADE	14
MODELS 192-222 — DOZER BLADE	14
MODELS 192-222 — DOZER BLADE EXTENSION	15
SECTION C: CHASSIS	17
CHASSIS	18
MODELS 192-222 — CHASSIS	18
MODELS 192-222 — CHASSIS COVERS	20
MODELS 192-222 — CHASSIS LUBRICATION	21
MODELS 192-222 — VALVE BRACKET	22
MODELS 192-222 — HOOD	23
SECTION D: TILT FRAME	25
TILT FRAME	26
MODELS 192-222 — TILT FRAME	26
MODELS 192-222 — ISOLATION MATS	28
MODELS 192-222 — TOOL BOX	29
SECTION E: BOOM	31
BOOM	32
MODELS 192-222 — BOOM	32
MODELS 192-222 — STICK	34
SECTION F: CABIN	37
CABIN	38
MODELS 192-222 — CABIN	38
MODELS 192-222 — CABIN FRAME	40
MODELS 192-222 — RADIO KIT	42
MODELS 192-222 — CABIN CABLES	43
MODELS 192-222 — WINDSHIELD	44
MODELS 192-222 — LOWER FRONT WINDSHIELD	46
MODELS 192-222 — UPPER FRONT WINDSHIELD	47
MODELS 192-222 — SIDE WINDOW	48
MODELS 192-222 — REAR WINDOW	49
MODELS 192-222 — CABIN DOOR	50
MODELS 192-222 — WINDSHIELD WASHER	52
MODELS 192-222 — DRIVERS SEAT	53
MODELS 192-222 — CAB HEATING	54
SECTION G: DIESEL ENGINE	55
DIESEL ENGINE	56
MODELS 192-222 — DIESEL ENGINE	56


MODELS 192-222 — ENGINE SUSPENSION.....	57
MODELS 192-222 — COOLING WATER RADIATOR	58
MODELS 192-222 — AIR INTAKE	59
MODELS 192-222 — EXHAUST	60
MODELS 192-222 — FUEL LINE.....	61
MODELS 192-222 — ACCELERATOR	62
MODELS 192-222 — DIESEL TANK.....	63
SECTION H: HYDRAULIC SYSTEM	65
HYDRAULIC SYSTEM	66
MODELS 192-222 — HYDRAULIC PUMP	66
MODELS 192-222 — HYDRAULIC OIL TANK	67
MODELS 192-222 — HYDRAULIC PUMP	68
MODELS 192-222 — HYDRAULIC OIL COOLER	69
MODELS 192-222 — TRAVELING MOTORS	70
MODELS 192-222 — VALVE ANGLE.....	72
MODELS 192-222 — CONTROL VALVE.....	74
MODELS 192-222 — PILOT OIL SUPPLY UNIT	76
MODEL 192 — SWIVEL JOINT.....	77
MODEL 222 — SWIVEL JOINT.....	78
MODELS 192-222 — TURNING MOTOR	79
MODELS 192-222 — SELECTION VALVE	80
MODELS 192-222 — CONTROL LEVERS	81
MODEL 222 — LOCK VALVE.....	82
MODEL 192 — DOZER BLADE VALVE	83
MODEL 222 — DOZER BLADE VALVE	84
MODELS 192-222 — BALL VALVE	85
MODELS 192-222 — DOZER BLADE CYLINDER	86
MODELS 192-222 — BOOM OFFSET CYLINDER	87
MODELS 192-222 — BOOM CYLINDER	88
MODELS 192-222 — STICK CYLINDER	89
MODELS 192-222 — BUCKET CYLINDER	90
MODELS 192-222 — TELESCOPIC CYLINDER	91
MODEL 222 — TILT CYLINDER	92
MODELS 192-222 — DOZER BLADE VALVE INSTALLATION	93
MODELS 192-222 — HYDRAULIC OIL COOLER INSTALLATION	94
MODEL 192 — TRAVELING MOTOR INSTALLATION	95
MODEL 222 — TRAVELING MOTOR INSTALLATION	96
MODELS 192-222 — TURNING MOTOR INSTALLATION	97
MODELS 192-222 — PILOT OIL SUPPLY UNIT INSTALLATION	98
MODELS 192-222 — BOOM OFFSET CYLINDER INSTALLATION	99
MODEL 192 — DOZER BLADE CYLINDER INSTALLATION	100
MODEL 222 — DOZER BLADE CYLINDER INSTALLATION	101
MODEL 192 — TELESCOPIC CYLINDER INSTALLATION	102
MODEL 222 — TELESCOPIC CYLINDER INSTALLATION	103
MODEL 222 — TILT CYLINDER INSTALLATION	104
MODELS 192-222 — BOOM CYLINDER INSTALLATION	105
MODELS 192-222 — AUXILIARY HYDRAULICS INSTALLATION	106
MODELS 192-222 — HAND LEVER INSTALLATION	107

SECTION I: ELECTRICAL SYSTEM	109
ELECTRICAL SYSTEM	110
MODELS 192-222 — ELECTRICAL INSTALLATION 1	110
MODELS 192-222 — ELECTRICAL INSTALLATION 2	111
MODELS 192-222 — BATTERY INSTALLATION	112
MODELS 192-222 — CONTROL BOARD	113
MODELS 192-222 — RELAY BOX	114
MODELS 192-222 — HEADLIGHTS	115
MODELS 192-222 — HORN	116
SECTION J: TOOLS	117
TOOLS	118
MODELS 192-222 — TOOLS	118
SECTION K: DECALS	119
DECALS	120
MODEL 192 — DECALS	120
MODEL 222 — DECALS	121

SECTION A: UNDERCARRIAGE

UNDERCARRIAGE	6
MODEL 192 — UNDERCARRIAGE	6
MODEL 222 — UNDERCARRIAGE	8
MODELS 192-222 — TRACK TENSION.....	10
MODELS 192-222 — TRACK ROLLER.....	11
MODELS 192-222 — TRACK ROLLER.....	12

MODELS 192-222 MINI-EXCAVATOR UNDERCARRIAGE MODEL 192 — UNDERCARRIAGE



ET1920100

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.


**MODELS 192-222 MINI-EXCAVATOR
UNDERCARRIAGE
MODEL 192 — UNDERCARRIAGE**

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
REF	162098	UNDERCARRIAGE ASSEMBLY	1	23	161915	TUBE.....	2
1	162097	BRACKET	1	24	651412	CS M14-2.0 X 50 C 10.9 ZO.....	4
2	162095	FRAME	1	25	651408	CS M12-1.7 X 40 C 10.9 ZO.....	24
3	162096	FRAME	1	26	651474	SHCS HS M10-1.2 X 25 10.9 ZO D912	20
4	160679	TELESCOPIC CYLINDER.....	1	27	162022	SCREW.....	34
5	160616	COVER	1	28	656093	CS M8-1.2 X 16 C 8.8 ZO.....	4
6	160622	PIN.....	2	29	161643	WASHER/ROUND HI-TENS DIN6916	24
7	161399	SCREW	2	30	161623	LW SPRING B10 DIN7981	34
8	161918	PLATE	4	31	161661	WASHER/GR A 8.4 ZO	12
9	160516	TRACK TENSION	2	33	161635	WASHER/NORD-LOCK NL 10 STUCK	20
10	160638	NON RETURN VALVE.....	2	34	161669	LOCKWASHER S10	16
11	160517	ROLLER.....	8	35	161676	LOCKWASHER S8	12
12	161930	COVER	2	36	161671	LOCKWASHER S14	4
13	161920	SWIVEL JOINT	1	37	651451	HLN INS M16-2.0 ZO	2
14	161917	COVER	1	38	656052	HN M16-2.0 ZO	2
15	162094	COVER	1	39	651468	PIN/SPRING M8 X 70 D1481	1
16	160633	TRAVELING GEAR	2	40	651391	CS M10-1.5 X 20 C 8.8 ZO	12
17	160634	SPROCKET.....	2	41	161640	WASHER/GR A 10.5 ZO	12
18	160624	RUBBER TRACK.....	2	42	161647	WASHER/ROUND HI-TENS 17	2
19	161916	COVER	1	43	161649	WASHER/GR A 18 ZO DIN7989.....	2
20	161724	TURNTABLE	1	44	651515	SHCS HS M8-1.2 X 20 8.8 ZO D912	8
21	160865	SCREW SEAL	2				

MODELS 192-222 MINI-EXCAVATOR

UNDERCARRIAGE

MODEL 222 — UNDERCARRIAGE




ET1920105

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

**MODELS 192-222 MINI-EXCAVATOR
UNDERCARRIAGE
MODEL 222 — UNDERCARRIAGE**

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
REF	162106	UNDERCARRIAGE ASSEMBLY	1	28	651500	SHCS HS M16-1.5 X 80 12.9 ZO D912	8
1	162105	BRACKET	1	29	161623	LW SPRING B10 DIN7981	34
2	162095	RIGHT SIDE FRAME ASSEMBLY	1	30	651445	SHSS M10 X 16 45H DP.	1
3	162096	LEFT SIDE FRAME ASSEMBLY	1	31	161672	LOCKWASHER S16	8
4	160679	TELESCOPIC CYLINDER	1	32	161412	LUBRICATION NIPPLE	2
5	160616	COVER	1	33	161416	PROTECTION CAP	2
6	160622	PIN	2	34	162124	COTTER PIN	2
7	161399	SCREW	2	35	651412	CS M14-2.0 X 50 C 10.9 ZO	4
8	161918	PLATE	4	36	162122	SCREW	23
9	160516	TRACK TENSION	2	37	651474	SHCS HS M10-1.2 X 25 10.9 ZO D912	20
10	160638	NON RETURN VALVE	2	38	162022	SCREW	34
11	160517	ROLLER	8	39	656093	CS M8-1.2 X 16 C 8.8 ZO	14
12	161930	COVER	2	40	161917	COVER	1
13	162115	SWIVEL JOINT	1	41	161643	WASHER/ROUND HI-TENS DIN6916	23
14	162102	BRACKET	1	42	161661	WASHER/GR A 8.4 ZO	12
15	162094	COVER	1	44	161635	WASHER/NORD-LOCK NL 10 STUCK	20
16	160633	TRAVELING GEAR	2	45	161669	LOCKWASHER S10	12
17	160634	SPROCKET	2	46	161676	LOCKWASHER S8	12
18	160624	RUBBER TRACK	2	47	161671	LOCKWASHER S14	4
19	161916	COVER	1	48	651451	HLN INS M16-2.0 ZO	2
20	161724	TURNTABLE	1	49	656052	HN M16-2.0 ZO	2
21	160865	SCREW SEAL	2	50	651468	PIN/SPRING M8 X 70 D1481	1
22	656001	CS M8-1.2 X 20 C 8.8 ZO	2	51	651391	CS M10-1.5 X 20 C 8.8 ZO	12
23	162103	BRACKET	1	52	161640	WASHER/GR A 10.5 ZO	16
24	162104	BRACKET	2	53	161647	WASHER/ROUND HI-TENS 17	2
25	160668	TIILT CYLINDER	1	54	161649	WASHER/GR A 18 ZO DIN7989	2
26	160779	PIN	1	55	651515	SHCS HS M8-1.2 X 20 8.8 ZO D912	8
27	160780	PIN	1	56	161915	TUBE	2

**MODELS 192-222 MINI-EXCAVATOR
UNDERCARRIAGE
MODELS 192-222 — TRACK TENSION**




ET1920110

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	160635	ROLLER.....	1	7	161564	SEAL.....	1
2	160518	GUIDANCE	2	8	161561	SEAL.....	1
3	161829	BRACKET	1	9	160521	CYLINDER	1
4	651398	CS M10-1.5 X 35 C 10.9 ZO	4	10	160523	SPRING.....	1
5	161623	LW SPRING B10 DIN7981.....	4	11	162049	NUT	1
6	160520	PISTON	1	12	162053	COTTER PIN.....	1

**MODELS 192-222 MINI-EXCAVATOR
UNDERCARRIAGE
MODELS 192-222 — TRACK ROLLER**



ET1920115


* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	160635	ROLLER.....	1
2	161421	PLUG.....	1
3	160522	SHAFT.....	1
4	161559	BEARING.....	2
5	162055	RETAINING RING	2
6	161575	SEAL	2

MODELS 192-222 MINI-EXCAVATOR

UNDERCARRIAGE

MODELS 192-222 — TRACK ROLLER



ET1920120

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	161919	ROLLER.....	1
2	161828	BRACKET	2
3	161827	SHAFT	1
4	162075	BEARING.....	2
5	162076	SEAL	2
6	162054	RETAINING RING	2
7	162043	SCREW	1


SECTION B: DOZER BLADE

DOZER BLADE	14
MODELS 192-222 — DOZER BLADE	14
MODELS 192-222 — DOZER BLADE EXTENSION	15

MODELS 192-222 MINI-EXCAVATOR

DOZER BLADE

MODELS 192-222 — DOZER BLADE




ET1920125

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	161931	DOZER BLADE	1
2	160654	PIN.....	2
3	161681	PIN/SPLIT 6.3 X 50 ZO D94	6
4	160655	PIN.....	2
5	161657	WASHER/GR A 34 ZO DIN125	4
6	160672	DOZER BLADE CYLINDER.....	1
7	161411	LUBRICATION FITTING	2
8	161416	PROTECTION CAP	2

**MODELS 192-222 MINI-EXCAVATOR
DOZER BLADE
MODELS 192-222 — DOZER BLADE EXTENSION**



ET1920130

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	161932	BLADE EXTENSION R	1
2	161933	BLADE EXTENSION L	1
3	160656	PIN.....	2
4	161405	COTTER PIN.....	2


SECTION C: CHASSIS

CHASSIS	18
MODELS 192-222 — CHASSIS	18
MODELS 192-222 — CHASSIS COVERS	20
MODELS 192-222 — CHASSIS LUBRICATION	21
MODELS 192-222 — VALVE BRACKET	22
MODELS 192-222 — HOOD	23

MODELS 192-222 MINI-EXCAVATOR

CHASSIS

MODELS 192-222 — CHASSIS



ET1920200

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.


**MODELS 192-222 MINI-EXCAVATOR
CHASSIS
MODELS 192-222 — CHASSIS**

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	161818	CHASSIS.....	1	22	651469	PIN/SPRING M8 X 70 D1481	1
2	161570	O-RING	1	23	160595	HYDRAULIC MOTOR.....	1
3	161643	WASHER/ROUND HI-TENS DIN6916.....	28	24	162093	BRACKET	1
4	651411	HB M12-1.7X 60 C 10.9 ZO.....	23	25	162101	BRACKET	1
5	161810	COUNTERWEIGHT.....	1	26	656148	SHCS HS 12-1.75X40 10.9 ZO.....	1
6	651496	SHCS HS M16-1.5 X 45 10.9 ZO D912.....	2	27	160515	BAR LOCK	1
7	651447	HN M16-2.00 ZO	4	28	161803	COVER	2
8	161541	BUSHING.....	2	29	162023	SCREW.....	4
9	161411	LUBRICATION FITTING	1	30	651485	SHCS HS M12-1.7 X 45 10.9 ZO D912	2
10	161422	PROTECTION CAP.....	1	31	160409	REFLECTOR.....	2
11	162109	SWING BRACKET.....	1	32	160644	REFLECTOR.....	2
12	160697	PIN.....	1	33	161627	RIVET/BLIND A4 X 12 DIN7337.....	8
13	161656	WASHER/ROUND HI-TENS 28 DIN6916.....	1	34	162019	RUBBER PROTECTOR	1
14	651454	HLN INS M27-3 ZO	1	35	161812	PLATE	1
15	162052	COTTER PIN	1	36	651498	SHCS HS M16-1.5 X 55 10.9 ZO D912	2
17	160680	BOOM OFFSET CYLINDER	1	37	161811	BRACKET	4
18	160601	PIN.....	1	38	651482	SHCS HS M12-1.7 X 35 12.9 ZO D912	1
19	160691	PIN.....	1	39	651410	HB M12-1.7X 55 C 10.9 ZO	1
20	651438	HB M8-1.2 X 70 C 8.8 ZO	1	40	161666	WASHER/GR A 6.4 ZO DIN9021	4
21	651458	HLN INS M8-1.2 8 ZO	1	41	162048	NUT.....	4

MODELS 192-222 MINI-EXCAVATOR

CHASSIS

MODELS 192-222 — CHASSIS COVERS




ET1920205

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	161822	COVER	1
2	161802	COVER	1
3	162016	RUBBER PROTECTOR (90 cm)	1
4	162020	RUBBER PROTECTOR (70 cm)	1
5	656001	CS M8-1.2 X 20 C 8.8 ZO	9
6	161676	LOCKWASHER S8	9
7	161667	WASHER/GR A 8.4 ZO	9
8	162015	RUBBER SEAL (35 cm).....	1

**MODELS 192-222 MINI-EXCAVATOR
CHASSIS**
MODELS 192-222 — CHASSIS LUBRICATION



ET1920210


* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	161722	LUBRICATION BLOCK	1	8	161392	LUBRICATION TUBE (92 cm).....	1
2	651507	SHCS HS M6-1 X 20 8.8 ZO D912	2	9	161392	LUBRICATION TUBE (80 cm).....	1
3	161675	LOCKWASHER S6	2	10	161400	SET SCREW.....	1
4	161411	LUBRICATION FITTING	2	11	161469	WASHER.....	4
5	161416	PROTECTION CAP.....	2	12	161468	NUT.....	4
6	161461	FITTING.....	4				

MODELS 192-222 MINI-EXCAVATOR

CHASSIS

MODELS 192-222 — VALVE BRACKET




ET1920215

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	161800	VALVE BRACKET	1
3	161948	RUBBER PROTECTOR.....	1
4	656001	CS M8-1.2 X 20 C 8.8 ZO	3
5	656105	CS M8-1.2 X 25 C 8.8 ZO	3
6	161615	NUT/CAGE M8.....	3
7	161667	WASHER/GR A 8.4 ZO	9
8	161676	LOCKWASHER S8	9
9	651458	HLN INS M8-1.2 8 ZO	3

**MODELS 192-222 MINI-EXCAVATOR
CHASSIS
MODELS 192-222 — HOOD**



ET1920230

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	161804	COVER	1	13	160402	LOCK.....	1
2	161805	TUBE	2	14	651503	SHCS HS M5-0.8 X 12 8.8 ZO D912	3
3	651393	CS M10-1.5 X 25 C 8.8 ZO	7	15	161659	WASHER/GR A 5.3 ZO DIN125	3
6	161816	HINGE	1	16	160400	LOCK.....	1
8	161669	LOCKWASHER S10	5	17	162047	NUT.....	2
9	161640	WASHER/GR A 10.5 ZO	9	18	161674	LOCKWASHER S5	3
10	161817	PLATE	1	19	160643	KEY.....	1
11	161610	NUT/CAGE M10	2	20	162016	RUBBER PROTECTOR	3
12	161820	HOOD	1	21	161902	ISOLATION MAT	1

SECTION D: TILT FRAME


TILT FRAME	26
MODELS 192-222 — TILT FRAME	26
MODELS 192-222 — ISOLATION MATS	28
MODELS 192-222 — TOOL BOX	29

SECTION D: TILT FRAME

MODELS 192-222 MINI-EXCAVATOR

TILT FRAME

MODELS 192-222 — TILT FRAME



ET1920220

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.


MODELS 192-222 MINI-EXCAVATOR
TILT FRAME
MODELS 192-222 — TILT FRAME

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	160653	BUSHING.....	2	22	161641	WASHER/GR 10.5 ZO	2
2	651446	SHSS M8 X 12 45H CP.....	4	23	651448	HLN INS M10-1.5 ZO	1
3	160596	BUSHING.....	2	24	161945	BRACKET	1
4	162034	SCREW	2	25	161813	BRACKET	1
5	161669	LOCKWASHER S10	6	26	161661	WASHER/GR A 8.4 ZO	2
6	161663	WASHER/GR A 10.5 ZO DIN9021	2	27	161676	LOCKWASHER S8	2
7	160711	CUSHION	2	28	656093	CS M8-1.2 X 16 C 8.8 ZO.....	2
8	651477	SHCS HS M12-1.7 X 110 10.9 ZO D912.....	2	29	651426	CS M6-1.0 X 35 C 8.8 ZO.....	1
9	161936	WASHER.....	2	30	651457	HLN INS M6-1.0 8 ZO	1
10	161875	WASHER	2	31	161854	BRACKET	1
11	651395	CS M10-1.5 X 30 C 10.9 ZO	4	32	656149	CS M6-1.0 X 16 C 8.8 ZO.....	3
12	161642	WASHER/GR A 13 ZO	2	33	161675	LOCKWASHER S6	3
13	161808	CAB MOUNT L	1	34	161666	WASHER/GR A 6.4 ZO DIN9021	3
14	161807	CAB MOUNT R	1	35	161613	NUT/CAGE M6	1
15	162026	SCREW	4	36	161943	PVC-EDGE PROTECTION (30 cm)	1
16	651434	HB M8-1.2 X 45 C 8.8 ZO	1	37	161946	SPACER	1
17	161643	WASHER/ROUND HI-TENS DIN6916.....	4	38	161661	WASHER/GR A 8.4 ZO	2
18	161642	WASHER/GR A 13 ZO	2	39	651458	HLN INS M8-1.2 8 ZO.....	2
19	162046	NUT	2	40	656004	HB M8-1.2 X 55 C 8.8 ZO	1
20	160612	PNEUMATIC SPRING	1	41	161667	WASHER/GR A 8.4 ZO.....	2
21	651399	CS M10-1.5 X 40 C 8.8 ZO	1				

MODELS 192-222 MINI-EXCAVATOR

TILT FRAME

MODELS 192-222 — ISOLATION MATS




ET1920225

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	161876	TIlttable Frame	1	7	161897	ISOLATION MAT	1
2	161948	RUBBER PROTECTOR (450 cm).....	1	8	161896	ISOLATION MAT	1
3	161943	PVC-EDGE PROTECTION (88 cm).....	1	9	161898	ISOLATION MAT	1
4	162010	HOSE (80 cm)	1	10	161901	ISOLATION MAT	1
5	161899	ISOLATION MAT	1	11	160602	FLOOR MAT	1

**MODELS 192-222 MINI-EXCAVATOR
TILT FRAME
MODELS 192-222 — TOOL BOX**



ET1920235

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	161879	TOOL BOX.....	1
2	656149	CS M6-1.0 X 16 C 8.8 ZO	2
3	161675	LOCKWASHER S6	2
4	161614	NUT/CAGE M6	2
5	161943	PVC-EDGE PROTECTION (150 cm)	1

SECTION E: BOOM


BOOM	32
MODELS 192-222 — BOOM.....	32
MODELS 192-222 — STICK.....	34

SECTION E: BOOM

MODELS 192-222 MINI-EXCAVATOR

BOOM

MODELS 192-222 — BOOM



ET1920300

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.


**MODELS 192-222 MINI-EXCAVATOR
BOOM
MODELS 192-222 — BOOM**

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	162108	BOOM	1	15	162068	COVER	2
2	161407	WASHER	2	16	162025	SCREW	2
3	161539	BUSHING	2	17	161555	HOSE CLAMP	3
4	161411	LUBRICATION FITTING	1	18	162067	COVER	3
5	161422	PROTECTION CAP	1	19	651425	CS M6-1.0 X 30 C 8.8 ZO	6
6	160630	TUBE	1	20	161557	HOSE CLAMP	3
7	160628	TUBE	1	21	162066	COVER	3
8	160629	TUBE	2	22	651426	CS M6-1.0 X 35 C 8.8 ZO	6
9	160631	TUBE	1	30	160669	BOOM CYLINDER	1
10	160632	TUBE	1	31	160690	PIN	1
11	161552	HOSE CLAMP	4	32	160693	PIN	1
12	162070	COVER	4	33	160692	PIN	1
13	651427	HB M6-1.0 X 35 C 8.8 ZO	4	34	651438	HB M8-1.2 X 70 C 8.8 ZO	3
14	161553	HOSE CLAMP	2	35	651458	HLN INS M8-1.2 8 ZO	3

MODELS 192-222 MINI-EXCAVATOR

BOOM

MODELS 192-222 — STICK




ET1920305

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	162107	STICK.....	1	14	651438	HB M8-1.2 X 70 C 8.8 ZO.....	3
2	161406	WASHER.....	6	15	651458	HLN INS M8-1.2 8 ZO.....	3
3	161543	BUSHING.....	4	20	160862	QUICK COUPLER.....	1
4	161539	BUSHING.....	2	21	160458	DUST PLUG	1
5	161411	LUBRICATION FITTING	3	22	161353	QUICK COUPLER.....	1
6	161422	PROTECTION CAP.....	3	23	160459	DUST CAP	1
10	160671	HANDLE CYLINDER.....	1	24		REFER TO FACTORY	
11	160689	PIN.....	1	25		REFER TO FACTORY	
12	160688	PIN.....	1	26		REFER TO FACTORY	
13	160692	PIN.....	1				

**MODELS 192-222 MINI-EXCAVATOR
BOOM
MODELS 192-222 — BUCKET LINK**



ET1920310

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	160661	CONNECTING LINK	1	11	160696	PIN	1
2	161406	WASHER	2	12	160695	PIN	1
3	161543	BUSHING.....	2	13	651454	HLN INS M27-3 ZO.....	2
4	161540	BUSHING.....	2	14	160688	PIN	1
5	161411	LUBRICATION FITTING	1	15	651438	HB M8-1.2 X 70 C 8.8 ZO.....	1
6	161422	PROTECTION CAP.....	1	16	651458	HLN INS M8-1.2 8 ZO.....	1
7	160662	CONNECTING LINK	1	17	160694	PIN	2
8	160663	CONNECTING LINK	1	18	161405	COTTER PIN.....	2
10	160670	BUCKET CYLINDER.....	1				


SECTION F: CABIN

CABIN	38
MODELS 192-222 — CABIN	38
MODELS 192-222 — CABIN FRAME	40
MODELS 192-222 — RADIO KIT	42
MODELS 192-222 — CABIN CABLES	43
MODELS 192-222 — WINDSHIELD	44
MODELS 192-222 — LOWER FRONT WINDSHIELD	46
MODELS 192-222 — UPPER FRONT WINDSHIELD	47
MODELS 192-222 — SIDE WINDOW	48
MODELS 192-222 — REAR WINDOW	49
MODELS 192-222 — CABIN DOOR	50
MODELS 192-222 — WINDSHIELD WASHER	52
MODELS 192-222 — DRIVERS SEAT.....	53
MODELS 192-222 — CAB HEATING	54

MODELS 192-222 MINI-EXCAVATOR

CABIN

MODELS 192-222 — CABIN



ET1920400

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.


**MODELS 192-222 MINI-EXCAVATOR
CABIN
MODELS 192-222 — CABIN**

Ref. No.	Part No.	Description	Qty. Req.
1	162014	CABIN	1
2	651489	SHCS HS M12-1.7 X 65 10.9 ZO D912.....	4
3	651483	SHCS HS M12-1.7 X 35 10.9 ZO D912.....	4
4	161670	LOCKWASHER S12	8
5	161645	WASHER/GR. A 13 DIN7349 ZO	4

MODELS 192-222 MINI-EXCAVATOR

CABIN

MODELS 192-222 — CABIN FRAME



ET1920405

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.


**MODELS 192-222 MINI-EXCAVATOR
CABIN
MODELS 192-222 — CABIN FRAME**

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	161835	CABIN FRAME	1	16	161921	PIN	2
2	161844	GUTTER	1	17	161780	STEP.....	2
3	160526	LOCK.....	2	18	161776	LOCK.....	4
4	160527	LOCK.....	2	19	161779	LOCK.....	2
5	160488	ILLUMINATION	1	20	161781	BRACKET	2
6	161782	COVER	1	21	161784	SPACER	2
7	161783	COVER	1	22	162029	SCREW.....	4
8	161769	ROOF ISOLATION.....	1	23	161634	SCREW/C'SUNK HD M5 X 16 DIN966 ZO.....	4
9	161937	FIXING STRIP (240 cm)	1	24	161843	NUT.....	4
10	161770	LOCK.....	11	25	162035	SCREW.....	2
11	161949	RUBBER PROTECTOR (220 cm).....	1	26	162036	SCREW.....	4
12	161950	RUBBER PROTECTOR	1	27	161660	WASHER/GR A 6.4 ZO DIN125	2
13	161924	PLATE	2	28	162037	SCREW.....	8
14	161923	WASHER.....	2	29	162031	SCREW.....	2
15	161922	BRACKET	2				

MODELS 192-222 MINI-EXCAVATOR

CABIN

MODELS 192-222 — RADIO KIT




ET1920410

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	161845	RADIO CONSOLE	1	8	656163	CS M5-0.8 X 10 C 8.8 ZO	2
2	162006	RADIO	1	9	161659	WASHER/GR A 5.3 ZO DIN125	2
3	161944	BRACKET	2	10	162050	WASHER.....	2
4	162005	SPEAKERS	2	11	162044	SCREW.....	3
5	161838	HARNESS WIRING	1	12	162030	SCREW.....	1
6	161839	CABLE	1	13	161846	RADIO KIT.....	1
7	162007	RUBBER ANTENNA	1				

**MODELS 192-222 MINI-EXCAVATOR
CABIN
MODELS 192-222 — CABIN CABLES**



ET1920415


* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	161846	CABLE	1
2	161841	CABLE	1
3	162012	PLASTIC HOSE (350 cm)	1
4	161842	HARNESS WIRING	1
5	161847	CONNECTION	1
6	160529	HARNESS WIRING KIT	1

MODELS 192-222 MINI-EXCAVATOR

CABIN

MODELS 192-222 — WINDSHIELD




ET1920420

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

**MODELS 192-222 MINI-EXCAVATOR
CABIN
MODELS 192-222 — WINDSHIELD**

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	160495	FRONT WINDSHIELD	1	11	161941	WASHER.....	2
2	161785	BRACKET	1	12	161951	EDGE PROTECTION	1
3	161786	BRACKET	1	13	161957	WASHER.....	1
4	161938	WIPER MOTOR ASSEMBLY.....	1	14	656048	HN M8-1.2 ZO.....	2
5	161939	WIPER BLADE HOLDER	1	15	162033	SCREW.....	2
6	161940	WIPER BLADE	1	16	161661	WASHER/GR A 8.4 ZO	4
7	160641	PVC-WASHER.....	2	17	161618	NUT/HEX DOMED CAP M8	4
8	160640	RUBBER WASHER	4	18	651466	SCREW FCHC HS M8-1.2 X 20 8.8 ZO D7991 .2	
9	160639	RUBBER WASHER	6	20	160497	WINDSHIELD KIT	1
10	160494	PLUG	4				

MODELS 192-222 MINI-EXCAVATOR
CABIN
MODELS 192-222 — LOWER FRONT WINDSHIELD




ET1920425

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	161772	FRONT WINDSHIELD	1
2	161771	NOZZLE	1
4	161964	SILICON GLUE	1

**MODELS 192-222 MINI-EXCAVATOR
CABIN
MODELS 192-222 — UPPER FRONT WINDSHIELD**



ET1920430


* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	160489	UPPER FRONT WINDSHIELD	1
4	161964	SILICON GLUE	1

MODELS 192-222 MINI-EXCAVATOR

CABIN

MODELS 192-222 — SIDE WINDOW




ET1920435

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	161774	SIDE WINDOW, COMPLETE	1
2	161775	SIDE WINDOW	1
3	161964	SILICON GLUE	1

**MODELS 192-222 MINI-EXCAVATOR
CABIN
MODELS 192-222 — REAR WINDOW**



ET1920440


* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	161773	REAR WINDOW	1
2	161964	SILICON GLUE	1

MODELS 192-222 MINI-EXCAVATOR

CABIN

MODELS 192-222 — CABIN DOOR




ET1920445

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

**MODELS 192-222 MINI-EXCAVATOR
CABIN
MODELS 192-222 — CABIN DOOR**

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	161777	DOOR FRAME.....	1	12	160491	DOOR LOCK COVER/RT.....	2
2	161836	DOOR FRAME.....	1	13	160712	COVER L.....	2
3	161778	DOOR WINDOW	1	14	161779	LOCK.....	1
4	161396	RUBBER PROTECTOR	4	15	161925	SQUARE NUT.....	1
6	162018	RUBBER PROTECTOR	4	16	656092	CS M6-1.0 X 12 C 8.8 ZO.....	1
7	160492	DOOR HANDLE.....	2	17	162045	NUT.....	3
8	161788	KEY	2	18	162042	SCREW.....	4
9	161942	DOOR HANDLE KIT	2	19	162031	SCREW.....	1
10	160525	LOCK L	2	20	160493	CABIN DOOR, COMPLETE	1
11	160490	TRAP LOCK/RT.....	2	21	161837	CABIN DOOR, COMPLETE	1

MODELS 192-222 MINI-EXCAVATOR
CABIN
MODELS 192-222 — WINDSHIELD WASHER




ET1920447

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	160716	WINDSHIELD WASHER	1
2	161814	BRACKET	1
3	651462	FCHC HS M6-1.0 X 16 8.8 ZO D7991.....	1
4	161666	WASHER/GR A 6.4 ZO DIN9021.....	3
5	651457	HLN INS M6-1.0 8 ZO.....	1
6	162012	PLASTIC HOSE (250 cm)	1
7	656149	CS M6-1.0 X 16 C 8.8 ZO	2
8	161676	LOCKWASHER	2
9	161613	NUT/CAGE M6.....	2
10	161995	SLIDE TERMINAL	2

**MODELS 192-222 MINI-EXCAVATOR
CABIN
MODELS 192-222 — DRIVERS SEAT**



ET1920450


* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	161874	CONTROL LEVER CONSOLE	1	20	161947	COVER	1
2	161726	DRIVER SEAT	1	21	161833	COVER	1
3	651518	SHCS HS M8-1.2 X 55 8.8 ZO D912.....	4	22	161834	COVER	1
4	161676	LOCKWASHER S8	4	23	161618	NUT/HEX DOMED CAP M8	4
5	161661	WASHER/GR A 8.4 ZO	12	24	162048	NUT	16
6	161615	NUT/CAGE M8	4	25	161634	SCREW/C'SUNK HD M5 X 16 DIN966 ZO	16
7	160407	CONSOLE/CONTROL LEVERS	1	26	161805	TUBE	2
8	160408	CONSOLE/CONTROL LEVERS	8	29	162026	SCREW	2
9	161730	PLUG	2	30	161642	WASHER/GR A 13 ZO	2
10	161832	PIN	1	31	160532	ARMREST	1
11	161831	PIN	1	32	160533	ARMREST	1
12	160611	PNEUMATIC SPRING	2	33	161728	SEAT BELT	1
13	161848	QUICK FIX	2	34	651424	CS M6-1.0 X 20 C 8.8 ZO	6
14	651390	HB M10-1.5 X 120 C 8.8 ZO	2	35	161675	LOCKWASHER S6	6
15	161651	WASHER 20	4	36	161666	WASHER/GR A 6.4 ZO DIN9021	6
16	161868	TUBE	2	37	161362	MICRO SWITCH	1
17	161403	BALL KNOB	2	39	161628	SCREW/PAN HEAD TAP	2

MODELS 192-222 MINI-EXCAVATOR

CABIN

MODELS 192-222 — CAB HEATING



ET1920455

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	161873	BRACKET	1	12	161389	HOSE (220 cm)	1
2	160531	HEATER SPINDLE	1	13	161389	HOSE (220 cm)	1
3	160530	AIR NOZZLE	2	14	162064	HOSE CLAMP	4
4	162017	RUBBER PROTECTOR (50 cm)	1	15	160860	HOSE COVER	2
5	656001	CS M8-1.2 X 20 C 8.8 ZO	4	16	161423	NUT	2
6	161676	LOCKWASHER S8	4	17	161424	WASHER	2
7	161667	WASHER/GR A 8.4 ZO	4	18	161436	FITTING	2
8	161615	NUT/CAGE M8	4	19	160950	BALL VALVE	1
9	161666	WASHER/GR A 6.4 ZO DIN9021	3	20	161477	FITTING	1
10	160406	CAB HEATER	1	21	161445	ELBOW	1
11	161630	SCREW/HEX HD TAP B5.5X19 DIN7976	3	22	161476	FITTING	1


SECTION G: DIESEL ENGINE

DIESEL ENGINE	56
MODELS 192-222 — DIESEL ENGINE	56
MODELS 192-222 — ENGINE SUSPENSION	57
MODELS 192-222 — COOLING WATER RADIATOR	58
MODELS 192-222 — AIR INTAKE	59
MODELS 192-222 — EXHAUST	60
MODELS 192-222 — FUEL LINE	61
MODELS 192-222 — ACCELERATOR	62
MODELS 192-222 — DIESEL TANK	63

MODELS 192-222 MINI-EXCAVATOR

DIESEL ENGINE

MODELS 192-222 — DIESEL ENGINE




ET1920500

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	162085	DIESEL ENGINE.....	1	14	425-35265	SEAL.....	1
2	425-36140	VENTILATOR	1	15	425-35269	THERMO SWITCH.....	1
3	425-36141	BELT	1	16	425-36142	SEAL.....	1
4	425-35259	OIL FILTER	1	17	425-36146	INJECTION VALVE.....	3
5	425-34683	THERMO SWITCH	1	18	425-35318	FUEL PUMP.....	1
6	425-34707	SEAL	1	19	425-35317	SEAL.....	1
7	425-36085	OIL PRESSURE SWITCH.....	1	20	425-36147	GENERATOR.....	1
8	425-35925	STOP SOLENOID	1	21	425-36148	REGULATOR	1
9	425-36144	CYLINDER HEAD SEAL.....	1	22	425-35274	INJECTION PUMP	1
10	425-35207	VALVE COVER SEAL	1	23	425-35376	STARTER	1
11	425-36145	OIL PAN.....	1	24	425-36149	PLUG	1
12	425-34753	OIL PLUG	1	25	161737	SEALANT	1
13	425-35264	WATER PUMP.....	1	26	160607	ENGINE SEAL KIT, COMPLETE	1

**MODELS 192-222 MINI-EXCAVATOR
DIESEL ENGINE
MODELS 192-222 — ENGINE SUSPENSION**




ET1920505

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	162081	ENGINE CARRIER	1
2	162082	ENGINE CARRIER	1
3	162080	ENGINE CARRIER	1
4	162083	ENGINE CARRIER	1
5	651393	CS M10-1.5 X 25 C 8.8 ZO	16
6	161669	LOCKWASHER S10	24
7	161641	WASHER/GR 10.5 ZO	24
8	160410	RUBBER BEARING.....	4
10	656102	HN M10-1.2 ZO	4
11	651395	CS M10-1.5 X 30 C 10.9 ZO	4

MODELS 192-222 MINI-EXCAVATOR
DIESEL ENGINE
MODELS 192-222 — COOLING WATER RADIATOR




ET1920510

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	161853	BRACKET	1	14	656149	CS M6-1.0 X 16 C 8.8 ZO.....	2
3	161615	NUT/CAGE M8	1	15	161675	LOCKWASHER S6.....	2
4	656001	CS M8-1.2 X 20 C 8.8 ZO	7	16	161856	HOSE CLAMP	1
5	161676	LOCKWASHER S8	7	18		HOSE	1
6	161667	WASHER/GR A 8.4 ZO	7	19	161857	HOSE CLAMP	2
7	161963	BRACKET	1	20	425-35271	COOLING WATER HOSE.....	1
8	161949	RUBBER PROTECTOR	2	21	425-35272	COOLING WATER HOSE.....	1
9	162016	RUBBER PROTECTOR (60 cm).....	1	22	425-34853	HOSE CLAMP	4
10	425-36150	WATER COOLER	1	23		HOSE	1
11	160424	COVER	1	24		HOSE CLAMP	2
13	425-36152	BRACKET	1	25			

**MODELS 192-222 MINI-EXCAVATOR
DIESEL ENGINE
MODELS 192-222 — AIR INTAKE**



EET1920515


* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	425-36153	AIR FILTER KIT.....	1
2	425-36154	AIR FILTER	1
3	425-36155	DUST INDICATOR	1
8	425-36101	MUFFLER	1
9	425-36156	SUCTION HOSE.....	1
10	425-36157	SUCTION HOSE.....	1
11	425-36158	HOSE	1
12	425-36159	HOSE CLAMP.....	5

MODELS 192-222 MINI-EXCAVATOR

DIESEL ENGINE

MODELS 192-222 — EXHAUST




ET1920520

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	162079	BRACKET	1	11	425-36161	SEAL.....	1
2	651393	CS M10-1.5 X 25 C 8.8 ZO	3	12	161661	WASHER/GR A 8.4 ZO	6
3	161669	LOCKWASHER S10	5	13	656048	HN M8-1.2 ZO.....	7
4	161640	WASHER/GR A 10.5 ZO	5	14	162084	BRACKET.....	1
5	425-36160	MUFFLER	1	15	651397	CS M10-1.5 X 35 C 8.8 ZO.....	2
6	656105	CS M8-1.2 X 25 C 8.8 ZO	3	16	656094	CS M8-1.2 X 30 C 8.8 ZO.....	1
7	161676	LOCKWASHER S8	11	17	160540	EXHAUST PIPE	1
8	161667	WASHER/GR A 8.4 ZO	5	18	160542	MUFFLER AND EXHAUST PIPE	1
9	160538	EXHAUST TUBE.....	1	19	161953	PIPE CLAMP ASSEMBLY	1
10	160646	SEAL	1	20	161661	WASHER/GR A 8.4 ZO	2

**MODELS 192-222 MINI-EXCAVATOR
DIESEL ENGINE
MODELS 192-222 — FUEL LINE**



ET1920525


* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	162077	FILTER HOUSING.....	1	10	651440	HB M8-1.2 X 90 C 8.8 ZO.....	1
2	425-35326	FUEL FILTER	1	11	161676	LOCKWASHER S8.....	1
4	161852	BRACKET	1	12	161661	WASHER/GR A 8.4 ZO	1
5	651391	CS M10-1.5 X 20 C 8.8 ZO	2	15	161391	HOSE (42 cm)	1
6	161669	LOCKWASHER S10	2	16	161391	HOSE (140 cm)	1
7	161640	WASHER/GR A 10.5 ZO	2	17	161391	HOSE (170 cm)	1
8	425-35973	FUEL FILTER ASSEMBLY	1	18	162065	HOSE CLAMP	6
9	425-36091	FUEL FILTER	1				

MODELS 192-222 MINI-EXCAVATOR

DIESEL ENGINE

MODELS 192-222 — ACCELERATOR




ET1920530

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	161928	THROTTLE CONTROL ASSEMBLY (INCLUDES PART NOS. 2, 3 AND 6)	1	7	161733	BRACKET	1
2	651461	FCHC HS M6-1.0 X 12 8.8 ZO D7991	4	8	656001	CS M8-1.2 X 20 C 8.8 ZO	2
3	161613	NUT/CAGE M6.....	4	9	161676	LOCKWASHER S8	2
4	160600	CABLE	1	10	161667	WASHER/GR A 8.4 ZO	2
6	161929	NIPPLE	1	11	160480	SPRING.....	1
				12	161734	BRACKET	1

**MODELS 192-222 MINI-EXCAVATOR
DIESEL ENGINE
MODELS 192-222 — DIESEL TANK**



ET1920535


* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	160513	GAS-OIL STORAGE TANK	1	10	161799	BRACKET	1
2	160436	STRAINER	1	11	161798	BRACKET	1
3	160401	TANK COVER	1	12	651436	CS M8-1.2 X 50 C 8.8 ZO	3
4	160403	KEY	1	14	161676	LOCKWASHER S8	3
5	161867	FITTING	2	15	161661	WASHER/GR A 8.4 ZO	3
6	160536	TRANSMITTER	1	16	161615	NUT/CAGE M8	1
7	162040	SCREW	6	17	161900	ISOLATION MAT	1
8	161659	WASHER/GR A 5.3 ZO DIN125	6				

SECTION H: HYDRAULIC SYSTEM

HYDRAULIC SYSTEM	66
MODELS 192-222 — HYDRAULIC PUMP.....	66
MODELS 192-222 — HYDRAULIC OIL TANK	67
MODELS 192-222 — HYDRAULIC PUMP	68
MODELS 192-222 — HYDRAULIC OIL COOLER	69
MODELS 192-222 — TRAVELING MOTORS	70
MODELS 192-222 — VALVE ANGLE.....	72
MODELS 192-222 — CONTROL VALVE.....	74
MODELS 192-222 — PILOT OIL SUPPLY UNIT.....	76
MODEL 192 — SWIVEL JOINT.....	77
MODEL 222 — SWIVEL JOINT.....	78
MODELS 192-222 — TURNING MOTOR.....	79
MODELS 192-222 — SELECTION VALVE	80
MODELS 192-222 — CONTROL LEVERS	81
MODEL 222 — LOCK VALVE.....	82
MODEL 192 — DOZER BLADE VALVE	83
MODEL 222 — DOZER BLADE VALVE	84
MODELS 192-222 — BALL VALVE	85
MODELS 192-222 — DOZER BLADE CYLINDER	86
MODELS 192-222 — BOOM OFFSET CYLINDER	87
MODELS 192-222 — BOOM CYLINDER	88
MODELS 192-222 — STICK CYLINDER	89
MODELS 192-222 — BUCKET CYLINDER	90
MODELS 192-222 — TELESCOPIC CYLINDER	91
MODEL 222 — TILT CYLINDER	92
MODELS 192-222 — DOZER BLADE VALVE INSTALLATION	93
MODELS 192-222 — HYDRAULIC OIL COOLER INSTALLATION	94
MODEL 192 — TRAVELING MOTOR INSTALLATION	95
MODEL 222 — TRAVELING MOTOR INSTALLATION	96
MODELS 192-222 — TURNING MOTOR INSTALLATION	97
MODELS 192-222 — PILOT OIL SUPPLY UNIT INSTALLATION	98
MODELS 192-222 — BOOM OFFSET CYLINDER INSTALLATION	99
MODEL 192 — DOZER BLADE CYLINDER INSTALLATION	100
MODEL 222 — DOZER BLADE CYLINDER INSTALLATION	101
MODEL 192 — TELESCOPIC CYLINDER INSTALLATION	102
MODEL 222 — TELESCOPIC CYLINDER INSTALLATION	103
MODEL 222 — TILT CYLINDER INSTALLATION	104
MODELS 192-222 — BOOM CYLINDER INSTALLATION	105
MODELS 192-222 — AUXILIARY HYDRAULICS INSTALLATION	106
MODELS 192-222 — HAND LEVER INSTALLATION	107

MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODELS 192-222 — HYDRAULIC PUMP




ET1920540

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	161954	PUMP BRACKET.....	1
2	160660	COUPLER	1
5	651396	CS M10-1.5 X 30 C 8.8 ZO	6
6	651397	CS M10-1.5 X 35 C 8.8 ZO	2
7	161669	LOCKWASHER S10	8
8	161640	WASHER/GR A 10.5 ZO	8
9	651480	SHCS HS M12-1.7 X 30 10.9 ZO D912.....	2
10	161670	LOCKWASHER S12	2
11	161642	WASHER/GR A 13 ZO	2

**MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODELS 192-222 — HYDRAULIC OIL TANK**



ET1920600


* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	161819	HYDRAULIC OIL TANK.....	1	14	161414	PLUG.....	1
2	651399	CS M10-1.5 X 40 C 8.8 ZO	1	15	161415	PLUG.....	2
3	651393	CS M10-1.5 X 25 C 8.8 ZO	2	16	160439	OIL LEVEL GLASS.....	1
4	161660	WASHER/GR A 6.4 ZO DIN125	3	17	161676	LOCKWASHER S8.....	4
5	161669	LOCKWASHER S10	3	18	160949	AIR FILTER.....	1
6	656105	CS M8-1.2 X 25 C 8.8 ZO	4	19	161485	REDUCER BUSHING.....	1
7	160404	HYDRAULIC OIL FILTER ASSEMBLY	1	20	161579	SEAL.....	1
8	160485	HYDRAULIC OIL FILTER ELEMENT	1	21	161948	RUBBER PROTECTOR (72 cm).....	1
9	160559	TUBE	1	22	161449	TEE	1
10	161490	FITTING.....	1	23	161661	WASHER/GR A 8.4 ZO.....	4
11	161432	FITTING.....	1	24	161443	ELBOW.....	2
12	161429	FITTING.....	1	25	160429	SEAL.....	1
13	161426	FITTING.....	5	26	160405	COVER	1

MODELS 192-222 MINI-EXCAVATOR

HYDRAULIC SYSTEM

MODELS 192-222 — HYDRAULIC PUMP




ET1920605

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	160592	HYDRAULIC PUMP ASSEMBLY.....	1	7	160588	GEAR PUMP.....	1
2	161565	O-RING	2	8	160608	SEAL KIT.....	1
3	161866	FLANGE.....	1	9	162099	HYDRAULIC PUMP	1
4	651475	SHCS HS M10-1.2 X 30 8.8 ZO D912.....	4	10	160609	SEAL KIT.....	1
5	161669	LOCKWASHER S10	4	11	161585	O-RING	3
6	161431	FITTING	3				

**MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODELS 192-222 — HYDRAULIC OIL COOLER**




ET1920610

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	160543	HYDRAULIC OIL COOLER.....	1
2	161432	FITTING.....	2
3	656001	CS M8-1.2 X 20 C 8.8 ZO	2
4	161676	LOCKWASHER S8	2
5	161667	WASHER/GR A 8.4 ZO	2

**MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODELS 192-222 — TRAVELING MOTORS**



ET1920615

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.


**MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODELS 192-222 — TRAVELING MOTORS**

Ref. No.	Part No.	Description	Qty. Req.
1	160633	TRAVELING GEAR	2
2	160971	FITTING	2
3	161574	O-RING	2
4	161426	FITTING	4
5	161429	FITTING	2
6	161443	ELBOW	2
8	162092	HYDRAULIC MOTOR	1
9	162091	SEAL KIT HYDRAULIC MOTOR	1
10	162090	SEAL KIT TRAVEL GEAR	1
11	162088	COVER TRAVEL GEAR	1

MODELS 192-222 MINI-EXCAVATOR

HYDRAULIC SYSTEM

MODELS 192-222 — VALVE ANGLE



ET1920620

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.


MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODELS 192-222 — VALVE ANGLE

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	161882	SHAFT.....	1	29	656102	HN M10-1.2 ZO	6
2	161881	HAND LEVER, TRAVELING	1	30	161884	LINKAGE.....	2
3	161880	HAND LEVER, TRAVELING	1	31	161886	LINKAGE.....	1
4	161883	LEVER.....	1	32	160597	HANDLE ASSEMBLY.....	1
5	162056	RETAINING RING	2	33	160598	BRACKET ASSEMBLY.....	1
6	162051	ROLL PIN.....	1	34	160599	LOCK.....	1
7	161411	LUBRICATION FITTING	2	35	161889	BRACKET.....	1
8	161422	PROTECTION CAP.....	2	36	161888	LEVER.....	3
9	160658	KNOB WITH RED SWITCH.....	1	37	161763	PLASTIC BUSHING	6
10	161764	KNOB.....	1	38	161885	SHAFT.....	1
11	162027	SET SCREW	1	39	161894	BRACKET.....	4
12	161560	BEARING.....	2	40	162058	WASHER.....	2
13	651391	CS M10-1.5 X 20 C 8.8 ZO	4	41	161895	PIN	3
14	161669	LOCKWASHER S10	6	42	161680	PIN/SPLIT 1.6 X 16 ZO D94	3
15	161640	WASHER/GR A 10.5 ZO	6	43	651397	CS M10-1.5 X 35 C 8.8 ZO	2
16	161890	BRACKET	1	44	651393	CS M10-1.5 X 25 C 8.8 ZO	3
17	162041	SCREW	4	45	161667	WASHER/GR A 8.4 ZO.....	20
18	161610	NUT/CAGE M10	2	46	161893	BAR.....	1
19	651393	CS M10-1.5 X 25 C 8.8 ZO	2	47	161892	LEVER.....	1
21	161797	AUXILIARY HYDRAULICS PEDAL	1	48	161891	BRACKET	2
22	161639	HEX/FIT BT W/SHT THD M8X50 ZO DIN610..	1	49	656102	HN M10-1.2 ZO	3
23	651458	HLN INS M8-1.2 8 ZO	4	50	160603	SPRING.....	1
24	162073	YOKE	1	51	656001	CS M8-1.2 X 20 C 8.8 ZO	2
25	161887	LINKAGE	1	52	161676	LOCKWASHER S8	10
26	656048	HN M8-1.2 ZO	2	53	651448	HLN INS M10-1.5 ZO	5
27	162072	BALL AND SOCKET	1	54	656093	CS M8-1.2 X 16 C 8.8 ZO	8
28	162074	YOKE	6	55		WASHER.....	2

MODELS 192-222 MINI-EXCAVATOR HYDRAULIC SYSTEM

HYDRAULIC SYSTEM

MODELS 192-222 — CONTROL VALVE




ET1920625

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	160565	CONTROL VALVE	1	15	161498	FITTING.....	1
2	161501	FITTING	6	16	161449	TEE	3
3	161439	ELBOW	2	17	161447	ELBOW	2
4	161443	ELBOW	3	18	161441	REDUCTION JOINT	1
5	161571	O-RING	9	19	161497	FITTING.....	1
6	161590	O-RING	8	20	161510	NON RETURN VALVE	1
7	161585	O-RING	2	21	160560	FITTING.....	7
8	161496	FITTING.....	4	22	161428	FITTING.....	4
9	161486	FITTING.....	4	23	161429	FITTING.....	2
10	161509	FITTING	2	24	161463	FITTING.....	1
11	161471	TEE	2	25	161467	TEE	1
12	161493	REDUCTION JOINT	2	26	161470	REDUCTION JOINT	2
13	161450	TEE	1	27	161446	ELBOW	1
14	161514	MEASURE JOINT	1	28	161508	FITTING.....	1

**MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODELS 192-222 — CONTROL VALVE**




ET1920627

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	160573	SECTION/CONTROL VALVE	1	10	160581	SECTION/CONTROL VALVE	1
2	161360	PRESSURE RELIEF VALVE, SECONDARY... .	3	11	161359	PRESSURE RELIEF VALVE, PRIMARY.....	2
3	160574	SECTION/CONTROL VALVE	1	13	160582	SPRING DISC.....	3
4	160575	SECTION/CONTROL VALVE	1	14	160583	SCREW MOUNT.....	3
5	160576	SECTION/CONTROL VALVE	1	15	160586	SEAL KIT.....	1
6	160577	SECTION/CONTROL VALVE	1	16	160584	SECTION/CONTROL VALVE	1
7	160578	SECTION/CONTROL VALVE	1	17	161871	CAP.....	3
8	160579	SECTION/CONTROL VALVE	1	18	160585	SPRING DISC.....	4
9	160580	SECTION/CONTROL VALVE	1				

MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODELS 192-222 — PILOT OIL SUPPLY UNIT




ET1920630

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	160594	PILOT OIL SUPPLY UNIT	1	11	161462	TEE	1
2	161567	SEAL	1	12	161514	MEASURE JOINT	2
3	160437	ACCUMULATOR	1	13	161438	ELBOW	3
4	161824	BRACKET	1	14	161448	TEE	1
5	656001	CS M8-1.2 X 20 C 8.8 ZO	2	15	161443	ELBOW	1
6	161676	LOCKWASHER S8	2	16	161414	PLUG	2
7	161667	WASHER/GR A 8.4 ZO	2	17	161443	ELBOW	2
8	651395	CS M10-1.5 X 30 C 10.9 ZO	1	18	161426	FITTING	1
9	161669	LOCKWASHER S10	1	19	160571	SOLENOID SWITCH	2
10	161641	WASHER/GR 10.5 ZO	1	20	160572	PLUG	1

**MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODEL 192 — SWIVEL JOINT**



ET1920635


* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	161920	SWIVEL JOINT	1
2	161429	FITTING.....	8
3	161426	FITTING.....	11
4	161458	FITTING.....	1
5	161448	TEE	2
6	160637	SEAL KIT.....	1

MODELS 192-222 MINI-EXCAVATOR

HYDRAULIC SYSTEM

MODEL 222 — SWIVEL JOINT




ET1920640

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	162115	SWIVEL JOINT	1
2	161429	FITTING	8
3	161426	FITTING	16
4	161448	TEE	2
5	161445	ELBOW	5
6	160698	SWIVEL DRIVE GASKETS	1

**MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODELS 192-222 — TURNING MOTOR**




ET1920645

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	160595	HYDRAULIC MOTOR	1	6	160570	SEAL.....	1
2	161428	FITTING.....	2	7	160604	SEAL KIT.....	1
3	161463	FITTING.....	1	8	160569	PRESSURE LIMITING VALVE	1
4	161446	ELBOW	2	9	160567	SHOCK VALVE	1
5	161471	TEE	1				

MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODELS 192-222 — SELECTION VALVE




ET1920650

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	160568	SELECTION VALVE.....	1
2	162028	SCREW	2
3	161426	FITTING	1
4	161428	FITTING	4
5	161427	FITTING	2
6	161444	ELBOW	2
7	161675	LOCKWASHER S6	2
8	161660	WASHER/GR A 6.4 ZO DIN125.....	2
9	160438	PLUG	1

**MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODELS 192-222 — CONTROL LEVERS**




ET1920655

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	161180	CONTROL LEVER.....	1	7	160487	SEAL KIT.....	1
2	160590	CHECK VALVE LEFT.....	1	8	160486	SEAL KIT.....	1
3	161426	FITTING.....	12	9	160463	JOYSTICK.....	1
4	651507	SHCS HS M6-1 X 20 8.8 ZO D912	8	10	160469	HANDLE	1
6	161660	WASHER/GR A 6.4 ZO DIN125	8	11	160470	BELLOWS.....	1

MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODEL 222 — LOCK VALVE




ET1920660

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	160667	NON RETURN VALVE	1
2	161426	FITTING	4
3	162123	SCREW	2
4	161674	LOCKWASHER S5	2
5	161665	WASHER/GR A 5.3 ZO DIN9021.....	2
6	161438	ELBOW	2

**MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODEL 192 — DOZER BLADE VALVE**




ET1920665

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	160621	VALVE DOZER BLADE	1	12	161667	WASHER/GR A 8.4 ZO.....	4
2	161427	FITTING.....	5	13	161466	ELBOW.....	1
3	161429	FITTING.....	1	14	161448	TEE	1
4	161566	SEAL	1	15	161877	COVER	1
5	161357	CONNECTOR	1	16	161615	NUT/CAGE M8	4
6	160651	THROTTLE	1	17	160397	ACTIVATOR COMPLETE	2
7	161514	MEASURE JOINT	1	20	161821	LEVER.....	1
8	161415	PLUG	1	21	161955	T-HANDLE.....	1
9	161463	FITTING.....	1	22	656001	CS M8-1.2 X 20 C 8.8 ZO	6
10	651437	HB M8-1.2 X 60 C 8.8 ZO	4	25	161806	LEVER.....	1
11	161676	LOCKWASHER S8	10	26	161903	HANDLE	1

MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODEL 222 — DOZER BLADE VALVE




ET1920670

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	160687	DOZER BLADE VALVE	1	13	161466	ELBOW	1
2	161427	FITTING	7	14	161448	TEE	1
3	161429	FITTING	1	15	162086	COVER	1
4	161566	SEAL	1	16	161615	NUT/CAGE M8	4
5	161357	CONNECTOR	1	17	160397	ACTIVATOR COMPLETE	3
6	160651	THROTTLE	1	20	161821	LEVER	1
7	161514	MEASURE JOINT	1	21	161955	T-HANDLE	1
8	161415	PLUG	1	22	656001	CS M8-1.2 X 20 C 8.8 ZO	7
9	161463	FITTING	1	25	161806	LEVER	1
10	651437	HB M8-1.2 X 60 C 8.8 ZO	4	26	161903	HANDLE	2
11	161676	LOCKWASHER S8	11	27	162078	LEVER	1
12	161667	WASHER/GR A 8.4 ZO	4				

**MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODELS 192-222 — BALL VALVE**




ET1920675

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	160972	BALL VALVE	1
2	651461	FCHC HS M6-1.0 X 12 8.8 ZO D7991	2
3	161675	LOCKWASHER S6	2
4	161666	WASHER/GR A 6.4 ZO DIN9021	2
5	161430	FITTING.....	2

MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODELS 192-222 — DOZER BLADE CYLINDER




ET1920700

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	160672	DOZER BLADE CYLINDER.....	1	12	161411	LUBRICATION FITTING	1
2	161934	CYLINDER TUBE	1	13	161413	LUBRICATION FITTING	1
3	160666	PISTON ROD.....	1	14	161416	PROTECTION CAP.....	2
4	160558	GLAND.....	1	15	160471	TUBE BURST COVER	1
5	160556	PISTON	1	16	161427	FITTING.....	2
6	161400	SET SCREW	1	17	161756	COVER	1
7	160703	SEAL KIT	1	18	161757	COVER	1
10	161558	BEARING.....	2	19	651430	CS M8-1.2 X 12 C 8.8 ZO	4
11	162059	RETAINING RING	2	20	656110	LW REG M8 ZO.....	4

**MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODELS 192-222 — BOOM OFFSET CYLINDER**




ET1920705

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	160680	BOOM OFFSET CYLINDER	1	9	160684	PISTON.....	1
2	161935	CYLINDER TUBE	1	10	161400	SET SCREW.....	1
3	160686	PISTON ROD.....	1	11	162061	BALL EXPANDER.....	1
4	160681	GLAND.....	1	12	160705	SEAL KIT.....	1
5	160683	RING	1	20	161545	BUSHING	2
6	160682	RING	1	21	161411	LUBRICATION FITTING	1
7	161410	WASHER	1	22	161416	PROTECTION CAP	1
8	160685	BUSHING.....	1	23	161427	FITTING	2

MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODELS 192-222 — BOOM CYLINDER




ET1920710

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	160669	BOOM CYLINDER.....	1	13	160700	SEAL KIT.....	1
2	162114	CYLINDER HOUSING.....	1	20	161544	BUSHING	2
3	160627	PISTON ROD.....	1	21	161411	LUBRICATION FITTING	2
4	160678	GLAND.....	1	22	161422	PROTECTION CAP.....	2
5	160464	RING	1	23	161429	FITTING.....	2
6	160465	RING	1	24	161754	COVER	1
7	161408	WASHER.....	1	25	656001	CS M8-1.2 X 20 C 8.8 ZO.....	2
8	160466	BUSHING.....	1	26	656110	LW REG M8 ZO.....	2
9	160673	PISTON	1	28	162087	GLIDE	1
10	161400	SET SCREW	1	29	161650	WASHER/GR A 19 ZO DIN125.....	2
11	162061	BALL EXPANDER	1	30	651468	PIN/SPRING M8 X 70 D1481	1
12	162060	BALL EXPANDER	1				

**MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODELS 192-222 — STICK CYLINDER**




ET1920715

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	160671	HANDLE CYLINDER.....	1	11	162061	BALL EXPANDER.....	1
2	162113	CYLINDER HOUSING.....	1	12	160702	SEAL KIT.....	1
3	160625	PISTON ROD.....	1	20	161544	BUSHING	2
4	160676	GLAND.....	1	21	161411	LUBRICATION FITTING	2
5	160464	RING	1	22	161422	PROTECTION CAP	2
6	160465	RING	1	23	161429	FITTING	2
7	161408	WASHER.....	1	24	161863	COVER	1
8	160466	BUSHING.....	1	25	656001	CS M8-1.2 X 20 C 8.8 ZO.....	2
9	160675	PISTON	1	26	656110	LW REG M8 ZO	2
10	161400	SET SCREW	1				

MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODELS 192-222 — BUCKET CYLINDER




ET1920720

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	160670	BUCKET CYLINDER	1	10	161544	BUSHING	2
2	162112	CYLINDER HOUSING	1	11	161411	LUBRICATION FITTING	2
3	160626	PISTON ROD	1	12	161422	PROTECTION CAP	2
4	160677	GLAND	1	13	161440	ELBOW	2
5	160674	PISTON	1	14	161864	COVER	1
6	161400	SET SCREW	1	15	656001	CS M8-1.2 X 20 C 8.8 ZO	2
7	160701	SEAL KIT	1	16	656110	LW REG M8 ZO	2
8	162061	BALL EXPANDER	1				

MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODELS 192-222 — TELESCOPIC CYLINDER




ET1920725

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	160679	TELESCOPIC CYLINDER.....	1
2	162111	CYLINDER HOUSING.....	1
3	160618	PISTON ROD.....	1
4	160617	GLAND.....	1
5	160620	PISTON	1
6	161401	SET SCREW	1
7	160704	SEAL KIT	1
10	161427	FITTING	2
12	160616	COVER	1
13	651468	PIN/SPRING M8 X 70 D1481	1

MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODEL 222 — TILT CYLINDER




ET1920730

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	160668	TILT CYLINDER.....	1
2	162110	CYLINDER HOUSING.....	1
3	160664	PISTON ROD.....	1
4	160665	GLAND.....	1
5	160787	PISTON	1
6	162060	BALL EXPANDER	1
7	160699	SEAL KIT.....	1
10	161426	FITTING	2
11	161443	ELBOW	2

**MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODELS 192-222 — DOZER BLADE VALVE INSTALLATION**




ET1920800

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	160566	HOSE.....	1
2	162071	HOSE CLAMP	2
3	161318	HIGH PRESSURE HOSE	1
4	161316	HIGH PRESSURE HOSE	1
5	161317	HIGH PRESSURE HOSE	1
6	161309	HIGH PRESSURE HOSE	1
7	161298	HIGH PRESSURE HOSE	1

MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODELS 192-222 — HYDRAULIC OIL COOLER INSTALLATION




ET1920805

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	161326	HIGH PRESSURE HOSE	1
2	161327	HIGH PRESSURE HOSE	1
3	161325	HIGH PRESSURE HOSE	1

**MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODEL 192 — TRAVELING MOTOR INSTALLATION**




ET1920810

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	161307	HIGH PRESSURE HOSE	4
2	161251	HIGH PRESSURE HOSE	1
3	161263	HIGH PRESSURE HOSE	1
4	161259	HIGH PRESSURE HOSE	1
5	161295	HIGH PRESSURE HOSE	4
6	162009	HOSE COVERING (140 cm)	1
7	161229	HIGH PRESSURE HOSE	1
8	161245	HIGH PRESSURE HOSE	1

MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODEL 222 — TRAVELING MOTOR INSTALLATION




ET1920815

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	161296	HIGH PRESSURE HOSE	1	7	162009	HOSE COVERING (140 cm).....	1
2	161306	HIGH PRESSURE HOSE	1	8	161259	HIGH PRESSURE HOSE	1
3	161301	HIGH PRESSURE HOSE	1	9	161297	HIGH PRESSURE HOSE	2
4	161308	HIGH PRESSURE HOSE	1	10	161295	HIGH PRESSURE HOSE	2
5	161245	HIGH PRESSURE HOSE	1	11	161289	HIGH PRESSURE HOSE	1
6	161288	HIGH PRESSURE HOSE	1	12	161245	HIGH PRESSURE HOSE	1

**MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODELS 192-222 — TURNING MOTOR INSTALLATION**




ET1920820

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	161293	HIGH PRESSURE HOSE	2
2	161312	HIGH PRESSURE HOSE	1
3	161321	HIGH PRESSURE HOSE	1
4	161237	HIGH PRESSURE HOSE	1

MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODELS 192-222 — PILOT OIL SUPPLY UNIT INSTALLATION




ET1920825

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	161231	HIGH PRESSURE HOSE	1
2	161262	HIGH PRESSURE HOSE	1
3	161233	HIGH PRESSURE HOSE	1
4	161240	HIGH PRESSURE HOSE	1
5	161258	HIGH PRESSURE HOSE	1
6	161244	HIGH PRESSURE HOSE	1

MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODELS 192-222 — BOOM OFFSET CYLINDER INSTALLATION




ET1920830

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	161290	HIGH PRESSURE HOSE	2
2	161231	HIGH PRESSURE HOSE	2

MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODEL 192 — DOZER BLADE CYLINDER INSTALLATION




ET1920835

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	161248	HIGH PRESSURE HOSE	1
2	161260	HIGH PRESSURE HOSE	1
3	161242	HIGH PRESSURE HOSE	1
4	161241	HIGH PRESSURE HOSE	1
5	162515	HOSE CLAMP	2
6	162066	COVER	2
7	651508	SHCS HS M6-1 X 25 8.8 ZO D912	4

**MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODEL 222 — DOZER BLADE CYLINDER INSTALLATION**




ET1920840

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	161268	HIGH PRESSURE HOSE	1
2	161249	HIGH PRESSURE HOSE	2
3	161246	HIGH PRESSURE HOSE	1
4	162515	HOSE CLAMP	2
5	162066	COVER	2
6	651508	SHCS HS M6-1 X 25 8.8 ZO D912	4

MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODEL 192 — TELESCOPIC CYLINDER INSTALLATION




ET1920845

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	161250	HIGH PRESSURE HOSE	1
2	161257	HIGH PRESSURE HOSE	1
3	161243	HIGH PRESSURE HOSE	2

**MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODEL 222 — TELESCOPIC CYLINDER INSTALLATION**




ET1920850

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	161261	HIGH PRESSURE HOSE	2
3	161232	HIGH PRESSURE HOSE	1
4	161234	HIGH PRESSURE HOSE	1

MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODEL 222 — TILT CYLINDER INSTALLATION




ET1920855

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	161234	HIGH PRESSURE HOSE	1
2	161247	HIGH PRESSURE HOSE	1
3	161266	HIGH PRESSURE HOSE	1
4	161261	HIGH PRESSURE HOSE	2
5	161267	HIGH PRESSURE HOSE	1

MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODELS 192-222 — BOOM CYLINDER INSTALLATION




ET1920860

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	161291	HIGH PRESSURE HOSE	2
2	161388	HOSE.....	2
3	161556	HOSE CLAMP	1
4	162069	COVER	1
5	651426	CS M6-1.0 X 35 C 8.8 ZO	1
6	161292	HIGH PRESSURE HOSE	4
7	161442	REDUCTION JOINT	4
8	161299	HIGH PRESSURE HOSE	2
9	161300	HIGH PRESSURE HOSE	2
11	160514	HOSE CLAMP	1
12	161801	COVER	1
13	651428	CS M6-1.0 X 50 C 8.8 ZO	4
14	161675	LOCKWASHER S6	4
15	161660	WASHER/GR A 6.4 ZO DIN125	4

MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODELS 192-222 — AUXILIARY HYDRAULICS INSTALLATION




ET1920865

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	161319	HIGH PRESSURE HOSE	1
2	161304	HIGH PRESSURE HOSE	1
3	161303	HIGH PRESSURE HOSE	1
4	161320	HIGH PRESSURE HOSE	1
5	161302	HIGH PRESSURE HOSE	1
6	161305	HIGH PRESSURE HOSE	1

**MODELS 192-222 MINI-EXCAVATOR
HYDRAULIC SYSTEM
MODELS 192-222 — HAND LEVER INSTALLATION**



ET1920870


* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	161222	HIGH PRESSURE HOSE	2
2	161354	HIGH PRESSURE HOSE	4
3	161262	HIGH PRESSURE HOSE	1
4	161219	HIGH PRESSURE HOSE	2
5	161221	HIGH PRESSURE HOSE	2
6	161220	HIGH PRESSURE HOSE	1
7	161465	TEE	1
10	162011	HOSE COVERING (142 cm).....	1
11	162011	HOSE COVERING (123 cm).....	1

SECTION I: ELECTRICAL SYSTEM

ELECTRICAL SYSTEM	110
MODELS 192-222 — ELECTRICAL INSTALLATION 1	110
MODELS 192-222 — ELECTRICAL INSTALLATION 2	111
MODELS 192-222 — BATTERY INSTALLATION	112
MODELS 192-222 — CONTROL BOARD	113
MODELS 192-222 — RELAY BOX	114
MODELS 192-222 — HEADLIGHTS	115
MODELS 192-222 — HORN	116

MODELS 192-222 MINI-EXCAVATOR
ELECTRICAL SYSTEM
MODELS 192-222 — ELECTRICAL INSTALLATION 1




ET1920900

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	160659	MAIN WIRING HARNESS	1
3	161997	SLIDE TERMINAL	9
4	162002	PLUG	3
5	161995	SLIDE TERMINAL	3
6	162002	PLUG	1
7	161999	PLUG	1
8	162000	PLUG	1
9	161363	SWITCH	1
10	161379	WIRING HARNESS	1
11	161732	SOCKET	1

**MODELS 192-222 MINI-EXCAVATOR
ELECTRICAL SYSTEM
MODELS 192-222 — ELECTRICAL INSTALLATION 2**



ET1920905


* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	160659	MAIN WIRING HARNESS.....	1
2	651505	SHCS HS M5-0.8 X 20 8.8 ZO D912	1
3	161665	WASHER/GR A 5.3 ZO DIN9021	1
4	656100	HN M5-.8 ZO	1
5	161998	FUSE.....	1
6	162003	PLUG.....	2
7	656048	HN M8-1.2 ZO.....	1
8	162001	PLUG.....	1
9	162004	PLUG.....	1
10	425-36149	PLUG.....	1
11	160419	REGULATOR	1
13	162021	SCREW.....	2
14	161665	WASHER/GR A 5.3 ZO DIN9021	2
15	656100	HN M5-.8 ZO	2
16	161355	RELAY DIODE.....	1
17	161858	FUSE HOUSING.....	1

MODELS 192-222 MINI-EXCAVATOR

ELECTRICAL SYSTEM

MODELS 192-222 — BATTERY INSTALLATION




ET1920910

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	161815	BATTERY CARRIER	1	10	161720	CLAMP	1
2	656001	CS M8-1.2 X 20 C 8.8 ZO	1	11	656004	HB M8-1.2 X 55 C 8.8 ZO	1
3	656094	CS M8-1.2 X 30 C 8.8 ZO	2	12	651458	HLN INS M8-1.2 8 ZO	1
4	161667	WASHER/GR A 8.4 ZO	6	15	161850	CABLE, POSITIVE	1
5	161676	LOCKWASHER S8	3	16	161994	PROTECTION CAP	1
6	656048	HN M8-1.2 ZO	2	17	161851	CABLE, NEGATIVE	1
9	161993	BATTERY.....	1	18	162008	CABLE, GROUND.....	1

**MODELS 192-222 MINI-EXCAVATOR
ELECTRICAL SYSTEM
MODELS 192-222 — CONTROL BOARD**



ET1920915


* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	160534	CONTROL BOARD	1	8	161996	FRAME	1
2	160535	CONTROL BOARD	1	9	161380	IGNITION SWITCH ASSEMBLY.....	1
3	161364	FUSE BOX.....	1	10	161368	COVER	1
4	161374	FUSE	1	11	160713	KEY.....	1
5	161369	SWITCH.....	1	13	161398	PLUG.....	1
6	161370	SWITCH.....	1	14	161849	WIRING HARNESS.....	1
7	161372	SWITCH.....	1				

MODELS 192-222 MINI-EXCAVATOR

ELECTRICAL SYSTEM

MODELS 192-222 — RELAY BOX




ET1920920

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
1	160890	RELAY	1	8	656100	HN M5-8 ZO	5
2	160821	RELAY	1	10	161809	RELAY COVER	1
3	160891	RELAY	1	11	161943	PVC-EDGE PROTECTION (25 cm)	1
4	160889	RELAY	1	12	651424	CS M6-1.0 X 20 C 8.8 ZO	2
5	651505	SHCS HS M5-0.8 X 20 8.8 ZO D912.....	3	13	161675	LOCKWASHER S6	2
6	162021	SCREW	2	14	161666	WASHER/GR A 6.4 ZO DIN9021	2
7	161665	WASHER/GR A 5.3 ZO DIN9021.....	5				

**MODELS 192-222 MINI-EXCAVATOR
ELECTRICAL SYSTEM
MODELS 192-222 — HEADLIGHTS**




ET1920925

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	160537	HEADLIGHT HOUSING.....	1
2	161367	HALOGEN LAMP.....	1
3	161379	WIRING HARNESS.....	2
4	161995	SLIDE TERMINAL	2
5	161997	SLIDE TERMINAL	2
6	162002	PLUG	1

**MODELS 192-222 MINI-EXCAVATOR
ELECTRICAL SYSTEM
MODELS 192-222 — HORN**



ET1920930

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	161366	HORN.....	1
2	161616	NUT/CAGE M8.....	1
3	656001	CS M8-1.2 X 20 C 8.8 ZO	1
4	161676	LOCKWASHER S8	1
5	161661	WASHER/GR A 8.4 ZO	1

SECTION J: TOOLS


TOOLS	118
MODELS 192-222 — TOOLS	118

SECTION J: TOOLS

MODELS 192-222 MINI-EXCAVATOR

TOOLS

MODELS 192-222 — TOOLS



ET1921010

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.
1	161989	TOOL ORGANIZER.....	1
2	161990	SCREW DRIVERS AND WRENCHES	1
3	161991	HAMMER.....	1
4	161992	GREASE GUN.....	1
5	161988	TOOL KIT.....	1

SECTION K: DECALS


DECALS	120
MODEL 192 — DECALS	120
MODEL 222 — DECALS	121

SECTION K: DECALS

MODELS 192-222 MINI-EXCAVATOR

DECALS

MODEL 192 — DECALS




ET1921000

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
2	161976	DECAL.....	2	15	161973	DECAL.....	1
3	161985	DECAL.....	2	16	161984	DECAL.....	1
4	161965	DECAL.....	1	20	162013	ID-PLATE (BIG).....	1
5	162119	DECAL.....	2	21	161967	DECAL.....	1
7	161970	DECAL.....	2	22	161966	DECAL.....	1
8	161974	DECAL.....	2	23	161969	DECAL.....	1
9	162121	DECAL.....	2	24	161968	DECAL.....	1
10	161987	DECAL.....	2	29	161972	DECAL.....	1
11	161986	DECAL.....	1	30	162117	DECAL.....	1
12	161981	DECAL.....	4	31	162118	DECAL.....	1
13	161982	DECAL.....	4	32	162100	DECAL SET.....	1
14	161983	DECAL.....	1				

**MODELS 192-222 MINI-EXCAVATOR
DECALS
MODEL 222 — DECALS**



ET1921005

* Reference numbers marked with an asterisk (*) indicate that the individual parts of the assembly are listed later in this section. Refer to the Table of Contents for locations of specific assemblies.

Ref. No.	Part No.	Description	Qty. Req.	Ref. No.	Part No.	Description	Qty. Req.
2	161976	DECAL.....	2	15	161973	DECAL	1
3	161985	DECAL.....	2	16	161984	DECAL	1
4	161965	DECAL.....	1	20	162013	ID-PLATE (BIG).....	1
5	162120	DECAL.....	2	21	161967	DECAL	1
7	161970	DECAL.....	2	22	161966	DECAL	1
8	161974	DECAL.....	2	23	161969	DECAL	1
9	161970	DECAL.....	2	24	161968	DECAL	1
10	161987	DECAL.....	2	29	161972	DECAL	1
11	161986	DECAL.....	1	30	162117	DECAL	1
12	161981	DECAL.....	4	31	162118	DECAL	1
13	161982	DECAL.....	4	32	162116	DECAL SET	1
14	161983	DECAL.....	1				

NUMERICAL INDEX

Part No.	Page No.	Ref. No.	Part No.	Page No.	Ref. No.	Part No.	Page No.	Ref. No.	Part No.	Page No.	Ref. No.
160397	83	17	160574	75	3	160669	92	1	161246	96	12
	84	17	160575	75	4		33	30	161247	101	3
160400	23	16	160576	75	5	160670	88	1	161248	104	2
160401	63	3	160577	75	6		35	10	161249	100	1
160402	23	13	160578	75	7	160671	90	1	161250	101	2
160403	63	4	160579	75	8		34	10	161251	102	1
160404	67	7	160580	75	9	160672	89	1	161257	95	2
160405	67	26	160581	75	10		14	6	161258	102	2
160406	54	10	160582	75	13	160673	86	1	161259	98	5
160407	53	7	160583	75	14	160674	88	9		95	4
160408	53	8	160584	75	16	160675	90	5		96	8
160409	19	31	160585	75	18	160676	89	9	161260	100	2
160410	57	8	160586	75	15		89	4	161261	103	1
160419	111	11	160588	68	7	160677	90	4		104	4
160424	58	11	160590	81	2	160678	88	4	161262	98	2
160429	67	25	160592	68	1	160679	7	4		107	3
160436	63	2	160594	76	1		9	4	161263	95	3
160437	76	3	160595	19	23	160680	91	1	161266	104	3
160438	80	9		79	1		19	17	161267	104	5
160439	67	16	160596	27	3		87	1	161268	101	1
160458	34	21	160597	73	32	160681	87	4	161288	96	6
160459	34	23	160598	73	33	160682	87	6	161289	96	11
160463	81	9	160599	73	34	160683	87	5	161290	99	1
160464	88	5	160600	62	4	160684	87	9	161291	105	1
160465	88	6	160602	28	11	160686	87	3	161293	97	1
160466	88	8	160604	73	50	160687	84	1	161295	95	5
	89	8	160607	79	7	160688	34	12		96	10
	89	8		56	26		35	14	161296	96	1
160469	81	10	160608	68	8	160689	34	11	161297	96	9
160470	81	11	160609	68	10	160690	33	31	161298	93	7
160471	86	15	160611	53	12	160691	19	19	161299	105	8
160480	62	11	160612	27	20	160692	33	33	161300	105	9
160485	67	8	160616	7	5		34	13	161301	96	3
160486	81	8		9	5	160693	33	32	161302	106	5
160487	81	7		91	12	160694	35	17	161303	106	3
160488	41	5	160617	91	4	160695	35	12	161304	106	2
160489	47	1	160618	91	3	160696	35	11	161305	106	6
160490	51	11	160620	91	5	160697	19	12	161306	96	2
160491	51	12	160621	83	1	160698	78	6	161307	95	1
160492	51	7	160622	7	6	160699	92	7	161308	96	4
160493	51	20		9	6	160700	88	13	161309	93	6
160494	45	10	160624	7	18	160701	90	7	161312	97	2
160495	45	1		9	18	160702	89	12	161316	93	4
160497	45	20	160625	89	3	160703	86	7	161317	93	5
160513	63	1	160626	90	3	160704	91	7	161318	93	3
160514	105	11	160627	88	3	160705	87	12	161319	106	1
160515	19	27	160628	33	7	160711	27	7	161320	106	4
160516	7	9	160629	33	8	160712	51	13	161321	97	3
	9	9	160630	33	6	160713	113	11	161325	94	3
160517	7	11	160631	33	9	160716	52	1	161326	94	1
	9	11	160632	33	10	160779	9	26	161327	94	2
160518	10	2	160633	7	16	160780	9	27	161353	34	22
160520	10	6		9	16	160787	92	5	161354	107	2
160521	10	9		71	1	160821	114	2	161355	111	16
160522	11	3	160634	7	17	160860	54	15	161357	83	5
160523	10	10		9	17	160862	34	20		84	5
160525	51	10	160635	10	1	160865	7	21	161359	75	11
160526	41	3		11	1		9	21	161360	75	2
160527	41	4	160637	77	6	160889	114	4	161362	53	37
160529	43	6	160638	7	10	160890	114	1	161363	110	9
160530	54	3		9	10	160891	114	3	161364	113	3
160531	54	2	160639	45	9	160949	67	18	161366	116	1
160532	53	31	160640	45	8	160950	54	19	161367	115	2
160533	53	32	160641	45	7	160971	71	2	161368	113	10
160534	113	1	160643	23	19	160972	85	1	161369	113	5
160535	113	2	160644	19	32	161180	81	1	161370	113	6
160536	63	6	160646	60	10	161219	107	4	161372	113	7
160537	115	1	160651	83	6	161220	107	6	161374	113	4
160538	60	9		84	6	161221	107	5	161379	110	10
160540	60	17	160653	27	1	161222	107	1		115	3
160542	60	18	160654	14	2	161229	95	7	161380	113	9
160543	69	1	160655	14	4	161231	98	1	161388	105	2
160556	86	5	160656	15	3		99	2	161389	54	12
160558	86	4	160658	73	9	161232	103	3		54	13
160559	67	9	160659	110	1	161233	98	3	161391	61	15
160560	74	21		111	1	161234	103	4		61	16
160565	74	1	160660	66	2		104	1		61	17
160566	93	1	160661	35	1	161237	97	4	161392	21	8
160567	79	9	160662	35	7	161240	98	4		21	9
160568	80	1	160663	35	8	161241	100	4	161396	51	4
160569	79	8	160664	92	3	161242	100	3	161398	113	13
160570	79	6	160665	92	4	161243	102	3	161399	7	7
160571	76	19	160666	86	3	161244	98	6		9	7
160572	76	20	160667	82	1	161245	95	8	161400	21	10
160573	75	1	160668	9	25		96	5		86	6

NUMERICAL INDEX

Part No.	Page No.	Ref. No.	Part No.	Page No.	Ref. No.	Part No.	Page No.	Ref. No.	Part No.	Page No.	Ref. No.
	87	10	161442	105	7	161610	23	11	161667	20	7
	88	10	161443	67	24		73	18		22	7
	89	10		71	6	161613	27	35		27	41
	90	6		74	4		52	9		54	7
161401	91	6		76	15		62	3		58	6
161403	53	17		76	17	161614	29	4		60	8
161405	15	4		92	11	161615	22	6		62	10
	35	18	161444	80	6		53	6		69	5
161406	34	2	161445	54	21		54	8		73	45
	35	2		78	5		58	3		76	7
161407	33	2	161446	74	27		63	16		83	12
161408	88	7		79	4		83	16		84	12
	89	7	161447	74	17		84	16		112	4
161410	87	7	161448	76	14	161616	116	2	161669	7	34
161411	14	7		77	5	161618	45	17		9	45
	19	9		78	4		53	23		23	8
	21	4		83	14	161623	7	30		27	5
	33	4		84	14		9	29		57	6
	34	5	161449	67	22		10	5		60	3
	35	5		74	16	161627	19	33		61	6
	73	7	161450	74	13	161628	53	39		66	7
	86	12	161458	77	4	161630	54	11		67	5
	87	21	161461	21	6	161634	41	23		68	5
	88	21	161462	76	11		53	25		73	14
	89	21	161463	74	24	161635	7	33		76	9
	90	11		79	3		9	44	161670	39	4
161412	9	32		83	9	161639	73	22		66	10
161413	86	13		84	9	161640	7	41	161671	7	36
161414	67	14	161465	107	7		9	52		9	47
	76	16	161466	83	13		23	9	161672	9	31
161415	67	15		84	13		60	4	161674	23	18
	83	8	161467	74	25		61	7		82	4
	84	8	161468	21	12		66	8	161675	21	3
161416	9	33	161469	21	11		73	15		27	33
	14	8	161470	74	26	161641	27	22		29	3
	21	5	161471	74	11		57	7		53	35
	86	14		79	5		76	10		58	15
	87	22	161476	54	22	161642	27	12		80	7
161421	11	2	161477	54	20		27	18		85	3
161422	19	10	161485	67	19		53	30		105	14
	33	5	161486	74	9		66	11		114	13
	34	6	161490	67	10	161643	7	29	161676	7	35
	35	6	161493	74	12		9	41		9	46
	73	8	161496	74	8		19	3		20	6
	88	22	161497	74	19		27	17		22	8
	89	22	161498	74	15	161645	39	5		27	27
	90	12	161501	74	2	161647	7	42		52	8
161423	54	16	161508	74	28		9	53		53	4
161424	54	17	161509	74	10	161649	7	43		54	6
161426	67	13	161510	74	20		9	54		58	5
	71	4	161514	74	14	161650	88	29		60	7
	76	18		76	12	161651	53	15		61	11
	77	3		83	7	161656	19	13		62	9
	78	3		84	7	161657	14	5		63	14
	80	3	161539	33	3	161659	23	15		67	17
	81	3		34	4		42	9		69	4
	82	2	161540	35	4		63	8		73	52
161427	92	10	161541	19	8	161660	41	27		76	6
	80	5	161543	34	3		67	4		83	11
	83	2		35	3		80	8		84	11
	84	2	161544	88	20		81	6		112	5
	86	16		89	20		105	15		116	4
	87	23		90	10	161661	7	31	161680	73	42
161428	91	10	161545	87	20		9	42	161681	14	3
	74	22	161552	33	11		27	26	161720	112	10
	79	2	161553	33	14		27	38	161722	21	1
161429	80	4	161555	33	17		45	16	161724	7	20
	67	12	161556	105	3		53	5		9	20
	71	5	161557	33	20		60	12	161726	53	2
	74	23	161558	86	10		60	20	161728	53	33
	77	2	161559	11	4		61	12	161730	53	9
	78	2	161560	73	12		63	15	161732	110	11
	83	3	161561	10	8		67	23	161733	62	7
	84	3	161564	10	7		116	5	161734	62	12
	88	23	161565	68	2	161663	27	6	161737	56	25
	89	23	161566	83	4	161665	82	5	161754	88	24
161430	85	5		84	4		111	3	161756	86	17
161431	68	6	161567	76	2		111	14	161757	86	18
161432	67	11	161570	19	2		114	7	161763	73	37
	69	2	161571	74	5	161666	19	40	161764	73	10
161436	54	18	161574	71	3		27	34	161769	41	8
161438	76	13	161575	11	6		52	4	161770	41	10
	82	6	161579	67	20		53	36	161771	46	2
161439	74	3	161585	68	11		54	9	161772	46	1
161440	90	13		74	7		85	4	161773	49	1
161441	74	18	161590	74	6		114	14	161774	48	1

NUMERICAL INDEX

Part No.	Page No.	Ref. No.	Part No.	Page No.	Ref. No.	Part No.	Page No.	Ref. No.	Part No.	Page No.	Ref. No.
161775	48	2	161880	73	3	161967	120	21	162031	41	29
161776	41	18	161881	73	2	161968	121	21	162033	51	19
161777	51	1	161882	73	1	161969	120	24	162034	45	15
161778	51	3	161883	73	4	161970	121	24	162035	27	4
161779	41	19	161884	73	30	161972	120	23	162036	41	25
	51	14	161885	73	38	161973	121	23	162037	41	26
161780	41	17	161886	73	31	161974	120	7	162040	63	7
161781	41	20	161887	73	25	161976	121	9	162041	73	17
161782	41	6	161888	73	36	161977	120	29	162042	51	18
161783	41	7	161889	73	35	161978	121	29	162043	12	7
161784	41	21	161890	73	16	161979	120	15	162044	42	11
161785	45	2	161891	73	48	161980	121	15	162045	51	17
161786	45	3	161892	73	47	161981	120	8	162046	27	19
161788	51	8	161893	73	46	161982	121	12	162049	10	11
161797	73	21	161894	73	39	161983	121	13	162050	42	10
161798	63	11	161895	73	41	161984	120	2	162051	73	6
161799	63	10	161896	28	8	161985	121	2	162052	19	41
161800	22	1	161897	28	7	161986	120	12	162053	10	15
161801	105	12	161898	28	9	161987	121	13	162054	10	12
161802	20	2	161899	28	5	161988	120	13	162055	12	6
161803	19	28	161900	63	17	161989	121	11	162056	92	5
161804	23	1	161901	28	10	161990	121	11	162057	88	12
161805	23	2	161902	23	21	161991	118	3	162058	92	6
	53	26	161903	83	26	161992	118	5	162059	86	11
161806	83	25		84	26	161993	118	1	162060	89	11
	84	25	161915	7	23	161994	118	2	162061	90	8
161807	27	14		9	56	161995	118	3	162064	61	14
161808	27	13	161916	7	19	161996	118	10	162065	33	18
161809	114	10		9	19	161997	118	10	162066	100	21
161810	19	5	161917	7	14	161998	119	3	162067	101	5
161811	19	37		9	40	161999	119	10	162068	102	6
161812	19	35	161918	7	8	161999	120	10	162069	87	11
161813	27	25		9	8	162000	120	11	162071	88	11
161814	52	2	161919	12	1	162001	121	11	162072	89	11
161815	112	1	161920	7	13	162002	121	11	162073	90	8
161816	23	6		77	1	162003	121	10	162074	73	28
161817	23	10	161921	41	16	162004	120	8	162075	12	4
161818	19	1	161922	41	15	162005	111	8	162076	12	5
161819	67	1	161923	41	14	162006	111	4	162077	61	1
161820	23	12	161924	41	13	162007	112	4	162078	60	1
161821	83	20	161925	51	15	162008	112	18	162079	57	3
	84	20	161928	62	1	162009	112	18	162080	57	3
161822	20	1	161929	62	6	162010	112	18	162081	57	1
161824	76	4	161930	7	12	162011	112	10	162082	57	2
161827	12	3		9	12	162012	112	11	162083	57	4
161828	12	2	161931	14	1	162013	113	20	162084	60	14
161829	10	3	161932	15	1	162014	113	1	162085	56	1
161831	53	11	161933	15	2	162015	113	8	162086	84	15
161832	53	10	161934	86	2	162016	113	8	162087	88	28
161833	53	21	161935	87	2	162017	114	6	162088	71	11
161834	53	22	161936	27	9	162018	114	6	162089	71	9
161835	41	1	161937	41	9	162019	114	6	162090	71	8
161836	51	2	161938	45	4	162020	114	6	162091	71	2
161837	51	21	161939	45	5	162021	114	11	162092	71	15
161838	42	5	161940	45	6	162022	114	11	162093	7	32
161839	42	6	161941	45	11	162023	114	11	162094	9	15
161841	43	2	161942	51	9	162024	114	11	162095	9	2
161842	43	4	161943	27	36	162025	114	11	162096	9	3
161843	41	24		28	3	162026	114	11	162097	9	1
161844	41	2		29	5	162027	114	11	162098	9	REF
161845	42	1		114	11	162028	114	10	162099	68	9
161846	42	13	161944	42	3	162029	114	10	162100	120	32
	43	1	161945	27	24	162030	114	12	162101	19	25
161847	43	5	161946	27	37	162031	114	12	162102	9	14
161848	53	13	161947	53	20	162032	114	12	162103	9	23
161849	113	14	161948	22	3	162033	114	12	162104	9	24
161850	112	15		28	2	162034	114	12	162105	9	1
161851	112	17		67	21	162035	114	12	162106	9	REF
161852	61	4	161949	41	11	162036	114	12	162107	34	1
161853	58	1		58	8	162037	114	12	162108	33	1
161854	27	31	161950	41	12	162038	114	12	162109	19	11
161856	58	16	161951	45	12	162039	114	12	162110	91	2
161857	58	19	161953	60	19	162040	114	12	162111	90	2
161858	111	17	161954	66	1	162041	114	12	162112	90	2
161863	89	24	161955	83	21	162042	114	12	162113	90	2
161864	90	14		84	21	162043	114	12	162114	90	2
161866	68	3	161957	45	13	162044	114	12	162115	90	2
161867	63	5	161963	58	7	162045	114	12	162116	90	2
161868	53	16	161964	46	4	162046	114	12	162117	90	2
161871	75	17		47	4	162047	114	12	162118	90	2
161873	54	1		48	3	162048	114	12	162119	90	2
161874	53	1		49	2	162049	114	12	162120	90	2
161875	27	10	161965	120	4	162050	114	12	162121	90	2
161876	28	1		121	4	162051	114	12	162122	90	2
161877	83	15	161966	120	22	162052	114	12	162123	90	2
161879	29	1		121	22	162053	114	12	162124	90	2

NUMERICAL INDEX

Part No.	Page No.	Ref. No.	Part No.	Page No.	Ref. No.	Part No.	Page No.	Ref. No.	Part No.	Page No.	Ref. No.
162113	89	2		114	12		60	13			
162114	88	2	651425	33	19		73	26			
162115	9	13	651426	27	29		111	7			
	78	1		33	22		112	6			
162116	121	32		105	5	656052	7	38			
162117	120	30	651427	33	13		9	49			
	121	30	651428	105	13	656092	51	16			
162118	120	31	651430	86	19	656093	7	28			
	121	31	651434	27	16		9	39			
162119	120	5	651436	63	12		27	28			
162120	121	5	651437	83	10		73	54			
162121	120	9		84	10	656094	60	16			
162122	9	36	651438	19	20		112	3			
162123	82	3		33	34	656100	111	4			
162124	9	34		34	14		111	15			
162515	100	5		35	15		114	8			
	101	4	651440	61	10	656102	57	10			
425-34683	56	5	651445	9	30		73	29			
425-34707	56	6	651446	27	2		73	49			
425-34753	56	12	651447	19	7	656105	22	5			
425-34853	58	22	651448	27	23		60	6			
425-35207	56	10		73	53		67	6			
425-35259	56	4	651451	7	37	656110	86	20			
425-35264	56	13		9	48		88	26			
425-35265	56	14	651454	19	14		89	26			
425-35269	56	15		35	13		90	16			
425-35271	58	20	651457	27	30	656148	19	26			
425-35272	58	21		52	5	656149	27	32			
425-35274	56	22	651458	19	21		29	2			
425-35317	56	19		22	9		52	7			
425-35318	56	18		27	39		58	14			
425-35326	61	2		33	35	656163	42	8			
425-35376	56	23		34	15						
425-35925	56	8		35	16						
425-35973	61	8		73	23						
425-36085	56	7		112	12						
425-36091	61	9	651461	62	2						
425-36101	59	8		85	2						
425-36140	56	2	651462	52	3						
425-36141	56	3	651466	45	18						
425-36142	56	16	651468	7	39						
425-36144	56	9		9	50						
425-36145	56	11		88	30						
425-36146	56	17		91	13						
425-36147	56	20	651469	19	22						
425-36148	56	21	651474	7	26						
425-36149	56	24		9	37						
	111	10	651475	68	4						
425-36150	58	10	651477	27	8						
425-36152	58	13	651480	66	9						
425-36153	59	1	651482	19	38						
425-36154	59	2	651483	39	3						
425-36155	59	3	651485	19	30						
425-36156	59	9	651489	39	2						
425-36157	59	10	651496	19	6						
425-36158	59	11	651498	19	36						
425-36159	59	12	651500	9	28						
425-36160	60	5	651503	23	14						
425-36161	60	11	651505	111	2						
651390	53	14		114	5						
651391	7	40	651507	21	2						
	9	51		81	4						
	61	5	651508	100	7						
	73	13		101	6						
651393	23	3	651515	7	44						
	57	5		9	55						
	60	2	651518	53	3						
	67	3	656001	9	22						
	73	19		20	5						
	73	44		22	4						
651395	27	11		54	5						
	57	11		58	4						
	76	8		62	8						
651396	66	5		69	3						
651397	60	15		73	51						
	66	6		76	5						
	73	43		83	22						
651398	10	4		84	22						
651399	27	21		88	25						
	67	2		89	25						
651408	7	25		90	15						
651410	19	39		112	2						
651411	19	4		116	3						
651412	7	24	656004	27	40						
	9	35		112	11						
651424	53	34	656048	45	14						

TORQUE SPECIFICATIONS

NOTE: Use these torque values when tightening **GEHL** hardware (excluding: Locknuts and Self-tapping, Thread Forming and Sheet Metal Screws) unless specified otherwise.

**All torque values are in Lb-Ft except those marked with an * which are Lb-In
(For metric torque value Nm, multiply Lb-Ft value by 1.355 or Lb-In value by 0.113)
(To convert Nm to Lb-Ft multiply by 0.738)**

Unified National Thread	Grade 2 		Grade 5 		Grade 8 	
	Dry	Lubed	Dry	Lubed	Dry	Lubed
8-32	19*	14*	30*	22*	41*	31*
8-36	20*	15*	31*	23*	43*	32*
10-24	27*	21*	43*	32*	60*	45*
10-32	31*	23*	49*	36*	68*	51*
1/4-20	66*	50*	9	75*	12	9
1/4-28	76*	56*	10	86*	14	10
5/16-18	11	9	17	13	25	18
5/16-24	12		19	14		20
3/8-16	20	15	30	23	45	
3/8-24	23	17	35	25	50	35
7/16-14	32	24	50	35	70	55
7/16-20	36	27	55	40	80	60
1/2-13	50	35	75	55	110	80
1/2-20	55	40	90	65	120	90
9/16-12	70	55	110	80	150	110
9/16-18	80	60	120	90	170	130
5/8-11	100	75	150	110	220	170
5/8-18	110	85	180	130	240	180
3/4-10	175	130	260	200	380	280
3/4-16	200	150	300	220	420	320
7/8-9	170	125	430	320	600	460
7/8-14	180	140	470	360	660	500
1-8	250	190	640	480	900	680
1-14	270	210	710	530	1000	740
Metric Course Thread	Grade 8.8 		Grade 10.9 		Grade 12.9 	
	Dry	Lubed	Dry	Lubed	Dry	Lubed
M6-1	8	6	11	8	13.5	10
M8-1.25	19	14	27	20	32.5	24
M10-1.5	37.5	28	53	39	64	47
M12-1.75	65	48	91.5	67.5	111.5	82
M14-2	103.5	76.5	145.5	108	176.5	131
M16-2	158.5	117.5	223.5	165.5	271	200



Gehl Company 143 Water Street, P.O. Box 179, West Bend, WI 53095-0179, U.S.A.